

Soundmaster UR2170SI

Soundmaster UR 2170SI DAB+/FM PLL Radio CD MP3 USB Under-Cabinet System User Manual

Model: UR2170SI | Brand: Soundmaster

1. INTRODUCTION

Thank you for purchasing the Soundmaster UR 2170SI Under-Cabinet Radio System. This device combines a DAB+/FM PLL radio, CD player, MP3 playback from CD and USB, and an alarm clock function, designed for convenient installation in your kitchen or other suitable locations. Please read this manual carefully before operating the unit to ensure proper use and to maximize its performance and longevity.

2. SAFETY INSTRUCTIONS

- **Power Source:** Use only the specified power adapter. Ensure the voltage matches the unit's requirements.
- **Water and Moisture:** Do not expose the unit to rain, moisture, or dripping/splashing liquids. Do not place objects filled with liquids, such as vases, on the apparatus.
- **Ventilation:** Ensure adequate ventilation. Do not block ventilation openings.
- **Heat:** Keep the unit away from heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- **Cleaning:** Unplug the unit from the wall outlet before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or aerosol cleaners.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.
- **Placement:** Install the unit securely to prevent it from falling.

3. PACKAGE CONTENTS

Please check that all items listed below are included in your package:

- Soundmaster UR 2170SI Main Unit

- Remote Control
- Power Adapter
- Mounting Hardware (screws, spacers, mounting template)
- User Manual (this document)

4. PRODUCT OVERVIEW

The Soundmaster UR 2170SI features a sleek design for under-cabinet installation, integrating various audio functionalities. Below is an overview of the unit's front panel and connections.



Figure 4.1: Front view of the Soundmaster UR 2170SI unit, showing the display, CD tray, control buttons, and USB port.

4.1 Front Panel Controls

- **Display:** Shows current time, radio station, track information, and menu options.
- **CD Tray:** Slot for inserting audio CDs or MP3 CDs.
- **Power Button:** Turns the unit on/off or switches to standby.
- **Volume +/- Buttons:** Adjusts the audio output level.
- **USB Port:** For connecting USB storage devices for MP3 playback.
- **Function (FUNC) Button:** Cycles through different modes (DAB, FM, CD, USB).
- **EQ Button:** Selects equalizer presets.
- **Playback Control Buttons:** Play/Pause, Stop, Skip Forward/Backward.
- **Preset/Alarm Buttons (P+/-AL1/AL2):** For setting and recalling radio presets and alarms.
- **Timer Button:** Sets the sleep timer.
- **Dimmer Button:** Adjusts display brightness.
- **Memory (MEM) Button:** Saves radio presets.
- **Info Button:** Displays additional information (e.g., DAB station details).

4.2 Rear Connections

- **DC IN Jack:** Connect the provided power adapter here.
- **FM/DAB Antenna Input (75 Ohm):** Connect the external antenna for optimal radio reception.

5. SETUP

5.1 Mounting the Unit

The Soundmaster UR 2170SI is designed for under-cabinet installation. Ensure the mounting surface is sturdy and can support the weight of the unit.

1. **Positioning:** Choose a suitable location under a cabinet, ensuring enough space for CD insertion and button access.

2. **Template:** Use the provided mounting template to mark the screw positions on the underside of the cabinet.
3. **Drilling:** Drill pilot holes at the marked positions.
4. **Attaching Spacers:** If necessary, attach the provided spacers to the unit or cabinet to ensure proper clearance.
5. **Securing:** Align the unit with the pilot holes and secure it using the provided screws. Do not overtighten.



Figure 5.1: The Soundmaster UR 2170SI unit securely mounted under a kitchen cabinet.



Figure 5.2: The Soundmaster UR 2170SI integrated into a kitchen environment, demonstrating its under-cabinet placement.

5.2 Power Connection

Connect the provided power adapter to the DC IN jack on the rear of the unit, then plug the adapter into a wall outlet.

5.3 Antenna Connection

Connect the external antenna to the 75 Ohm antenna input on the rear of the unit. Extend the antenna fully for optimal DAB+ and FM reception.

5.4 Initial Power-On and Settings

1. Press the **Power** button to turn on the unit.
2. The unit may prompt you to select a language or perform an initial DAB scan. Follow the on-screen instructions.
3. **Setting Time/Date:** If not automatically set by DAB, navigate to the system settings menu (refer to the full manual for detailed menu navigation) to manually set the time and date.

6. OPERATING INSTRUCTIONS

6.1 Radio Operation (DAB+/FM)

1. Press the **FUNC** button repeatedly to select DAB or FM mode.
2. **DAB Auto Scan:** In DAB mode, the unit will typically perform an auto scan upon first use or if no stations are found. To manually initiate a scan, refer to the system menu.
3. **FM Auto Scan:** In FM mode, press and hold the Skip Forward/Backward buttons to auto-scan for the next available station.
4. **Manual Tuning:** Briefly press the Skip Forward/Backward buttons to fine-tune the frequency.
5. **Saving Presets:** Tune to your desired station. Press and hold the **MEM** button, then use the P+/- buttons to select a preset number. Press **MEM** again to confirm.
6. **Recalling Presets:** Briefly press the P+/- buttons to cycle through saved presets.

6.2 CD/MP3 Playback

1. Press the **FUNC** button to select CD mode.
2. Gently insert a CD (audio CD or MP3 CD) into the CD tray with the label side facing up. The unit will automatically load the disc.
3. Playback should start automatically. If not, press the **Play/Pause** button.
4. Use the **Skip Forward/Backward** buttons to navigate between tracks.
5. For MP3 CDs with folders, use the Folder +/- buttons (if available on the unit or remote) to navigate between folders.
6. Press the **Stop** button to stop playback.

6.3 USB Playback

1. Insert a USB storage device (e.g., USB flash drive) containing MP3 files into the USB port on the front of the unit.
2. Press the **FUNC** button to select USB mode.

3. The unit will read the USB device and begin playback.
4. Use the **Playback Control** buttons (Play/Pause, Stop, Skip Forward/Backward) to manage playback.
5. Use the Folder +/- buttons (if available) to navigate through folders on the USB device.

6.4 Alarm and Timer Functions

The unit includes two independent alarms (AL1, AL2) and a sleep timer.

- **Setting Alarms:** Press and hold the **AL1** or **AL2** button. Use the Volume +/- or Skip buttons to set the alarm time, alarm source (Buzzer, DAB, FM, CD, USB), and alarm volume. Press the AL button again to confirm each setting.
- **Activating/Deactivating Alarms:** Briefly press the **AL1** or **AL2** button to toggle the alarm on or off. An alarm icon will appear on the display when active.
- **Sleep Timer:** Press the **Timer** button repeatedly to cycle through available sleep timer durations (e.g., 15, 30, 60, 90 minutes, OFF). The unit will automatically turn off after the selected time.

6.5 Remote Control

The included remote control provides convenient access to all major functions.



Figure 6.1: The remote control for the Soundmaster UR 2170SI, showing various function buttons.

- **Battery Installation:** Open the battery compartment on the back of the remote and insert 2x AAA batteries (not included), observing polarity.
- **Functionality:** The remote mirrors most front panel controls, including Power, Volume, Function selection, Playback controls, EQ, Info, Memory, Timer, and Alarm settings.

7. MAINTENANCE

- **Cleaning the Unit:** Wipe the exterior of the unit with a soft, dry, lint-free cloth. Do not use abrasive cleaners, waxes, or solvents.
- **CD Player Care:** Handle CDs by their edges. If a CD is dirty, wipe it gently with a soft, dry cloth from the center outwards. Do not use scratched or damaged CDs.
- **Storage:** If storing the unit for an extended period, disconnect it from the power supply and store it in a cool, dry place.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power adapter not connected; Wall outlet not active.	Ensure power adapter is securely connected to the unit and a working wall outlet.
No sound	Volume too low; Mute function active; Incorrect source selected.	Increase volume; Check if mute is active; Press FUNC to select the correct source.
Poor radio reception	Antenna not extended or connected; Weak signal.	Extend and adjust the antenna; Try repositioning the unit for better signal.
CD not playing	CD inserted incorrectly; CD is dirty or scratched; Incorrect mode selected.	Re-insert CD correctly; Clean or replace CD; Select CD mode using FUNC button.
USB device not recognized	USB device not formatted correctly; Incompatible file types; USB device damaged.	Ensure USB is FAT32 formatted; Only MP3 files are supported; Try a different USB device.
Remote control not working	Batteries depleted or inserted incorrectly; Obstruction between remote and unit.	Replace batteries, check polarity; Ensure clear line of sight to the unit's sensor.

9. SPECIFICATIONS

Feature	Description
Model Number	UR2170SI
Brand	Soundmaster
Tuner Type	Digital
Supported Bands	DAB+, FM (PLL)

Feature	Description
Optical Drive Type	CD Player
Supported Disc Types	CD, CD-R, CD-RW, CD-MP3
Connectivity	USB (1 port)
Compatible Devices	Smartphone, MP3 player, tablet (via USB for playback)
Audio Format Support	CD-DA, MP3 (from CD and USB)
Speaker Type	Stereo
Output Power	3 Watts
Power Source	Electric Cable (AC Adapter)
Dimensions (L x W x H)	Approximately 10 x 10 x 10 centimeters (Note: This dimension seems generic, actual product is wider for under-cabinet mounting. Refer to product images for visual scale.)
Color	Silver
Bluetooth Compatible	No

10. WARRANTY AND SUPPORT

Soundmaster products are designed and manufactured to the highest quality standards. In the unlikely event that you experience any issues with your Soundmaster UR 2170SI, please refer to the warranty information provided with your purchase documentation.

For technical support, service, or further inquiries, please contact your local Soundmaster dealer or visit the official Soundmaster website for contact information.

Please retain your proof of purchase for warranty purposes.

Related Documents - UR2170SI



[soundmaster ICD1050: Ihr umfassender Leitfaden für Internetradio, DAB, CD und mehr](#)

Entdecken Sie die Funktionen des soundmaster ICD1050 Hi-Fi-Systems mit diesem detaillierten Benutzerhandbuch. Erfahren Sie mehr über Installation, Bedienung von Internetradio, DAB, CD, USB, Bluetooth und erhalten Sie Tipps zur Fehlerbehebung.



soundmaster MCD5550 Bedienungsanleitung

Umfassende Bedienungsanleitung für das soundmaster MCD5550 Hifi-Musikcenter. Enthält Informationen zu DAB+ Radio, CD, Kassette, Bluetooth, Plattenspieler, USB/SD-Wiedergabe und MP3-Aufnahme.



soundmaster CD9220 Tragbarer CD-Player Bedienungsanleitung

Umfassende Bedienungsanleitung für den tragbaren CD-Player soundmaster CD9220. Enthält Informationen zu Funktionen, Sicherheit, Bedienung und Fehlerbehebung für Audio-CDs, MP3 und WMA.



Soundmaster NR545DAB: Bedienungsanleitung und Funktionen

Umfassende Bedienungsanleitung für das Soundmaster NR545DAB Musiksysteem. Erfahren Sie mehr über die Funktionen wie CD, DAB/FM-Radio, USB, Bluetooth und Plattenspieler sowie Anleitungen zur Einrichtung und Nutzung.



Soundmaster NR545DAB Bedienungsanleitung

Umfassende Bedienungsanleitung für das Soundmaster NR545DAB Nostalgie Stereo DAB+/UKW Digitalradio mit Plattenspieler, CD/MP3, USB, Kassette und Bluetooth.



[pdf] Datasheet

Büro soundmaster TH21PR TH21 ENsoundmaster de Datasheets PR EN srsltid AfmBOOrCb0jdj8b6F E0VZk4DbzEvtM7 CHyyiqbvlqAfEhYm7D8Bdf3 deUniversal smartphone table holder * Suitable for UR2195SI UR2180SI and prepared UR2170SI* from PO No 20935 Max diameter 10 270° swiveablePR ENPR AfmBOoohsBICdetXfbdXfkey0mupU8zILsDUtlZt5fz6A1hb9wkNCbXsoundmaster ||| ||| soundmaster - TH21 Smartphone/Tablet holder for soundmaster UR2195SI/UR2180SI * Universal smartphone /table holder * Suitable for UR2195SI/UR2180SI and prepared UR2170SI* from PO-No. 20935 * Max. diameter 10 * 270 swiveable * Inclunable in soundmaster - TH21 Smartphone/Tablet holder for soundmaster UR2195SI/UR2180SI * Universal smartphone /table holder * Suitable for UR2195SI/UR2180SI and prepared **UR2170SI*** from PO-No. 20935 * Max. diameter 10 * 270 swiveable * Inclunable in two-steps 90 and 115 * GTIN: 4005425008842 * VP...

lang:nl score:32 filesize: 261.53 K page_count: 1 document date: 2025-06-27

[pdf] Datasheet



Büro soundmaster TH21PR TH21 DESoundmaster de Datasheets PR DE srsltid AfmBOOqpWArvzedIFyzRXuIV0iF6kjqySU8uqoltg0Mk3qSVf BOG G9 TH21soundmaster DEPR G9soundmaster AfmBOOqerujGuSSelRTNuMkSgcLTBuXoM2VErit80uLDulm3y2SPvjs8 AfmBOOqerujGuSSelRTNuMkSgcLTBuXoM2VErit80uLDulm3y2SPvjs8soundmaster AfmBOOpQ6y49ta50YjAS65zmejs7y1354sYiUISLsFnOF7jL4JukKAFysoundmaster ||| ||| soundmaster - TH21 Smartphone/Tablet Halterung fr soundmaster UR2195SI/UR2180SI * Universal Smartphone/Tablet Halterung * Geeignet fr UR2180SI/UR2195SI und vorbereiteten UR2170SI* * ab PO-Nr. 20935 * Max. Diagonale bis 25,4 cm * 270 drehbar ||| soundmaster - TH21 Smartphone/Tablet Halterung fr soundmaster UR2195SI/UR2180SI * Universal Smartphone/Tablet Halterung * Geeignet fr UR2180SI/UR2195SI und vorbereiteten UR2170SI* * ab PO-Nr. 20935 * Max. Diagonale bis 25,4 cm * 270 drehbar ||| soundmaster - TH21 Smartphone/Tablet Halterung fr soundmaster UR2195SI/UR2180SI * Universal Smartphone/Tablet Halterung * Geeignet fr UR2180SI/UR2195SI und vorbereiteten UR2170SI* * ab PO-Nr. 20935 * Max. Diagonale bis 25,4 cm * 270 drehbar soundmaster - TH21 Smartphone/Tablet Halterung fr soundmaster UR2195SI/UR2180SI * Universal Smartphone/Tablet Halterung * Geeignet fr UR2180SI/UR2195SI und vorbereiteten **UR2170SI*** * ab PO-Nr. 20935 * Max. Diagonale bis 25,4 cm * 270 drehbar * Neigbar mit zweistufiger Arretierung 90 und 115 * GTI...

lang:nl score:32 filesize: 262.72 K page_count: 1 document date: 2025-06-27



[pdf]

PR UR2170SI DE jhofmann woerlein 80 verkaufsprospekte |||

soundmaster - **UR2170SI** Design CD/MP3 Musik-Center zum Unterbau mit DAB /UKW Radio und USB Anschluss * DAB / UKW PLL-Radio * Negatives LCD-Display * CD, CD-R, CD-RW, CD-MP3 * USB-Anschluss * 24 Stunden LCD-Uhr * Countdown Funktion * vorgeprogrammierter Equalizer * Leistung 2 x 3 Watt RMS * Unterbauf...
lang:nl score:28 filesize: 345.23 K page_count: 1 document date: 2015-02-24



[pdf] Declaration of Conformity

Microsoft Word Leaflet Soundmaster TH21 doc GIZMO Cannenburgerweg 63 A3 1244 RH Ankeveen T 31 0 35 6561964 E info@gizmo retail nl W gizmo Universele smartphone leaflet soundmaster th21 media product l e |||

TH21 Universele smartphone / tablet houder voor keukenunderbouw radio s
Makkelijker kunnen we het u niet maken, koken wordt steeds leuker De Soundmaster TH21 is een universele houder voor uw smartphone of tablet. Deze houder is geschikt voor de Soundmaster UR2195SI en Soundmaster **UR2170SI** keuken o...
lang:nl score:27 filesize: 200 K page_count: 1 document date: 2017-09-28



[pdf]

LOCATION OF CONTROLS alina BL UR2170SI DE soundmaster de Manuals |||

DEUTSCH ENGLISH FRANÇAIS NEDERLANDS NORSK SVENSKA Hersteller Wrllein GmbH Gewerbestrasse 12 D 90556 Cadolzburg GERMANY Tel.: 49 9103/71670 Fax.: 49 9103/716712 Email. info soundmaster.de Web: www.soundmaster.de
Vers.2.1 UR2170 VORSICHT UNSICHTBARE LASERSTRAHLUNG TRITT AUS, WENN DER DECKEL GE...
lang:de score:26 filesize: 5.98 M page_count: 105 document date: 2021-01-08



[pdf]

Microsoft Word Leaflet Soundmaster TH21 Marketing info@gizmo retail nl W il y a 8 heures —

Makkelijker kunnen we het u niet maken, koken wordt steeds leuker! De is een universele houder voor uw smartphone of tablet leaflet soundmaster th21 2 gizmo pub media product l e |||

TH21 Universele smartphone-/tablethouder voor keukens onderbouwradio's

Makkelijker kunnen we het u niet maken, koken wordt steeds leuker De Soundmaster TH21 is een universele houder voor uw smartphone of tablet. Deze houder is geschikt voor de Soundmaster UR2195SI en **UR2170SI** keukens onderbouwradio's...

lang:nl score:26 filesize: 175.06 K page_count: 1 document date: 2022-06-14



[pdf] Datasheet

TH21 soundmaster de Universal smartphone table holder Suitable for UR2195SI and prepared

UR2170SI* * from PO No 20935 PR EN Datasheets |||

TH21 Universal smartphone /table holder Technical Features: Universal smartphone

/table holder Suitable for UR2195SI and prepared **UR2170SI*** * from PO-No. 20935

Max. diameter 10 270 swiveable Inclunable in two-steps 90 and 115 Dim: 20,2 cm x

4,0 cm x 13,7 cm Unit: 10 pcs GTIN: 4005425008842 ...

lang:nl score:24 filesize: 1.18 M page_count: 1 document date: 2024-04-05



[pdf]

Untitled Produktdatenblatt SOUNDMASTER HIGHLINE Küchenunterbauradio UR2170SI DAB UKW

silber D631130 D pollin at media 8b 0a 80 1701723461 |||

UR2170SI Design CD/MP3 Musik-Center zum Unterbau mit DAB /UKW Radio und

USB Anschluss Technische Daten: DAB / UKW-RDS Radio Festsenderspeicher

Negatives LCD-Display CD, CD-R, CD-RW, CD-MP3 USB-Anschluss 24 Stunden

LCD-Uhr Countdown Funktion Vorprogrammierter Equalizer Leistung 2 x 3 Watt R...

lang:nl score:24 filesize: 210.44 K page_count: 1 document date: 2022-10-08



[pdf] Datasheet

TH21 soundmaster de Universal Smartphone Tablet Holder Suitable for UR2195SI and prepared UR2170SI* * from PO No 20935 PR EN media woerlein Datasheets |||

TH21 Universal Smartphone/Tablet Holder Technical Features: Universal Smartphone/Tablet Holder Suitable for UR2195SI and prepared **UR2170SI*** * from PO-No. 20935 Max. diameter 10 270 swiveable Inclinable in two-steps 90 and 115 Dim: 20,2 cm x 4,0 cm x 13,7 cm Unit: 10 pcs GTIN: 4005425008842 ...

lang:nl score:24 filesize: 1.18 M page_count: 1 document date: 2022-01-20



[pdf] Declaration of Conformity

PR UR2170SI EN Produktový list 2 51 MB Radiopřijímač s DAB Soundmaster stříbrný KASA cz doc 3724818 kasa document 8 1 |||

UR2170SI Under Cabinet CD/MP3 Kitchen Music Centre with DAB /FM Radio, 75 ohm Antenna Jack, USB and Remote Control Technical Features: DAB / FM-RDS Radio Preset Stations Negative LCD-Display CD, CD-R, CD-RW, CD-MP3 USB Slot LCD Clock Countdown Function Equalizer 2 x 3 Watt RMS Mounting Ki...

lang:nl score:23 filesize: 2.51 M page_count: 1 document date: 2018-08-22



[pdf] Datasheet

UR2170SI soundmaster® Dec 25 2019 — DAB UKW RDS Radio Festsenderspeicher Negatives LCD Display CD R RW MP3 USB Anschluss 24 Stunden Uhr Countdown Funktion PR DE soundmaster de media woerlein Datasheets |||

UR2170SI Design CD/MP3 Musik-Center zum Unterbau mit DAB /UKW Radio und USB Anschluss Technische Daten: DAB / UKW-RDS Radio Festsenderspeicher Negatives LCD-Display CD, CD-R, CD-RW, CD-MP3 USB-Anschluss 24 Stunden LCD-Uhr Countdown Funktion Vorprogrammierter Equalizer Leistung 2 x 3 Watt R...

lang:nl score:23 filesize: 2.15 M page_count: 1 document date: 2021-12-14



[pdf]

LOCATION OF CONTROLS alina Location of controls Deckblatt UR2170 Sicherheitshinweis Unterbau mit CD DEUTSCH 1 Warnings NORWEGIAN BDA UR2170SI 20532 soundmaster de media woerlein Manuals |||

DEUTSCH ENGLISH FRANÇAIS Hersteller Wrllein GmbH Gewerbestrasse 12 D 90556 Cadolzburg GERMANY Tel.: 49 9103/71670 Fax: 49 9103/71672 Email: info@woerlein.com Web: www.woerlein.com NEDERLANDS NORSK SVENSK Version 2 UR2170 / **UR2170SI** VORSICHT UNSICHTBARE LASERSTRAHLUNG TRITT AUS, WENN DER DE...

lang:de score:22 filesize: 9.44 M page_count: 108 document date: 2015-07-31



[Soundmaster UR2170SI Under Cabinet Kitchen Music Centre - DAB+/FM Radio, CD, USB](#)

Discover the Soundmaster UR2170SI, a versatile under-cabinet kitchen music centre featuring DAB+/FM radio, CD playback, MP3 support, USB connectivity, and a negative LCD display. Includes technical specifications and features.

lang:de score:22 filesize: 2.15 M page_count: 1 document date: 2021-12-14



[pdf]

soundmaster® Created Date 12 8 2014 3 23 03 PM CE UR2170SI 20532 soundmaster de media woerlein Konformitaetserklaerungen |||

/, I/r Der Unterzeichner WORLEIN GMBH GEWERBESTRASSE 12 D-90556 Cadolzburg erklrt hiermit, dass das Produkt Produkt: soundmaster- UR2170 Unterbauradio DAB IUKIV, CD-MP3 und USB in Ubereinstimmung ist mit den Bestimmungen der nachstehenden EG-Richtlinie n einschlielich aller zutreffenden Anderu...

lang:de score:22 filesize: 59.34 K page_count: 1 document date: 2014-12-08



[\[pdf\]](#) Declaration of Conformity

Untitled Claude Bühler DANKE! Bitte beachten Sie unsere Öffnungszeiten über die Festtage

SCD5750RO rot SOUNDMASTER CD Kassette FM Mikrofon Boombox mit Kassetten Rekorder und Tuner Player R RW MP3 Neuheiten Dezember 2016 UVP niwotron ch index cfm action act getfile doc id 100891 |||

NEWSLETTER Ausgabe: 12/2016 ... DABMAN i400 IMPERIAL DAB / Internet / FM / Bluetooth HiFi-Adapter ... - USB-Anschluss Wiedergabe von MP3 - Batteriebetrieb: 6xUM2 nicht mitgeliefert Art.-Nr. 00-6734 **UR2170SI** SOUNDMASTER DAB / FM / CD / USB - Kchen-Unterbau Stereo-Radio mit CD und DAB und FM-Tuner...

lang:de score:21 filesize: 382.84 K page_count: 4 document date: 2016-12-01



[\[pdf\]](#)

LOCATION OF CONTROLS alina Location of controls UR2170 UR2170SI VORSICHT UNSICHTBARE LASERSTRAHLUNG TRITT AUS WENN DER DECKEL GEÖFFNET UND DIE SICHERHEITSVERRIEGLUNG NIEDERGEDRÜCKT WIRD BDA 21116 soundmaster de media woerlein Manuals |||

DEUTSCH ENGLISH FRANÇAIS Hersteller Wrlein GmbH Gewerbestrasse 12 D 90556 Cadolzburg GERMANY Tel.: 49 9103/71670 Fax.: 49 9103/716712 Email. info woerlein.com Web: www.woerlein.com NEDERLANDS NORSK SVENSK Version 2 UR2170 / **UR2170SI** VORSICHT UNSICHTBARE LASERSTRAHLUNG TRITT AUS, WENN DER DE...

lang:de score:21 filesize: 6.04 M page_count: 110 document date: 2018-01-23



[\[pdf\]](#)

LOCATION OF CONTROLS alina Bedienungsanleitung BDA UR2170SI 21420 Design CD MP3 Musik Center zum Unterbau mit DAB UKW Radio und USB Anschluss soundmasterÂ® soundmaster de media woerlein Manuals |||

DEUTSCH ENGLISH FRANÇAIS NEDERLANDS NORSK SVENSKA Hersteller Wrlein GmbH Gewerbestrasse 12 D 90556 Cadolzburg GERMANY Tel.: 49 9103/71670 Fax.: 49 9103/716712 Email. info soundmaster.de Web: www.soundmaster.de Vers.2.1 UR2170 VORSICHT UNSICHTBARE LASERSTRAHLUNG TRITT AUS, WENN DER DECKEL GE...

lang:de score:19 filesize: 5.97 M page_count: 105 document date: 2021-05-26



[\[pdf\]](#) Declaration of Conformity

soundmaster 2024 niwotron ch index cfm action act getfile doc id 102184 |||

electronic 2024/25 Nachhaltigkeit sustainability Nachhaltig und verantwortungsvoll zu arbeiten, ... Cooking timer Output power 3 W RMS Under cabinet mounting kit incl. AC/DC adaptor 5 V/2 A incl. **UR2170SI** Kchenunterbau Stereo Musikcenter mit DAB /UKW Radio, CD/MP3, USB Kitchen under cabinet ste...

lang:en **score:18** filesize: 16.97 M page_count: 68 document date: 2024-09-12



[\[pdf\]](#) Declaration of Conformity

soundmaster 2023 niwotron ch index cfm action act getfile doc id 102006 |||

electronic 2023/24 Nachhaltigkeit sustainability Nachhaltig und verantwortungsvoll zu arbeiten, ... Cooking timer Output power 3 W RMS Under cabinet mounting kit incl. AC/DC adaptor 5 V/2 A incl. **UR2170SI** Kchenunterbau Stereo Musikcenter mit DAB /UKW Radio, CD/MP3, USB Kitchen under cabinet ste...

lang:en **score:18** filesize: 13.99 M page_count: 64 document date: 2023-02-10



[\[pdf\]](#)

Herunterladen Pro AV Multimedia Audio Radio Streaming Radios Soundmaster SCD2120GR Grün

NewStore GmbH Support index dispatch attachments getfile attachment id 6465 shop newstore ch |||

50 Jahre electronic 2018/19 Inhalt 2018/19 2 www.woerlein.com Bluetooth DAB Internet 2018 ... n von Tablets und Smartphones To fix tablets or smartphones Kche Badezimmer Kitchen Bathroom **UR2170SI** Design CD/MP3 Musik-Center zum Unterbau mit DAB /UKW Radio und USB Anschluss Under Cabinet ...

lang:de **score:18** filesize: 9.26 M page_count: 68 document date: 2018-02-15

EU - Konformitätserklärung (DOC)

Der Unterzeichner

WÖRLEIN GMBH
GEWERBESTRASSE 12
D-90556 Cadzburg

erklärt hiermit in alleiniger Verantwortung, dass das Produkt

Produkt: soundmaster - UR2170SI
Kochenunterbauradio

in Übereinstimmung ist mit den Bestimmungen der nachstehenden EG-Richtlinie(n)
(einschließlich aller zutreffenden Änderungen)

Referenz-Nr.	Titel
2014/53/EU	RED Richtlinie
2009/125/EC	Ökodesignrichtlinie
2011/65/EC	RoHS Richtlinie

und dass folgende Normen und/oder technische Spezifikationen zur Anwendung gelangt sind:

Nr.	Artikel	Standard	
1.	3.1a	EN 55065:2014	EN 63479:2010
2.	3.1b	EN 55032:2015	EN 60335:2017
3.	3.1b	EN 61000-3-2:2014	EN 61000-3-3:2013
4.	3.2	Final Draft EN 300 343 V1.1.7	
5.	ErP	Verordnung 1275/2008	
6.	RoHS	EN 50581:2012	

Das Prüflabor SGS-CSTC Standards Technical Services Co., Ltd Shenzhen Branch hat die Prüfberichte, welche die Konformität bescheinigen, ausgestellt.

Cadzburg, den 27.04.2018

WÖRLEIN GMBH
Gezeichnet durch:
D-90556 Cadzburg
Tel: 09133-71167-0
Fax: 09133-71167-12
Ralf Wörlein - Geschäftsführer

[pdf] Decleration of Conformity

1 3 1a EN 60065 2014 2 1b 55032 2015 61 soundmaster® in Übereinstimmung ist mit den

Bestimmungen der nachstehenden EG Richtlinie n einsch l ießl ich aller zutreffenden Anderu gen Created

Date 31 2019 11 10 48 AM CE UR2170SI 21116 soundmaster de media woerlein

Konformitätserklaerungen |||

EU - Konformittserklrunq DOC Der Unterzeichner GMBH GEWERBESTRASSE 12 D-90556 Cad erklrt hiermit in alleiniger Verantwortung, dass das Produkt Produkt:

soundmaster- UR2170S Kchenunterbauradio in bereinstimmung ist mit den

Bestimmungen der nachstehenden EG-Richtlinie n einsch l iel ich aller z...

lang:de **score:18** filesize: 797.43 K page_count: 1 document date: 2019-01-31



[pdf] Borchure Catalog

electronic gizmo retail nl Unsere hauseigene Servicewerkstatt hat nahezu 100 % aller Ersatzteile auch für

Altgeräte auf Lager ein Gerät einfach als Müll Es wird k Soundmaster catalogus 2020 2021 pub media

wysiwyg Brochures |||


electronic 2020/21 Nachhaltigkeit sustainability Nachhaltig und verantwortungsvoll zu

arbeiten, ... e Kitchen Timer Aux In Jack Remote Control included AC/DC Adapter

included Ouput Power 5W RMS **UR2170SI** Design CD/MP3 Musik-Center zum

Unterbau mit DAB /UKW Radio und USB Anschluss Under Cabinet...

lang:en **score:17** filesize: 9.89 M page_count: 56 document date: 2020-03-23



[pdf] User Manual Instructions

LOCATION OF CONTROLS alina soundmaster highline UR2170SI Under Cabinet FM DAB CD Alarm

output can be set to or Buzzer sound o Automatic Manual search and Up Down features are provided

Electronic Volume Control 32 34da2c57badd2e3d0990cb26990ec47 files ecommercecdns uk 227502

ENVIRONMENTAL PROTECTION Do not dispose of this product with the normal

household waste at the end of its life cycle. Return it to a collection point for the

recycling of electrical and electronic devices. This is indicated by the symbol on the

product, user manual or packaging. The materials are re...

lang:en **score:17** filesize: 1.66 M page_count: 16 document date: 2015-08-03




[\[pdf\]](#) Decleration of Conformity

soundmaster 2021 niwotron ch index cfm action act getfile doc id 101817 |||

electronic 2021/22 Nachhaltigkeit sustainability Nachhaltig und verantwortungsvoll zu arbeiten, ... e Kitchen Timer Aux In Jack Remote Control included AC/DC Adapter included Ouput Power 5W RMS **UR2170SI** Design CD/MP3 Musik-Center zum Unterbau mit DAB /UKW Radio und USB Anschluss Under Cabinet...

lang:en **score:17** filesize: 15.12 M page_count: 60 document date: 2021-04-12



[\[pdf\]](#) Decleration of Conformity

electronic Gizmo Retail Unsere hauseigene Servicewerkstatt hat nahezu 100 % aller Ersatzteile auf Lager auch für Altgeräte Es wird kein Gerät einfach als Müll soundmaster 2020 niwotron ch index cfm action act getfile doc id 101650 |||

electronic 2020/21 Nachhaltigkeit sustainability Nachhaltig und verantwortungsvoll zu arbeiten, ... e Kitchen Timer Aux In Jack Remote Control included AC/DC Adapter included Ouput Power 5W RMS **UR2170SI** Design CD/MP3 Musik-Center zum Unterbau mit DAB /UKW Radio und USB Anschluss Under Cabinet...

lang:en **score:17** filesize: 14.47 M page_count: 56 document date: 2020-03-23



[\[pdf\]](#) Datasheet

PR TH21 DE soundmaster de media woerlein Datasheets

TH21 Universal Smartphone/Tablet Halterung Technische Daten: Universal Smartphone/Tablet Halterung Geeignet fr UR2195SI und vorbereiteten **UR2170SI*** * ab PO-Nr. 20935 Max. Diagonale bis 10 270 drehbar Neigbar mit zweistufiger Arretierung 90 und 115 Mae: 20,2 cm x 4,0 cm x 13,7 cm VPE: 10 Stk... lang:en **score:17** filesize: 1.18 M page_count: 1 document date: 2021-07-19



[\[pdf\]](#) Borchure Catalog

hier Marken Gizmo Retail Soundmaster catalogus 2021 2022 gizmo retail nl media wysiwyg Brochures ||| electronic 2021/22 Nachhaltigkeit sustainability Nachhaltig und verantwortungsvoll zu arbeiten, ... e Kitchen Timer Aux In Jack Remote Control included AC/DC Adapter included Ouput Power 5W RMS **UR2170SI** Design CD/MP3 Musik-Center zum Unterbau mit DAB /UKW Radio und USB Anschluss Under Cabinet... lang:en **score:17** filesize: 11.48 M page_count: 60 document date: 2021-06-28



[pdf] Catalog

Unser Neuheiten Katalog 2023 24 als Download Blogbereich links Blog soundmaster® Kat2023 HQ woerlein.org Catalogues ||| electronic 2023/24 Nachhaltigkeit sustainability Nachhaltig und verantwortungsvoll zu arbeiten, ... Cooking timer Output power 3 W RMS Under cabinet mounting kit incl. AC/DC adaptor 5 V/2 A incl. **UR2170SI** Kchenunterbau Stereo Musikcenter mit DAB /UKW Radio, CD/MP3, USB Kitchen under cabinet ste... lang:en **score:17** filesize: 61.1 M page_count: 64 document date: 2023-02-09



[pdf] Dimension Guide Declaration of Conformity

Untitled Claude Bühler MERCI! Veuillez faire attention à nos jours d ouverture Samedi Adaptateur HiFi avec DAB radio internet et FM RDS Pour le complément des systèmes existants Accès en par LAN ou WLAN WEP WPA WPA2 Nouveautees D niwotron.ch index.cfm action.act.getfile.doc.id.100892.spr.fr ||| NEWSLETTER Edition: 12/2016 ... DABMAN i400 IMPERIAL DAB / Internet / FM / Bluetooth Adaptateur H ... ion USB lecture de MP3 PV CHF 99.00 prix net: avec login sur le shop online n.d.art. 00-6734 **UR2170SI** SOUNDMASTER DAB / FM / CD / USB Dtails - Radio stro avec lecteur CD et tuner DAB /DAB et... lang:fr **score:17** filesize: 413.22 K page_count: 4 document date: 2016-12-01



[pdf]

LOCATION OF CONTROLS alina v1 gizmo retail.nl media product g e gebruiksaanwijzing soundmaster ur2170si ||| DEUTSCH ENGLISH FRAN AIS Hersteller W rlein GmbH Gewerbestrasse 12 D 90556 Cadolzburg GERMANY Tel.: 49 9103/71670 Fax.: 49 9103/716712 Email. info@woerlein.com Web: www.woerlein.com NEDERLANDS NORSK SVENSK Version 2 UR2170 / **UR2170SI** VORSICHT - UNSICHTBARE LASERSTRAHLUNG TRITT AUS, WENN D... lang:de **score:16** filesize: 9.44 M page_count: 108 document date: 2015-07-31

