

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Magic Wand](#) /

› [Magic Wand Rechargeable HV-270 Personal Massager Instruction Manual](#)

## Magic Wand HV-270

# Magic Wand Rechargeable HV-270 Personal Massager Instruction Manual

Model: HV-270 | Brand: Magic Wand

## 1. INTRODUCTION

Thank you for choosing the Magic Wand Rechargeable HV-270. This manual provides essential information for the safe and effective use of your personal massager. Please read it thoroughly before first use and retain it for future reference.



Figure 1: Magic Wand Rechargeable HV-270 Personal Massager

## 2. IMPORTANT SAFETY INFORMATION

- Do not use in or near water.
- Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.
- The Magic Wand Rechargeable massager is ETL listed for compliance with North American safety standards and registered with the FDA as a Class I medical device.

### 3. PRODUCT FEATURES

The Magic Wand Rechargeable HV-270 offers advanced features for a customizable experience:

- **Cordless Convenience:** Enjoy up to 3 hours of cordless use on a full charge.
- **Plug-and-Play Power:** For uninterrupted sessions, plug in the included six-foot AC A/C cord for continuous power.
- **Variable Speeds:** Select from four intensities, reaching up to 6,300 RPM.
- **Vibration Patterns:** Choose from four distinct vibration patterns.
- **Ergonomic Design:** Features an ergonomic long-body design with a flexible neck and soft silicone head for comfortable contouring.
- **Body-Safe Material:** The cushioned head is made from seamless, non-porous silicone, ensuring hygiene and ease of cleaning.
- **Automatic Shut-off:** Includes an automatic 20-minute shut-off feature for safety and battery longevity.



Figure 2: Key features of the Magic Wand Rechargeable massager including high capacity motor, 3-hour battery life, 4 speeds, and soft silicone head.

## 4. SETUP AND CHARGING

### 4.1 Initial Charge

Before first use, fully charge your Magic Wand Rechargeable massager. Connect the included AC A/C power cord to the charging port located at the base of the massager and plug it into a standard electrical outlet. The indicator lights will show charging progress.

### 4.2 Plug-and-Play Option

For continuous use, the massager can be operated while plugged in, even if the battery is not fully charged. This provides maximum, uninterrupted power.



Figure 3: The 6-foot AC A/C power cord for charging and continuous power.

## 5. OPERATING INSTRUCTIONS

The Magic Wand Rechargeable features intuitive 8-function controls:

1. **Power On/Off:** Press the power button (circular icon) to turn the massager on or off.
2. **Adjust Intensity (Speeds):** Use the middle button (three horizontal lines icon) to cycle through

four variable speeds. The blue indicator lights will show the current intensity level.

3. **Select Vibration Patterns:** Use the rightmost button (wave icon) to select one of the four distinct vibration patterns. The green indicator lights will show the selected pattern.



Figure 4: Control panel with power, intensity, and pattern selection buttons.

## 5.1 Official Product Overview

*Video 1: An official overview of the Magic Wand Rechargeable HV-270, demonstrating its features and controls. This video is provided by Vibratex, Inc., the product seller.*

## 6. MAINTENANCE AND CARE

To ensure the longevity and hygiene of your massager:

- Clean the cushioned head with mild soap and water or a specialized toy cleaner after each use.
- Wipe the body of the massager with a damp cloth.
- Do not submerge the entire unit in water.
- Store in a cool, dry place away from direct sunlight.

## 7. TROUBLESHOOTING

- **Massager turns off automatically:** The device features an automatic 20-minute shut-off for safety and to preserve battery life. Simply power it back on if you wish to continue use.
- **No power/not charging:** Ensure the charging cable is securely connected to both the massager and a working power outlet. Allow sufficient time for charging. If the issue persists, refer to the warranty information.

## 8. PRODUCT SPECIFICATIONS

Specification	Detail
Model Number	VTHV270
Dimensions	12.2 x 2.36 x 1.97 inches
Weight	1.5 Pounds
Battery	1 Lithium Ion battery required
Material	Silicone (head)
Speeds	4 (up to 6,300 RPM)
Patterns	4
Cord Length	6 feet (AC A/C cord)

## 9. WARRANTY INFORMATION

The Magic Wand Rechargeable HV-270 comes with a **1-year manufacturer's warranty**. Please retain your proof of purchase for any warranty claims. For details on warranty coverage and how to make a claim, refer to the documentation included with your product or contact customer support.

## 10. CUSTOMER SUPPORT

If you have any questions, concerns, or require assistance with your Magic Wand Rechargeable HV-270, please contact the manufacturer's customer support. Contact information can typically be found on the product packaging or the official Magic Wand website.