

techno line MA 10410

Technoline MA 10410 Weather Station User Manual

Model: MA 10410

Brand: techno line

1. INTRODUCTION

Thank you for choosing the Technoline MA 10410 Weather Station. This device is designed to provide accurate indoor and outdoor temperature and humidity readings, a reliable radio-controlled clock, and a weather forecast function. Please read this manual carefully before operating the device to ensure proper use and to maximize its performance and lifespan.




Figure 1: Technoline MA 10410 Weather Station main unit and outdoor sensor. The display shows indoor temperature (23.5°C), time (12:34), indoor humidity (48% RH), outdoor temperature (10.3°C), maximum (18.1°C) and minimum (6.4°C) outdoor temperatures, outdoor humidity (52% RH), a weather forecast icon (partly cloudy), and a pressure history graph.

2. SAFETY INFORMATION

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping the device or subjecting it to strong impacts.
- Do not disassemble or attempt to repair the device yourself. Contact qualified service personnel.
- Keep batteries out of reach of children. Dispose of used batteries properly according to local regulations.
- Ensure correct battery polarity when inserting.

3. SETUP

3.1 Package Contents

Before starting, ensure all components are present:

- Technoline MA 10410 Main Display Unit
- Outdoor Sensor
- User Manual (this document)

3.2 Battery Installation

The main unit and outdoor sensor require batteries for operation.

1. **Main Unit:** Open the battery compartment cover on the back of the main display unit. Insert 3 AAA batteries (not included) according to the polarity markings (+/-). Close the cover securely.
2. **Outdoor Sensor:** Open the battery compartment cover on the back of the outdoor sensor. Insert 2 AAA batteries (not included) according to the polarity markings (+/-). Close the cover securely.

Note: It is recommended to insert batteries into the outdoor sensor first, then into the main unit, to ensure proper synchronization.

3.3 Sensor Placement

- Place the outdoor sensor in a shaded, dry location, protected from direct sunlight and rain, to ensure accurate temperature and humidity readings.
- Ensure the outdoor sensor is within the effective transmission range of the main unit (typically up to 100 meters in open air).
- Avoid placing the sensor near large metal objects or electrical appliances that may interfere with the radio signal.

3.4 Initial Synchronization

After battery installation, the main unit will automatically search for the outdoor sensor and the DCF-77 radio signal for time synchronization.

- The outdoor temperature and humidity should appear on the main unit's display within a few minutes.
- The radio-controlled clock (DCF-77) will attempt to synchronize automatically. This process may take several minutes or hours, depending on signal strength. A signal icon will indicate successful reception.

- If the time does not synchronize automatically, refer to the "Manual Time Setting" section in Operating.

4. OPERATING INSTRUCTIONS

4.1 Display Overview

The LCD display provides various information:

- **Indoor Temperature:** Current temperature inside.
- **Indoor Humidity:** Current humidity inside.
- **Outdoor Temperature:** Current temperature from the outdoor sensor.
- **Outdoor Humidity:** Current humidity from the outdoor sensor.
- **Time and Date:** Radio-controlled time and date.
- **Weather Forecast:** Graphical representation of expected weather conditions.
- **Pressure History:** Barometric pressure trend over time.
- **MAX/MIN Readings:** Maximum and minimum recorded temperatures.

4.2 DCF-77 Radio Controlled Clock

The weather station automatically receives the DCF-77 time signal for accurate timekeeping. The signal icon will flash during reception and remain solid when synchronized.

- **Manual Time Setting:** If the DCF-77 signal is unavailable, you can set the time manually. Refer to the specific buttons on your device (usually "SET" or "MODE") and follow the on-screen prompts to adjust hours, minutes, and date.

4.3 Temperature and Humidity Display

- The indoor and outdoor temperature and humidity are continuously displayed.
- **MAX/MIN Readings:** Press the "MAX/MIN" button (if available) to view the highest and lowest recorded indoor/outdoor temperatures and humidity since the last reset. Press again to cycle through or hold to reset.

4.4 Weather Forecast

The weather station analyzes barometric pressure changes to predict weather conditions for the next 12-24 hours. The forecast is indicated by graphical icons (e.g., sunny, partly cloudy, cloudy, rainy).

Note: The weather forecast is an estimation and may not always be 100% accurate.

4.5 Alarm Function

The device includes an alarm function. Refer to the specific buttons (e.g., "ALARM") and on-screen indicators to set and activate the alarm. The alarm will sound at the set time and can typically be snoozed or turned off.

4.6 LCD Contrast Regulation

To adjust the display's readability, especially when viewed from different angles, use the LCD contrast regulation feature. This is usually controlled by a dedicated button or a combination of buttons (refer to your device's physical controls).

5. MAINTENANCE

- **Cleaning:** Clean the display unit and sensor with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries in both the main unit and outdoor sensor when the low battery indicator appears on the display. Always replace all batteries at the same time with new ones of the same type.
- **Long-Term Storage:** If the device will not be used for an extended period, remove all batteries to prevent leakage.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No outdoor temperature/humidity display.	◦ Batteries in sensor are low or incorrectly inserted. ◦ Sensor is out of range or blocked by interference. ◦ Sensor not synchronized with main unit.	◦ Replace sensor batteries, ensuring correct polarity. ◦ Move sensor closer to the main unit or to a location with less interference. ◦ Re-synchronize by removing and reinserting batteries in both units (sensor first).
Time not synchronizing (DCF-77).	◦ Weak DCF-77 signal due to location or interference. ◦ Manual time setting required.	◦ Move the main unit to a window or a location with better signal reception. ◦ Perform a manual time setting as described in section 4.2.
Inaccurate temperature/humidity readings.	◦ Sensor exposed to direct sunlight or heat sources. ◦ Sensor placed in a location with poor air circulation.	◦ Relocate the outdoor sensor to a shaded, well-ventilated area. ◦ Ensure the indoor unit is not near heat-emitting appliances.

7. SPECIFICATIONS

Feature	Detail
Model	MA 10410
Brand	techno line
Power Source	Battery Powered (Main Unit: 3 AAA, Sensor: 2 AAA)
Connectivity Technology	Radio Frequency (RF)
Display Type	LCD
Material	Plastic
Color	White
Temperature Accuracy	1 °C

Feature	Detail
Product Dimensions (Main Unit)	8.27 x 2.64 x 7.28 inches
Item Weight	10.4 ounces (0.3 Kilograms)
Special Features	DCF-77 Radio Controlled Clock, Indoor/Outdoor Temperature, Indoor/Outdoor Humidity, Weather Forecast, Alarm, LCD Contrast Regulation

8. WARRANTY AND SUPPORT

8.1 Warranty Information


The Technoline MA 10410 Weather Station typically comes with a manufacturer's warranty. Please refer to the warranty card included with your product or contact the retailer for specific warranty terms and conditions. Keep your purchase receipt as proof of purchase.



8.2 Customer Support

For technical assistance, troubleshooting not covered in this manual, or warranty claims, please contact your retailer or the manufacturer's customer support. Contact information can usually be found on the product packaging or the manufacturer's official website.


Note: Do not attempt to open or repair the device yourself, as this may void the warranty.

Related Documents - MA 10410

	Gebruiksaanwijzing MA10410 Mobile Alerts Weerstation Uitgebreide gebruikershandleiding voor het MA10410 Mobile Alerts weerstation van Techno Line. Bevat informatie over installatie, functies, bediening, weersvoorspelling, technische specificaties en probleemoplossing.
	Techno Line WT250 Radio Controlled Clock Instruction Manual Instruction manual for the Techno Line WT250 radio-controlled clock, detailing features, setup, manual time setting, alarm setting, and function key operations.

	Hama Black Line Plus Weather Station Operating Instructions Comprehensive operating instructions for the Hama Black Line Plus Weather Station (Model 00 186418), covering setup, features, safety, and technical specifications.
	COMET P3116 Economy Humidity and Temperature Transmitter Instruction Manual Instruction manual for the COMET P3116 transmitter, detailing its specifications for measuring temperature and relative humidity with 4-20 mA current outputs. Covers installation, dimensions, operating conditions, measured values, and technical support.
	Mini-Z AWD MA-020 ASF 2.4GHz Instruction Manual Comprehensive instruction manual for the Mini-Z AWD MA-020 ASF 2.4GHz R/C car, covering assembly, operation, safety precautions, and maintenance. Includes detailed content lists and troubleshooting tips.
	NISSAN Vehicle Maintenance Manual Comprehensive guide to maintaining your NISSAN vehicle, covering engine, chassis, body, fluids, and specifications. Includes periodic maintenance schedules, procedures, and service data for reliable operation.


Documents - techno line – MA 10410



[\[pdf\]](#) User Manual

WIRELESS 868 MHz WEATHER CLOCK pauline Techno line MA 10410 manual ManualsPlanet techno ma manualsplanet manualPdf |||

MA 10410 Betriebsanleitung EINFÜHRUNG: Herzlichen Glückwunsch zum Erwerb dieser modernen Wetterstation, einem Beispiel für hervorragendes Design und feine Handwerkskunst. Die Station bietet Ihnen Zeitanzeige, Anzeige von Datum, Kalender, Raum- und Auentemperatur, Raum- und Auenluftfeuchtigkeit sowie ei...
 lang:de score:29 filesize: 272.01 K page_count: 2 document date: 2018-03-12




[\[pdf\]](#) User Manual

MA10410 Mobile Alerts Manual EN rosch mode demploi 1396671 station meteo radiopilotée numérique techno line mobile alerts ma 10410 asset conrad media10 add 160267 c1 en 001396671ML03

MA 10410 Instruction Manual INTRODUCTION Congratulations on purchasing this weather station as an example of innovative design and quality piece of engineering. Providing time, date, calendar, indoor and outdoor temperature, indoor and outdoor relative humidity, and air pressure history information,...


lang:en **score:27** filesize: 174.59 K page_count: 2 document date: 2015-01-21



[Gebruiksaanwijzing MA10410 Mobile Alerts Weerstation](#)

Uitgebreide gebruikershandleiding voor het MA10410 Mobile Alerts weerstation van Techno Line. Bevat informatie over installatie, functies, bediening, weersvoorspelling, technische specificaties en probleemoplossing.

lang:nl **score:25** filesize: 579.3 K page_count: 2 document date: 2017-02-02




[\[pdf\]](#) User Manual

MA10410 Mobile Alerts Manual DE rosch mode demploi 1396671 station meteo radiopilotée numérique techno line mobile alerts ma 10410 asset conrad media10 add 160267 c1 de 001396671ML02

MA 10410 Betriebsanleitung EINFÜHRUNG: Herzlichen Glückwunsch zum Erwerb dieser modernen Wetterstation, einem Beispiel für hervorragendes Design und feine Handwerkskunst. Die Station bietet Ihnen Zeitanzeige, Anzeige von Datum, Kalender, Raum- und Auentemperatur, Raum- und Auenluftfeuchtigkeit sowie ei...

lang:de **score:25** filesize: 184.49 K page_count: 2 document date: 2015-01-21



[\[pdf\]](#)

Kejciaczek mode demploi 1396671 station meteo radiopilotée numérique techno line mobile alerts ma 10410 asset conrad media10 add 160267 c1 pl 001396671ML06

INSTRUKCJA OBSŁUGI www.conrad.pl Nr produktu 001396671 Stacja pogodowa internetowa Techno Line **MA 10410**, 100 m, - 39.9 do 59.9 C, 20 do 95 Strona 1 z 15 Dystrybucja Conrad Electronic Sp. z o.o., ul. Knianina 12, 31-637 Kraków, Polska Copyright Conrad Electronic 2012, Kopiowanie, rozpowszechni...

lang:pl **score:23** filesize: 531.44 K page_count: 15 document date: 2016-05-12



[\[pdf\]](#)

MA10410 Info DE cdr Sandra Kuhn information 1396671 techno line mobile alerts ma 10410 wireless digital weather station asset conrad media10 add 160267 c1 de 001396671IN01 |||

MOBILE ALERTS Mobile Alerts - **MA 10410** technoline Wetterstation inkl. Außensender TX45TH-IT Y Y DCF-77 Funkuhr mit manueller Einstelloption Y Zeitzoneneinstellung -2/ 5 h Y Datums- und Wochentagsanzeige Y Innen- und Außentemperaturanzeige Y MIN/MAX Speicherung Y Innen- und Außentemperaturanzeige Y ...

lang:de score:21 filesize: 2.81 M page_count: 1 document date: 2015-02-19

[\[pdf\]](#) User Manual

MA10410 Mobile Alerts Manual EN rosch MA 10410 Weather ShopOnly the data for indoor outdoor temperature and humidity are transmitted to The time base radio controlled is a Cesium Atomic usermanual 1396671 techno line mobile alerts ma 10410weathershop co uk amfile file 96 product 3559 srsLtd AfmBOooEo8V 2l cnYU 47TrQTIU dhGhtKYoo6KGA10 65iA0YlctvX ShopMA

Atomic INTRODUCTION Congratulations on purchasing this weather station as an example of innovative design quality piece engineeringusermanual 10410usermanual 65iA0YlctvXweathershop AfmBOoqMTDRYMeil2CZpq4qq4mUm9XttDonG8rlh49xrmDCW4ntg2cj8 engineeringINTRODUCTION AfmBOoqMTDRYMeil2CZpq4qq4mUm9XttDonG8rlh49xrmDCW4ntg2cj8weathershop AfmBOorS5059P5S VwlUj41r EtVaYmJvlnTKlOnhT30b1WaareLhP6g |||

MA 10410 Instruction Manual INTRODUCTION Congratulations on purchasing this weather station as an example of innovative design and quality piece of engineering. Providing time, date, calendar, indoor and outdoor temperature, indoor and outdoor relative humidity, and air pressure history information,...


lang:en score:19 filesize: 174.59 K page_count: 2 document date: 2015-01-21

[\[pdf\]](#) User Manual

Microsoft Word ku1396676 M 341nyi Ivett Techno Line Mobile Alerts MA 10006 digitální bezdrátová meteorostanice Předpověď pro 1 den Conrad cz manual 1396676 techno line mobile alerts ma digitalni bezdratova predpoved asset conrad media10 add 160267 c1 hu 001396676ML01 |||

MA 10006 - kezd kszlet Gateway **MA 10410** Hasznlati tmutat Alkalmazs leltse Tltse le a MOBILE-ALERTS App-ot az „Apple App Store -bl vagy a„Google Play Store bl. A gateway csatlakoztatsa Csatlakoztassa a gatewayt a vele szlltott hlzati adapterrel az elektromos hlzatra. Csatlakoztassa a vele szl...

lang:tl score:19 filesize: 273.69 K page_count: 2 document date: 2019-12-12



[\[pdf\]](#) User Manual

Techno Line Mobile Alerts MA 10006 digitální bezdrátová meteorostanice Předpověď pro 1 den Conrad cz manual 1396676 techno line mobile alerts ma digitalni bezdratova predpoved asset conrad media10 add 160267 c1 fr 001396676ML04 |||

Conrad sur INTERNET www.conrad.fr Le décret relatif aux batteries usages impose au consommateur de d ... Conrad. Imprim en CEE. XXX/03-16/EG NOTICE Version 03/16 Kit de démarrage MA10006 avec station mto **MA 10410** et passerelle. Code : 001396676 Cette notice fait partie du produit. Elle contient des info...


lang:fr **score:18** filesize: 1006.14 K page_count: 8 document date: 2016-03-07

[\[pdf\]](#)

information 1396671 station meteo radiopilotee numerique techno line mobile alerts ma 10410 asset conrad media10 add 160267 c1 de 001396671IN01

...

lang:fr **score:15** filesize: 1 M page_count: 0 document date: 0000-00-00



[\[pdf\]](#)

1396671 Dočekal František mode d'emploi station meteo radiopilotee numerique techno line mobile alerts ma 10410 asset conrad media10 add 160267 c1 cs 001396671ML01

Internetová meteorostanice Mobile Alerts MA10410 1 venkovní senzor Obj. c. 139 66 71 Vžen zákazník, děkujeme Vám za Vaši důvěru a za nákup internetové meteorostanice. Tento návod k obsluze je součástí výrobku. Obsahuje důležité pokyny k uvedení výrobku do provozu a k jeho obsluze. Jestliže výrobek pedte jiným osobám, dbe...


lang:it **score:14** filesize: 319.86 K page_count: 6 document date: 2016-04-05

[\[pdf\]](#)

1396671 Dočekal František Internetová meteorostanice Mobile Alerts návodila za uporabo techno line mobile alerts ma 10410 digitalna brezžična vremenska postaja maksasset conrad media10 add 160267 c1 cs 001396671ML01 navodila maks stevilo senzorjev |||

Internetová meteorostanice Mobile Alerts MA10410 1 venkovní senzor Obj. c. 139 66 71 Vžen zákazník, děkujeme Vám za Vaši důvěru a za nákup internetové meteorostanice. Tento návod k obsluze je součástí výrobku. Obsahuje důležité pokyny k uvedení výrobku do provozu a k jeho obsluze. Jestliže výrobek pedte jiným osobám, dbe...

lang:it **score:12** filesize: 319.86 K page_count: 6 document date: 2016-04-05



[\[pdf\]](#)

használati útmutató 1396674 vezeték nélküli hőmérő és paratartalom mérő techno line wl 2000 asset conrad media10 add 160267 c1 fr 001396674ML04

Conrad sur INTERNET www.conrad.fr Les appareils électriques et électroniques usages DEEE doivent être ... d. Imprim en CEE. XXX/03-16/EG NOTICE Version 03/16 Station de surveillance de la qualité de l'air **MA 10410** Code : 001396674 Cette notice fait partie du produit. Elle contient des informations import...

lang:fr **score:11** filesize: 304.86 K page_count: 4 document date: 2016-03-24