

## **hofstein H165608**

# **Hofstein Biot LED Floor Lamp H165608 User Manual**

Model: H165608

## **1. INTRODUCTION**

---

Thank you for purchasing the Hofstein Biot LED Floor Lamp. This manual provides essential information for the safe assembly, operation, and maintenance of your new lamp. Please read these instructions carefully before use and retain them for future reference.

The Hofstein Biot LED Floor Lamp is a modern lighting solution featuring a main upright and an adjustable reading arm. It is designed for indoor use and offers dimmable functionality for both light sources.

## **2. SAFETY INSTRUCTIONS**

---

- This product is intended for indoor use only. Do not expose to moisture or extreme temperatures.
- Ensure the power supply is disconnected before assembly, cleaning, or maintenance.
- The lamp operates on 230 Volts. Verify your local voltage matches this requirement.
- The integrated LED bulbs are not replaceable. Do not attempt to replace them.
- Keep packaging materials away from children to prevent choking hazards.
- Position the lamp on a stable, level surface to prevent tipping.
- Do not cover the lamp with any materials while in operation, as this may cause overheating.
- If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

## **3. PACKAGE CONTENTS**

---

Carefully unpack all components and check for any damage. If any parts are missing or damaged, contact customer support immediately.

- Hofstein Biot LED Floor Lamp (main body, base, upright, reading arm)

- Integrated LED light sources (18W for upright, 5W for reading light)
- Assembly hardware (if applicable)
- User Manual

## 4. SETUP AND ASSEMBLY

---

Assembly typically requires two persons for ease and safety. Follow these general steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Attach the Base:** Securely attach the lamp pole to the base using the provided hardware. Ensure it is tightened firmly.
3. **Assemble the Pole Sections:** If the lamp pole comes in multiple sections, carefully screw them together, ensuring the electrical wiring passes through freely and is not pinched.
4. **Position the Reading Arm:** The reading arm is adjustable. Position it to your desired angle.
5. **Connect to Power:** Once fully assembled and stable, plug the power cord into a suitable 230V wall outlet. The lamp features a foot switch on the cable for convenient power control.



Figure 1: Fully assembled Hofstein Biot LED Floor Lamp. This image shows the overall design of the lamp, featuring a main upright and an adjustable reading light, both in a brass finish with white glass shades.



Figure 2: Dimensions of the Hofstein Biot LED Floor Lamp. The lamp stands 180 cm tall, with a main shade diameter of 32 cm and a base diameter of 27 cm. The reading arm extends 43 cm with a 12 cm shade diameter.

## 5. OPERATING INSTRUCTIONS

---

The Hofstein Biot LED Floor Lamp features two independent light sources, each with its own dimmer control.

1. **Power On/Off:** Use the foot switch located on the power cable to turn the entire lamp on or off.
2. **Main Uplight Operation:** The main uplight (18W) is controlled by the upper rotary dimmer switch located on the lamp pole. Rotate the switch clockwise to increase brightness and counter-clockwise to decrease brightness.
3. **Reading Light Operation:** The adjustable reading light (5W) is controlled by the lower rotary dimmer switch on the lamp pole. Rotate the switch clockwise to increase brightness and counter-clockwise to decrease brightness.
4. **Adjusting the Reading Arm:** The reading arm is flexible and can be adjusted to direct light precisely where needed.

hofstein®



Figure 3: Close-up of the dimmer controls on the lamp pole. The upper knob controls the 18W main uplight, and the lower knob controls the 5W reading light, allowing independent brightness adjustment.



Figure 4: Illustration of different dimmer levels for the main uplight, ranging from 100% brightness to 0% (off), demonstrating the lamp's dimmable functionality.

hofstein®



Figure 5: Close-up view of the adjustable reading light, highlighting its flexible arm and integrated LED light source.

## 6. MAINTENANCE

---

- **Cleaning:** Disconnect the lamp from the power supply before cleaning. Use a soft, dry cloth to wipe the metal and glass surfaces. Do not use abrasive cleaners or solvents, as these can damage the finish.
- **Bulb Replacement:** The LED light sources are integrated and not designed for user replacement. If a light source fails, the entire fixture may need professional servicing or replacement.
- **Inspection:** Periodically check the power cord and plug for any signs of damage. If damage is found, discontinue use and contact a qualified electrician or the manufacturer.

## 7. TROUBLESHOOTING

---

If you encounter issues with your lamp, refer to the following common problems and solutions:

- **Lamp does not turn on:**
  - Ensure the power cord is securely plugged into a working wall outlet.
  - Check if the foot switch is in the 'on' position.

- Verify that the dimmer switches are not set to minimum (off) position.
  - Test the outlet with another appliance to confirm it has power.
- **Light flickers or is dim:**
    - Adjust the dimmer switch to increase brightness.
    - Ensure the lamp is receiving stable power.
  - **Lamp is unstable:**
    - Ensure the base is fully tightened and placed on a flat, stable surface.

If these steps do not resolve the issue, please contact Hofstein customer support.

## 8. SPECIFICATIONS

Feature	Detail
Brand	hofstein
Model Number	H165608
Type	LED Floor Lamp with Reading Arm
Material	Metal (Brass finish), Glass (White)
Dimensions (Height)	180 cm
Main Uplight Diameter	32 cm
Base Diameter	28 cm
Reading Light Shade Diameter	12 cm
Power Supply	230 Volts
Main Uplight Power	18 Watts (Integrated LED)
Reading Light Power	5 Watts (Integrated LED)
Luminous Flux (Main)	1620 Lumens
Color Temperature	3000 Kelvin (Warm White)
Dimmable	Yes (Independent dimmers)
Switch Type	Foot switch on cable, Rotary dimmers on pole
Protection Rating	IP20 (Protection against solid objects larger than 12.5mm, no protection against water)
Protection Class	II
Energy Label	F (as per 2019/2015 regulation)
Weight	7.3 Kilograms




Figure 6: Energy label for the Hofstein Biot LED Floor Lamp (Model H165608), indicating an energy efficiency class F under the 2019/2015 regulation. For more details, visit the [EPREL database](#).

## 9. WARRANTY AND SUPPORT

Hofstein is committed to customer satisfaction. While specific warranty details are not provided in this manual, please retain your proof of purchase. In case of any issues or questions regarding your Hofstein Biot LED Floor Lamp, please contact the retailer or Hofstein customer service for assistance.

For more information about Hofstein products, you may visit the official Hofstein store: [Hofstein Store](#).