

ASI 04733

User Manual for ASI 04733 Recessed Waste Receptacle

Model: 04733 | Brand: ASI

INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of the ASI 04733 Recessed Waste Receptacle. This traditional 3-gallon waste receptacle features a self-closing door mounted with a stainless steel spring hinge, designed for recessed installation. Please read this manual thoroughly before use to ensure proper function and longevity of your unit.

SAFETY INFORMATION

Always observe the following safety precautions:

- Ensure proper installation by qualified personnel to prevent injury or damage.
- Do not overload the receptacle beyond its stated capacity of 3 gallons.
- Keep hands clear of the self-closing door mechanism during operation.
- Use appropriate personal protective equipment (PPE) during installation and maintenance.
- Dispose of waste materials according to local regulations.

SETUP AND INSTALLATION

The ASI 04733 is designed for recessed wall mounting. Professional installation is recommended.

Required Tools:

- Measuring tape
- Level
- Drill
- Screwdriver
- Appropriate fasteners for wall type

Installation Steps:

1. **Prepare Wall Opening:** Create a rough wall opening according to the product's specified dimensions. Ensure the

opening is plumb and level.

2. **Mounting Frame:** Secure the mounting frame (if separate) into the wall opening using appropriate fasteners. Ensure it is flush with the wall surface.
3. **Insert Receptacle:** Carefully slide the waste receptacle unit into the mounted frame or directly into the prepared wall opening.
4. **Secure Unit:** Fasten the receptacle securely to the wall studs or blocking using screws through the designated mounting holes.
5. **Test Door:** Verify that the self-closing door operates smoothly and returns to its closed position without obstruction.



Image: The ASI 04733 Recessed Waste Receptacle, shown with its self-closing door, designed for seamless integration into a wall opening.

OPERATING INSTRUCTIONS

The ASI 04733 Recessed Waste Receptacle is designed for simple and hygienic waste disposal.

1. **Opening the Door:** Gently push the top of the self-closing door inward to open the waste chute.
2. **Disposing Waste:** Place waste materials into the opening. Ensure items fit within the 3-gallon capacity.
3. **Closing the Door:** Release the door. The stainless steel spring hinge will automatically return the door to its closed position, concealing the waste.
4. **Emptying the Receptacle:** To empty, open the main access panel (if applicable, typically with a key or latch) and remove the internal waste liner or bag. Dispose of contents and replace the liner/bag before closing the access panel.

MAINTENANCE AND CARE

Regular maintenance ensures the longevity and hygienic operation of your waste receptacle.

- **Cleaning:** Clean the exterior surfaces regularly with a soft cloth and a mild, non-abrasive cleaner. For stainless steel, use a cleaner specifically designed for stainless steel to maintain its finish. Avoid harsh chemicals or abrasive pads.
- **Interior Cleaning:** Periodically clean the interior of the receptacle, especially after emptying, to prevent odors and bacterial buildup.
- **Door Mechanism:** Inspect the self-closing spring hinge periodically for smooth operation. If the door becomes stiff or does not close properly, check for obstructions or wear. Do not lubricate the hinge unless specified by the manufacturer.
- **Damage Inspection:** Regularly check for any signs of damage, such as dents, scratches, or loose components. Address any issues promptly to prevent further deterioration.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Door does not close completely.	Obstruction in hinge mechanism or worn spring.	Check for debris around the hinge. If spring is worn, contact customer support for replacement parts.
Unit appears loose in wall.	Mounting screws are loose or wall anchors are failing.	Tighten mounting screws. If necessary, use stronger wall anchors or consult a professional for re-installation.
Unpleasant odors persist.	Infrequent cleaning or improper waste disposal.	Increase cleaning frequency. Ensure waste is properly bagged and disposed of regularly. Use odor neutralizers if needed.

SPECIFICATIONS

Model Number	04733
Brand	ASI
Capacity	3 Gallons
Material	Stainless Steel
Finish Type	Stainless Steel
Color	Silver
Opening Mechanism	Swing-Lid (Self-closing door)
Item Weight	20 Pounds
Recommended Uses	Bathroom accessories
Shape	Square

WARRANTY AND SUPPORT

For warranty information or technical support regarding your ASI 04733 Recessed Waste Receptacle, please contact ASI customer service directly. Keep your purchase receipt as proof of purchase.

Contact Information:

- Visit the official ASI website for contact details.
- Refer to the product packaging for specific customer service phone numbers or email addresses.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question