

[Manuals.plus](#) /

› [TOOLPORT](#) /

› TOOLPORT FLEX Smart 3x2m Party Tent Instruction Manual

TOOLPORT FLEX Smart

TOOLPORT FLEX Smart 3x2m Party Tent Instruction Manual

Model: FLEX Smart | Size: 3x2m

1. INTRODUCTION

Thank you for choosing the TOOLPORT FLEX Smart 3x2m Party Tent. This manual provides essential information for the safe assembly, operation, and maintenance of your new party tent. Please read these instructions carefully before setup and retain them for future reference.



Figure 1: Assembled TOOLPORT 3x2m Party Tent in a garden setting.

2. SAFETY INSTRUCTIONS

Your safety is paramount. Please adhere to the following safety guidelines:

- Ensure proper ground anchoring.
- Consider wind conditions and follow user limits for safe operation.
- Do not use the tent in extreme weather conditions such as heavy winds, snow, or thunderstorms.
- Keep all flame and heat sources away from the tent fabric.
- Always supervise children around the tent.
- Regularly check all connections and anchoring points for stability.



Figure 2: General safety guidelines for tent usage.

3. PACKAGE CONTENTS

Before assembly, verify that all components are present:

- Galvanized steel frame construction
- Roof canopy (PE 450 N, 1 piece)
- Side panels with wind deflectors and windows
- Gable end panels (entrance with zipper door)
- Tensioners (guy ropes)
- Ground pegs/stakes
- Assembly instructions

4. SETUP INSTRUCTIONS

Follow these steps for proper assembly. It is recommended to have at least two people for setup.

1. **Unpack and Sort:** Carefully unpack all components and sort them according to the parts list in the separate assembly instructions. The tubes are numbered for easier identification.
2. **Assemble the Frame:**
 - Connect the galvanized steel tubes (approx. 38mm diameter) using the connectors (approx. 42mm diameter).
 - Secure connections with butterfly screws for strong load resistance.
 - Ensure all connections are tight and secure.



Figure 3: Detail of the bolted frame connection.

3. **Install the Roof Canopy:** Place the single-piece PE roof canopy over the assembled frame. Ensure it is centered and evenly distributed.
4. **Attach Side and Gable Panels:**
 - Attach the side panels and gable end panels to the frame using the provided elastic loops and Velcro fasteners.
 - The side panels feature wind deflectors and windows.
 - The entrance gable has a zipper door for easy access.



Figure 4: Side panel attachment and window design.

5. Secure the Tent:

- Use the ground pegs/stakes and guy ropes to firmly anchor the tent to the ground.
- Ensure all foot plates (approx. 9.5 cm diameter) are securely fastened.



Figure 5: Foot plate anchoring detail.

Setup Video Guide

Your browser does not support the video tag.

Video 1: Visual guide for assembling a party tent, demonstrating frame connection, canopy installation, and anchoring. (Note: Video title mentions 'Devoko', but the assembly process is generally applicable).

5. OPERATING INSTRUCTIONS

The TOOLPORT FLEX Smart Party Tent is designed for temporary outdoor use, ideal for parties and events. Its high-quality PE 450 N canopy is 100% waterproof and UV resistant, providing protection from sun and light rain.

- **Weather Conditions:** While the tent offers protection from sun and rain, it is not designed for strong winds or heavy snowfall. Always monitor weather forecasts and dismantle the tent if adverse conditions are expected.
- **Ventilation:** The side panels can be partially or fully removed to allow for optimal air circulation and temperature regulation.
- **Entry:** The entrance gable features a zipper door for convenient access.



Figure 6: Tent with side panels open, suitable for good weather.



Figure 7: Tent with all side panels closed for full enclosure.

6. MAINTENANCE

Proper maintenance will extend the lifespan of your tent:

- **Cleaning:** Clean the canopy and side panels with mild soap and water. Avoid harsh chemicals or abrasive materials that could damage the fabric.
- **Drying:** Ensure all fabric components are completely dry before packing away to prevent mold and mildew.
- **Storage:** Store the tent in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Frame Inspection:** Periodically inspect the galvanized steel frame for any signs of damage or corrosion. Replace damaged parts as needed.

7. TROUBLESHOOTING

If you encounter issues with your tent, consider the following:

- **Instability:** Ensure all frame connections are securely bolted and the tent is properly anchored to the ground with all pegs and guy ropes. High winds require extra precautions or dismantling.
- **Water Leakage:** Check that the roof canopy is correctly installed and tensioned. The seams are thermo-welded for waterproofing.
- **Difficulty Assembling:** Refer to the numbered tubes and the detailed assembly instructions provided. Ensure you have sufficient help.

8. SPECIFICATIONS

Feature	Detail
Brand	TOOLPORT
Model Number	FLEX Smart
Dimensions (L x W x H)	3m x 2m x 2m (2L x 3l x 2H meters)
Floor Surface	6 square meters
Frame Material	Galvanized Steel (approx. 38mm diameter tubes, 42mm diameter connectors)
Canopy Material	PE 450 N (Polyethylene)
Water Resistance Level	Waterproof
UV Protection	Yes
Item Weight	29400 Grams
Assembly Required	Yes




Figure 8: Tent dimensions diagram.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact TOOLPORT customer service directly. Keep your proof of purchase for any warranty claims.

You can visit the official TOOLPORT store for more information: [TOOLPORT Store](#)