

[Manuals.plus](#) /

› [TOOLPORT](#) /

› TOOLPORT 5x10 m Marquee Party Tent with PVC Tarpaulin Instruction Manual

TOOLPORT 6168

TOOLPORT 5x10 m Marquee Party Tent Instruction Manual

Model: 6168

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your TOOLPORT 5x10 m Marquee Party Tent. Designed for various events and outdoor gatherings, this tent features a robust steel frame and a durable, waterproof PVC tarpaulin. Please read all instructions carefully before setup to ensure safe and correct usage.

The TOOLPORT 5x10 m Marquee Party Tent is suitable for all occasions, including team events, business functions, weddings, birthdays, and other celebrations. It can also serve as temporary shelter, storage space, or protection for items like an outdoor pool.

Safety Warning: Ensure the tent is properly anchored in strong winds and avoid exposure to heat sources like open flames, due to potential fire risk. Please follow the assembly instructions carefully to prevent damage.

SETUP INSTRUCTIONS

Your tent comes ready for easy installation. We include ground stakes, safety ropes, and a detailed manual to guide you through the process. The stable construction is reinforced by bolting the poles and connections, ensuring a secure structure unlike unstable click systems. Secure ground anchoring is achieved with robust ground stakes and guy ropes, all included in the delivery.

For detailed safety information and assembly steps, please refer to the official safety document:

[Safety Information \(PDF\)](#)

Components Overview

- **Steel Frame:** Consists of approximately 38 mm strong steel tubes and connectors with approximately 42 mm diameter. Connections are bolted for stability.
- **Tarpaulins:** Extra strong PVC 700 N, 100% waterproof and UV-resistant. Includes roof, side walls, and

front/back sections.

- **Anchoring Kit:** Ground stakes and safety ropes for secure installation.



Image: Overview of tent components, including frame parts and tarpaulin. This image illustrates the various pieces that make up the tent structure, such as poles, connectors, and the main fabric sections.

Assembly Steps (Summary)

1. Unpack all components and verify against the packing list.
2. Assemble the roof frame structure by connecting the steel tubes and connectors.
3. Attach the roof tarpaulin to the assembled roof frame.
4. Erect the leg poles and secure them to the roof frame.
5. Attach the side walls and front/back sections, ensuring proper closure mechanisms are engaged.
6. Securely anchor the tent to the ground using the provided ground stakes and safety ropes. Ensure all ropes are taut.



Image: Detailed view of a bolted steel frame connection. This image highlights the robust connection points of the tent's steel frame, emphasizing the bolted design for enhanced stability.

OPERATING INSTRUCTIONS

Once assembled, your TOOLPORT Marquee Party Tent is ready for use. The tent provides a spacious and protected area for various activities.

Usage Guidelines

- Ensure all zippers and closures on the side walls are properly secured to protect against weather elements.
- Regularly check the tension of the safety ropes and the security of the ground stakes, especially during changing weather conditions.
- The tent is designed for temporary use. For prolonged periods, consider additional anchoring or professional advice.

Environmental Considerations

- In strong winds or severe weather, it is recommended to dismantle the tent to prevent damage.

- Avoid placing heating appliances or open flames inside or too close to the tent due to fire risk.
- The PVC tarpaulin is UV-resistant, but prolonged exposure to intense sunlight can affect its lifespan.



Image: Interior view of the tent, illustrating the spacious area available for events. This image demonstrates the ample space provided by the marquee, suitable for various gatherings.

MAINTENANCE

Proper maintenance will extend the life of your TOOLPORT Marquee Party Tent.

Cleaning

- Clean the PVC tarpaulin with mild soap and water. Avoid harsh chemicals or abrasive cleaners, as these can damage the material.
- Rinse thoroughly with clean water and allow the tarpaulin to dry completely before storage to prevent mold and mildew.
- Wipe down the steel frame with a damp cloth to remove dirt and debris.

Storage

- Before disassembling and storing, ensure all parts of the tent (tarpaulins, ropes, frame) are clean and completely dry.
- Store the tent in a cool, dry place, away from direct sunlight and extreme temperatures.
- Fold tarpaulins neatly to prevent creases and damage. Store frame components in their original packaging or a protective bag.

TROUBLESHOOTING

This section addresses common issues you might encounter with your party tent.

Common Issues and Solutions

Problem	Possible Cause	Solution
Tent feels unstable or sways	Improper anchoring; loose frame connections; strong winds.	Ensure all ground stakes are fully inserted and safety ropes are taut. Check all frame connections are bolted securely. Dismantle in very strong winds.
Water leakage	Tarpaulin not properly tensioned; small tears; zippers not fully closed.	Ensure tarpaulin is taut to allow water runoff. Inspect for tears and repair if necessary. Close all zippers completely.
Difficulty assembling frame	Incorrect pole orientation; missing parts.	Refer to the detailed assembly manual (PDF). Double-check part numbers and ensure correct orientation. Contact support if parts are missing.

SPECIFICATIONS

- **Brand:** TOOLPORT
- **Model:** 6168
- **Size:** 5x10 m
- **Floor Area/Coverage:** 50 square meters
- **Color:** Blue-White
- **Tarpaulin Material:** PVC (approx. 500 g/m² with 10% weight tolerance), 700 N strength
- **Frame Material:** Alloy Steel / Stainless Steel
- **Pole Diameter:** Approx. 38 mm
- **Connector Diameter:** Approx. 42 mm
- **Wall Thickness (Connectors):** Approx. 1.3 mm
- **Wall Thickness (Poles):** Approx. 1.1 mm
- **Water Resistance Level:** Water-resistant
- **UV Protection:** Yes
- **Item Weight:** 143.01 kg
- **Recommended Uses:** Events, outdoor gatherings
- **Assembly Required:** Yes
- **Country of Origin:** Germany

WARRANTY INFORMATION

Specific warranty details for the TOOLPORT 5x10 m Marquee Party Tent are not provided in this document. For information regarding product warranty, please refer to the documentation included with your purchase or contact the seller directly. Keep your proof of purchase for any warranty claims.

SUPPORT

For further assistance, technical support, or inquiries regarding your TOOLPORT Marquee Party Tent, please contact the manufacturer or seller.

- **Manufacturer:** TOOLPORT
- **Online Store:** Visit the [TOOLPORT Store on Amazon](#)
- **Seller:** TÄLTPARTNER (as per purchase information)

Please have your model number (6168) and purchase details ready when contacting support.