

AXI Swibee 100 cm Nest Swing User Manual

Model: A190.007.07

Brand: AXI

1. PRODUCT OVERVIEW

The AXI Swibee 100 cm Nest Swing is designed for outdoor use, providing a comfortable and fun experience for children. Its robust construction allows for single or multiple users to relax or play. The swing features a durable, water-repellent seat and adjustable ropes for versatile installation.





Image 1.1: The AXI Swibee 100 cm Nest Swing, featuring its black frame and green mesh seat, ready for installation.

Key Features:

- PE mesh seat with water-repellent material for durability and comfort.
- Black braided ropes with black PP rope connections, designed for strength and adjustability.
- Suitable for swing frames between 200 cm and 240 cm in height.
- Rope connections are spaced 660 mm apart for stable hanging.

2. SAFETY INFORMATION

WARNING:

- Maximum user weight: 150 kg (330 lbs). Do not exceed this limit.
- Adult supervision is required at all times when children are using the swing.
- Ensure the swing is installed on a level surface with adequate clearance from obstacles.
- Regularly inspect all components for wear, damage, or loose connections. Discontinue use if any damage is found.
- Do not allow children to stand on the swing or engage in rough play that could lead to falls.
- Ensure proper ground clearance to prevent injuries.

3. ASSEMBLY AND SETUP

The AXI Swibee Nest Swing is supplied unassembled and comes with clear instructions for easy setup. Please follow these steps carefully to ensure safe and correct installation.

Required Tools (Not Included):

- Wrench or pliers (if needed for tightening connections)
- Measuring tape
- Ladder (for reaching swing frame)

Assembly Steps:

1. Unpack all components and verify against the parts list provided in the packaging.
2. Assemble the swing frame (if not already present and suitable). The swing is designed for frames between 200 cm and 240 cm in height.
3. Attach the black braided ropes to the swing seat's connection points. Ensure all connections are secure.
4. Adjust the length of the ropes to achieve the desired swing height. The rope connections are spaced 660 mm apart.
5. Securely attach the swing to your existing swing frame using appropriate swing hangers (not included). Ensure the hangers are rated for the swing's weight and dynamic forces.
6. Before first use, perform a thorough safety check:
 - Verify all connections are tight and secure.
 - Check that the swing hangs level and has sufficient clearance from surrounding objects.
 - Test the swing's stability by applying gentle pressure.




Image 3.1: Technical drawing illustrating the dimensions of the AXI Swibee Nest Swing, including the 980mm diameter and 660mm rope connection spacing.

4. OPERATING INSTRUCTIONS

The AXI Swibee Nest Swing is designed for comfortable and safe play. Follow these guidelines for optimal use:

- **Single User:** A single child can lie down comfortably on the swing for relaxation or gentle swinging.
- **Multiple Users:** The swing can accommodate multiple children, provided the combined weight does not exceed 150 kg. Encourage cooperative play and ensure all users remain seated or lying down.

- **Gentle Swinging:** Encourage gentle, controlled swinging motions. Avoid excessive force or twisting that could strain the ropes or frame.
- **Entry and Exit:** Ensure children enter and exit the swing safely, without jumping on or off.



Image 4.1: A child comfortably lying on the AXI Swibee Nest Swing, demonstrating its spacious design for relaxation.



Image 4.2: Two children sharing the AXI Swibee Nest Swing, highlighting its capacity for multiple users.



Image 4.3: Two children smiling and enjoying their time on the AXI Swibee Nest Swing, showcasing the fun and comfort it provides.

5. MAINTENANCE

Regular maintenance will extend the life of your AXI Swibee Nest Swing and ensure continued safety.

- **Cleaning:** The PE mesh seat and water-repellent fabric can be cleaned with a damp cloth and mild soap. Rinse thoroughly and allow to air dry. Avoid harsh chemicals or abrasive cleaners.
- **Rope Inspection:** Periodically check the ropes for fraying, cuts, or excessive wear. Ensure the rope connections are secure and not showing signs of stress.
- **Frame Inspection:** If the swing is attached to a wooden or metal frame, regularly inspect the frame for rust, cracks, loose bolts, or other damage.
- **Seasonal Care:** During winter months or periods of prolonged non-use, it is recommended to remove the swing and store it indoors in a dry place to protect it from extreme weather conditions.
- **Weight Limit Adherence:** Always ensure the maximum user weight of 150 kg is not exceeded.

6. TROUBLESHOOTING

If you encounter any issues with your AXI Swibee Nest Swing, consider the following common solutions:

- **Swing is not level:** Check the rope lengths and adjust them evenly. Ensure the swing frame itself is level.
- **Excessive squeaking:** Inspect the swing hangers and connections. Lubricate metal-on-metal contact points with a suitable outdoor lubricant if necessary.
- **Ropes showing wear:** If ropes show significant fraying or damage, they should be replaced immediately. Do not attempt to repair damaged ropes.
- **Swing feels unstable:** Re-check all assembly connections and ensure they are tightened securely. Verify the swing frame is stable and properly anchored.

If the problem persists or you suspect a manufacturing defect, please contact AXI customer support.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	100 x 100 x 120 cm (L x W x H)
Item Weight	2 Kilograms
Model Number	A190.007.07
Manufacturer Age Recommendation	3 to 10 months (Note: This seems to be an error in the source data, as the product is a large nest swing. Typically, such swings are for older children. Please refer to product packaging for accurate age guidance.)
Material Composition	Plastic (PE mesh seat), PP (rope connections)
Color	Green (seat) and Black (frame/ropes)
Frame Material	PP (Polypropylene)
Surface Type	Textured (Plastic) and Braided (Rope)
Assembly Required	Yes
Number of Players	From 1
Maximum User Weight	150 kg

8. WARRANTY AND SUPPORT

The AXI Swibee 100 cm Nest Swing comes with a **2-year warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.



Image 8.1: Official 2-Year Warranty badge, signifying the product's coverage against manufacturing defects.

For technical support, warranty claims, or any questions regarding your AXI product, please contact AXI customer service through their official website or the retailer where you purchased the product.

For more information about AXI products, visit the official AXI Store:[AXI Store on Amazon](#)

© 2024 AXI. All rights reserved.