

QANBA Q2 PRO LED

QANBA Q2 PRO LED Arcade Joystick PS3/PC Instruction Manual

Model: Q2 PRO LED | Brand: QANBA

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your QANBA Q2 PRO LED Arcade Joystick. Designed for an authentic arcade experience, this fightstick is compatible with PlayStation 3 (PS3) and PC platforms. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.



Image 1.1: The QANBA Q2 PRO LED Arcade Joystick with its signature blue LED lighting activated.

2. PACKAGE CONTENTS

Verify that all items listed below are present in your package:

- QANBA Q2 PRO LED Arcade Joystick
- USB Connection Cable (integrated or separate)
- Instruction Manual (this document)
- Spare parts (e.g., button caps, joystick restrictor gate -*may vary by region/package*)



Image 2.1: The QANBA Q2 PRO LED Arcade Joystick alongside its product box.

3. FEATURES

The QANBA Q2 PRO LED Arcade Joystick offers several features designed to enhance your gaming experience:

- **LED Illumination:** Buttons and joystick feature vibrant blue LED lighting for visual appeal.
- **Multi-Platform Compatibility:** Seamlessly switch between PlayStation 3 and PC.
- **High-Quality Components:** Equipped with durable arcade-grade joystick and buttons for precise input.
- **Ergonomic Design:** Comfortable layout for extended gaming sessions.

- **Sturdy Construction:** Built to withstand intense gameplay.



Image 3.1: The QANBA Q2 PRO LED Arcade Joystick demonstrating its illuminated buttons and joystick.

4. SETUP

4.1 Connecting to PlayStation 3 (PS3)

1. Ensure your PS3 console is powered off or in standby mode.
2. Locate an available USB port on your PS3 console.
3. Connect the USB cable from the QANBA Q2 PRO LED Arcade Joystick to the USB port on your PS3.
4. Power on your PS3. The console should automatically detect the joystick.
5. The joystick's LEDs will illuminate, indicating a successful connection.

4.2 Connecting to PC

1. Ensure your PC is powered on.
2. Locate an available USB port on your PC.
3. Connect the USB cable from the QANBA Q2 PRO LED Arcade Joystick to the USB port on your PC.
4. Your operating system (e.g., Windows) will typically detect and install the necessary drivers automatically. This may take a few moments.
5. Once drivers are installed, the joystick's LEDs will illuminate.
6. You may need to configure the joystick within your game's control settings or through your operating system's game controller settings.

5. OPERATING INSTRUCTIONS

The QANBA Q2 PRO LED Arcade Joystick features a standard arcade button layout and a responsive joystick for precise control.

5.1 Basic Controls

- **Joystick:** Used for directional input (Up, Down, Left, Right, and diagonals).
- **Action Buttons:** Typically arranged in an 8-button layout, corresponding to game actions (e.g., punch, kick, jump).
- **Start/Select Buttons:** Located on the side or top panel, used for pausing games, navigating menus, etc.
- **PS Button (for PS3):** Functions as the PlayStation button on a standard controller.



Image 5.1: A detailed view of the joystick and action buttons with their blue LED illumination.

5.2 LED Functionality

The blue LEDs on the joystick and buttons will automatically illuminate when the device is powered on and connected to a compatible system (PS3 or PC). There are no user-configurable settings for the LED lighting on this model.

5.3 Mode Switching (PS3/PC)

The QANBA Q2 PRO LED Arcade Joystick automatically detects the connected platform (PS3 or PC). No manual mode switching is required. Ensure the joystick is connected to the correct platform's USB port.

6. MAINTENANCE

Proper maintenance ensures the longevity and performance of your arcade joystick.

- **Cleaning:** Use a soft, dry cloth to wipe down the surface of the joystick. For stubborn marks, a slightly damp cloth with mild soap can be used, followed by immediate drying. Avoid abrasive cleaners or solvents.
- **Storage:** Store the joystick in a cool, dry place away from direct sunlight and extreme temperatures. Protect it from dust when not in use.
- **Cable Care:** Avoid sharp bends or kinks in the USB cable. Do not pull the cable forcefully when disconnecting.

7. TROUBLESHOOTING

If you encounter issues with your QANBA Q2 PRO LED Arcade Joystick, refer to the following common solutions:

Problem	Possible Solution
Joystick not recognized by PS3/PC.	<ul style="list-style-type: none">◦ Ensure the USB cable is securely connected to both the joystick and the console/PC.◦ Try a different USB port.◦ Restart your console/PC.◦ On PC, check Device Manager for driver status.
Buttons or joystick not responding.	<ul style="list-style-type: none">◦ Verify the joystick is properly recognized (LEDs are on).◦ Test in a different game or application.◦ Ensure game control settings are configured correctly for the joystick.
LEDs are not illuminating.	<ul style="list-style-type: none">◦ Confirm the joystick is powered on and connected to a host device.◦ Check USB connection.

8. SPECIFICATIONS

- **Model:** Q2 PRO LED
- **Compatibility:** PlayStation 3 (PS3), PC
- **Connectivity:** USB
- **Input:** 8-way joystick, 8 action buttons, Start/Select/PS buttons
- **Lighting:** Blue LED illumination for joystick and buttons
- **Dimensions & Weight:** Refer to product packaging for specific measurements.


9. WARRANTY AND SUPPORT

QANBA products are manufactured to high-quality standards. For information regarding warranty coverage, technical support, or replacement parts, please refer to the warranty card included with your product or visit the official QANBA website. Keep your proof of purchase for warranty claims.

Official QANBA Website: www.qanba.com (Note: This is a placeholder URL, please refer to actual product documentation for correct support links.)

© 2023 QANBA. All rights reserved.

Related Documents - Q2 PRO LED

	<p>Qanba Drone 2 Arcade Joystick Instruction Manual</p> <p>Instruction manual for the Qanba Drone 2 Arcade Joystick, covering operating instructions, mode switch, turbo button functionality, mute button features, specifications, safety warnings, and compliance information.</p>
	<p>Qanba Gravity KT Arcade Button Instruction Manual</p> <p>Comprehensive guide for the Qanba Gravity KT Arcade Button, detailing its specifications, installation, usage, and maintenance. Features adjustable gravity for personalized gaming experiences.</p>
	<p>Qanba Titan Arcade Joystick (B1) Instruction Manual</p> <p>Instruction manual for the Qanba Titan Arcade Joystick (Model B1), detailing features, operation, specifications, and safety warnings. Includes multilingual support for English, French, Spanish, German, and Italian.</p>
	<p>Qanba Titan Arcade Joystick Instruction Manual</p> <p>Comprehensive instruction manual for the Qanba Titan Arcade Joystick (Model: B1), detailing its features, operating instructions, and safety guidelines.</p>
	<p>Qanba Obsidian 2 Arcade Joystick Instruction Manual</p> <p>Comprehensive instruction manual for the Qanba Obsidian 2 Arcade Joystick (Model: Q7), detailing operating instructions, features, specifications, and safety warnings for PlayStation 5/4 and PC use.</p>
	<p>Qanba Drone 2 Arcade Joystick Instruction Manual</p> <p>Instruction manual for the Qanba Drone 2 Arcade Joystick, covering operating instructions, mode switch, turbo button functionality, mute button features, specifications, safety warnings, and compliance information.</p>

