Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tecnolite CTL-8215/CR

Tecnolite CTL-8215/CR Pendant Lamp User Manual

Model: CTL-8215/CR | Brand: Tecnolite

1. Introduction

This manual provides essential instructions for the safe installation, operation, and maintenance of your Tecnolite CTL-8215/CR Pendant Lamp. Please read this manual thoroughly before installation and retain it for future reference.
The Tecnolite CTL-8215/CR is a modern, chrome-finished pendant lamp designed for indoor use, featuring an E27 base for compatible light bulbs.

2. Safety Information

- **Electrical Safety:** Installation must be performed by a qualified electrician or competent person in accordance with local electrical codes. Always disconnect power at the circuit breaker before installation, maintenance, or bulb replacement.
- **Indoor Use Only:** This lamp is designed for indoor use only. Do not expose to moisture or outdoor elements.
- **Bulb Compatibility:** Use only E27 base LED A19 bulbs as suggested. Ensure the bulb's wattage does not exceed the lamp's maximum rating (not explicitly stated, but good practice).
- **Handling:** Handle the lamp with care to avoid damage to the finish or electrical components.
- **IP Rating:** The lamp has an IP44 rating, meaning it is protected against solid objects larger than 1mm and splashing water from any direction. However, it is still recommended for indoor use and not direct water exposure.

3. Package Contents

Verify that all components are present before beginning installation:

- 1x Tecnolite CTL-8215/CR Pendant Lamp fixture
- 1x Instruction Manual
- Mounting hardware (typically included, though not explicitly listed as separate item)

Note: Light bulb is not included and must be purchased separately.

4. Setup and Installation

Follow these steps for proper installation of your pendant lamp. It is recommended to have two people for installation.

4.1 Preparation

1. **Turn off Power:** Locate the circuit breaker controlling the light fixture's power and turn it off. Verify power is off using a voltage tester.
2. **Unpack:** Carefully remove all components from the packaging.
3. **Identify Components:** Familiarize yourself with the lamp fixture, ceiling canopy, and mounting bracket.

4.2 Mounting the Fixture

1. **Attach Mounting Bracket:** Secure the mounting bracket to the ceiling junction box using the provided screws. Ensure it is firmly attached.
2. **Adjust Cable Length:** The pendant lamp features an adjustable cable. Adjust the cable length to your desired height by gently pushing the cable through the mechanism in the ceiling canopy.




Image Description: A diagram illustrating the adjustable cable mechanism of the pendant lamp. One image shows a long cable, and another shows a shorter cable, with an inset detail of the ceiling canopy mechanism that allows for length adjustment without cutting the cable.

3. **Electrical Connections:** Connect the lamp's wires to the household electrical wires according to standard wiring practices (e.g., black to black, white to white, ground to ground). Use wire nuts to secure connections.
4. **Secure Canopy:** Carefully push the ceiling canopy up to the ceiling, covering the junction box and wiring. Secure it in place with the provided screws or locking mechanism.

4.3 Installing the Light Bulb

1. **Insert Bulb:** Screw an E27 base LED A19 bulb (not included) into the lamp socket. Do not overtighten.
2. **Restore Power:** Once installation is complete and all connections are secure, restore power at the circuit breaker.
3. **Test:** Turn on the light switch to test the lamp.



Image Description: The Tecnolite CTL-8215/CR pendant lamp, chrome finish, shown next to its product packaging. The lamp features a dome-shaped shade and a hanging cable.

5. Operating Instructions

The Tecnolite CTL-8215/CR pendant lamp operates via a standard wall switch connected to its electrical circuit. There are no integrated controls on the lamp itself.

- **To Turn On:** Flip the wall switch connected to the lamp to the "ON" position.
- **To Turn Off:** Flip the wall switch connected to the lamp to the "OFF" position.

6. Maintenance

Regular maintenance ensures the longevity and appearance of your pendant lamp.

- **Cleaning:**

- Ensure the lamp is turned off and cool before cleaning.
- Wipe the chrome finish with a soft, dry, or slightly damp cloth.
- Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.

- **Bulb Replacement:**
  - Always turn off power at the circuit breaker before replacing a bulb.
  - Allow the old bulb to cool completely before removing it.
  - Replace with an E27 base LED A19 bulb of appropriate wattage.

7. Troubleshooting

If your pendant lamp is not functioning correctly, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Lamp does not light up.	No power to the fixture. Loose wire connection. Defective light bulb.	Check circuit breaker and wall switch. Turn off power and check wiring connections. Replace the light bulb.
Lamp flickers.	Loose bulb. Incorrect bulb type. Loose wiring.	Tighten the bulb. Ensure an E27 LED A19 bulb is used. Turn off power and check wiring connections.

If troubleshooting steps do not resolve the issue, contact Tecnolite customer support.

8. Specifications

Feature	Detail
Model Number	CTL-8215/CR
Brand	Tecnolite
Color	Chrome
Style	Medium
Finish	Chrome
Material	Chrome
Shape	Oval
Power Source	Corded Electric
Voltage	100-240 Volts (Nominal 127V)
Installation Method	Suspended (Ceiling Mount)
Number of Pieces	1
Bulb Type	LED (E27 Base, A19 suggested)

Feature	Detail
Switch Style	External Wall Switch
Usage	Indoor Use Only
IP Rating	IP44
Product Dimensions (L x W x H)	22.5 x 22.5 x 209 cm
Weight	1.5 Kilograms




Image Description: A diagram illustrating the dimensions of the pendant lamp. It shows the total height of 2090 mm, and the shade width of 225 mm, with a human silhouette for scale.




Image Description: A technical line drawing of the pendant lamp, detailing its dimensions: ceiling plate diameter (121 mm), ceiling plate height (24 mm), shade height (207 mm), shade width (225 mm), and total adjustable height (up to 2090 mm).

9. Warranty and Support

Your Tecnolite CTL-8215/CR Pendant Lamp is covered by a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.

For warranty claims, technical support, or any questions regarding your product, please contact Tecnolite customer service. Refer to the official Tecnolite website or your purchase documentation for contact information.

Online Resources: For additional information and product details, visit the official Tecnolite website:Tecnolite Brand Store



Image Description: A graphic displaying "1 AÑO DE GARANTÍA" (1 YEAR WARRANTY) in bold text, with the number "1" prominently featured.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00V8J0AB6

More documents and user manuals: **https://manuals.plus/**