

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

- › [A|X ARMANI EXCHANGE](#) /
- › A|X Armani Exchange Chronograph Watch User Manual

A|X ARMANI EXCHANGE AX2164

User Manual

A|X ARMANI EXCHANGE CHRONOGRAPH WATCH

Model: AX2164

Introduction

This manual provides essential information for the proper use, care, and maintenance of your A|X Armani Exchange Chronograph Watch, Model AX2164. Designed with an urban lifestyle in mind, this timepiece combines sophisticated style with reliable functionality. Please read this manual thoroughly to ensure optimal performance and longevity of your watch.



Figure 1: Front view of the AIX Armani Exchange Chronograph Watch (Model AX2164) featuring a black dial with gold accents and a black stainless steel bracelet.

Key Features

- **Chronograph Movement:** Features a black brushed, textured dial with chronograph functionality for precise time measurement.
- **Durable Construction:** 46mm case with a scratch-resistant mineral crystal.
- **Accurate Timekeeping:** Equipped with accurate quartz movement and an analog display.
- **Comfortable Band:** Black stainless steel bracelet designed for a customized fit by removing links.
- **Water Resistance:** Water resistant up to 50 meters (165 feet), suitable for swimming in shallow water (5 ATM).

Setup and Initial Use

1. Setting the Time and Date

1. **Pull the Crown:** Gently pull the crown (the knob on the side of the watch) out to the first or second click position. The second click position is typically for setting the time, and the first click for the date (if applicable).
2. **Adjust Time/Date:** Rotate the crown to set the hour, minute, and date. For time, ensure AM/PM is correctly set if your watch has a date function that changes at midnight.
3. **Push the Crown Back:** Once set, push the crown back into its normal position to start the watch movement.

2. Adjusting the Bracelet

The stainless steel bracelet is designed for a comfortable fit. If the bracelet is too loose or too tight, links can be added or removed. It is highly recommended to have this adjustment performed by a professional jeweler or watch repair service to prevent damage to the watch or bracelet.



Figure 2: The watch comfortably fitted on a wrist, highlighting its sleek design.

Operating the Chronograph

Your A|X Armani Exchange watch features a chronograph function, allowing you to measure elapsed time. The chronograph typically consists of three sub-dials and two pushers (buttons) located on either side of the crown.

1. **Start:** Press the top pusher to start the chronograph. The chronograph second hand will begin to move.
2. **Stop/Pause:** Press the top pusher again to stop or pause the chronograph. The elapsed time will be displayed on the sub-dials.
3. **Reset:** While the chronograph is stopped, press the bottom pusher to reset all chronograph hands back to their zero positions.







Figure 3: Side view illustrating the crown and chronograph pushers.

Water Resistance

This watch is water resistant up to 50 meters (5 ATM). This means it is suitable for short periods of recreational swimming in shallow water. It is **not** suitable for diving, snorkeling, or high-impact water sports. Avoid operating the crown or pushers when the watch is wet or submerged, as this can compromise the water resistance.

Maintenance and Care

- **Cleaning:** Regularly wipe your watch with a soft, dry cloth to remove dust, dirt, and moisture. For the stainless steel bracelet, a slightly damp cloth can be used, followed by immediate drying.
- **Avoid Chemicals:** Do not expose your watch to harsh chemicals, solvents, or detergents, as these can damage the case, crystal, or strap.
- **Temperature Extremes:** Avoid exposing the watch to extreme temperatures (hot or cold) or sudden temperature changes, which can affect its accuracy and water resistance.
- **Battery Replacement:** The watch uses 1 Lithium Metal battery. When the battery runs low, the watch may stop or the second hand may jump. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and functionality.
- **Storage:** When not in use, store your watch in a cool, dry place, preferably in its original box or a watch case, to protect it from dust and scratches.



Figure 4: Store your watch in its original packaging for protection.

Troubleshooting

Problem	Possible Cause	Solution
Watch not running	Crown is pulled out; Battery is depleted.	Push the crown back in completely. Replace battery (professional service recommended).
Time is inaccurate	Time not set correctly; Exposure to strong magnetic fields; Low battery.	Reset the time. Keep watch away from strong magnets. Replace battery.
Condensation under crystal	Exposure to extreme temperature changes; Compromised water resistance.	Seek professional service immediately to prevent internal damage.

Specifications

Feature	Detail
Model Number	AX2164

Feature	Detail
Product Dimensions	3.39 x 4.25 x 3.7 inches; 8.78 ounces
Case Diameter	46mm
Band Width	22mm
Movement	Quartz Chronograph
Crystal Material	Mineral
Band Material	Stainless-steel
Water Resistance	50m (165ft); 5 ATM
Battery Type	1 Lithium Metal battery (included)
Country of Origin	China

Official Product Videos

Armani Exchange AX Men's Stainless Steel Quartz Dress Watch

Your browser does not support the video tag.

This video provides a 360-degree view of the Armani Exchange AX Men's Stainless Steel Quartz Dress Watch, showcasing its design and features from various angles.

Armani Exchange Men's AX2164 Black Watch

Your browser does not support the video tag.

This video offers a brief overview of the Armani Exchange Men's AX2164 Black Watch, highlighting its aesthetic appeal and key design elements.

Warranty and Support

For information regarding warranty coverage, repairs, or technical support, please refer to the warranty card included with your purchase or visit the official A|X Armani Exchange website. You may also contact the seller directly for assistance.

Always ensure that any repairs or battery replacements are carried out by authorized service centers to maintain the validity of your warranty and the integrity of your watch.