

## WENKO 21676100

# Wenko 21676100 Toilet Brush Set Instruction Manual

Model: 21676100

## INTRODUCTION

---

This manual provides essential information for the proper setup, operation, and maintenance of your Wenko 21676100 Toilet Brush Set. Please read these instructions carefully before use to ensure safe and effective product handling.

## SAFETY INFORMATION

---

- Keep out of reach of children and pets.
- Use only for its intended purpose: cleaning toilet bowls.
- Do not use abrasive cleaners or harsh chemicals on the ceramic holder, as this may damage the finish.
- Handle the ceramic holder with care to prevent breakage.

## PACKAGE CONTENTS

---

Verify that all components are present in the package:

- 1 x Ceramic Toilet Brush Holder (White/Bahia Blue)
- 1 x Toilet Brush with exchangeable bristles (Black)





Image: Wenko 21676100 Toilet Brush Set. This image displays the complete toilet brush set, featuring the white ceramic holder with a blue band and the black-bristled toilet brush with a metallic handle.

## SETUP

- Unpack Components:** Carefully remove all items from the packaging.
- Inspect for Damage:** Check the ceramic holder and brush for any signs of damage during transit. If damaged, contact customer support.
- Assemble Brush (if necessary):** The toilet brush typically comes pre-assembled. If the brush head is separate from the handle, screw the brush head firmly onto the handle.
- Placement:** Place the ceramic holder on a flat, stable surface near the toilet. Ensure it is not easily knocked over.
- Insert Brush:** Place the assembled toilet brush into the ceramic holder.

## OPERATING INSTRUCTIONS

- Remove Brush:** Lift the toilet brush from its ceramic holder.
- Clean Toilet Bowl:** Use the brush to clean the interior surfaces of the toilet bowl.
- Rinse Brush:** After cleaning, rinse the brush thoroughly in the toilet bowl by flushing while holding the brush in the water stream.
- Return to Holder:** Allow excess water to drip off the brush before returning it to the ceramic holder. The open design of the holder allows for air circulation.

## MAINTENANCE AND CARE

- Cleaning the Holder:** Regularly clean the ceramic holder with a mild soap and water solution. Wipe dry with a soft cloth. Avoid abrasive sponges or cleaners.
- Cleaning the Brush:** The brush head can be cleaned with a disinfectant spray or by soaking in a mild bleach solution (follow bleach product instructions for dilution and safety). Rinse thoroughly after cleaning.
- Brush Head Replacement:** The brush features exchangeable bristles. When the bristles become worn or damaged, unscrew the old brush head and replace it with a new one (replacement brush heads sold separately).
- Storage:** Store the toilet brush set in a dry environment.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Brush bristles are worn.	Normal wear and tear from use.	Replace the brush head.
Ceramic holder appears dirty or stained.	Accumulation of dust or water spots.	Clean with mild soap and water, then dry thoroughly.

Problem	Possible Cause	Solution
Brush does not sit securely in holder.	Incorrect placement or damaged holder.	Ensure the brush is inserted correctly. Inspect holder for damage.

## SPECIFICATIONS

- **Model:** 21676100
- **Brand:** WENKO
- **Material:** High-quality Ceramic (Holder), Plastic/Metal (Brush)
- **Color:** White / Bahia Blue
- **Dimensions (W x D x H):** Approximately 11.2 cm x 11.2 cm x 40 cm (4.33 x 4.33 x 15.75 inches)
- **Item Weight:** Approximately 0.59 kg (1.3 lbs)




Image: Dimensions of Wenko 21676100 Toilet Brush Set. This image illustrates the approximate height of the toilet brush set, indicating it is about 16 inches or 41 cm tall.

## SUPPORT

For further assistance, replacement parts, or warranty inquiries, please contact Wenko customer support. Refer to the product packaging or the official Wenko website for contact details.

**Website:** [www.wenko.com](http://www.wenko.com)