#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- OttLite /
- > OttLite 48500C Rechargeable LED Travel Light User Manual

#### OttLite 48500C

# OttLite 48500C Rechargeable LED Travel Light User Manual

Model: 48500C

#### 1. INTRODUCTION

Thank you for choosing the OttLite 48500C Rechargeable LED Travel Light. This manual provides essential information for the safe and efficient operation, setup, and maintenance of your new light. Please read these instructions thoroughly before use and retain them for future reference.

## 2. PRODUCT FEATURES

- Super bright natural daylight LEDs with two brightness settings.
- Rechargeable design, includes USB cable and AC adapter.
- Integrated LCD display featuring date, time, temperature, and a snooze alarm.
- · Versatile use on any tabletop or with the included wall mount.
- Folds flat for enhanced portability.

#### 3. PACKAGE CONTENTS

Verify that all items are present in your package:

- OttLite 48500C Rechargeable LED Travel Light
- USB Charging Cable
- AC/DC Power Adapter
- · Wall Mount Bracket

## 4. SETUP

## 4.1 Initial Charging

Before first use, fully charge the light. Connect the USB charging cable to the light's charging port and the other end to the provided AC/DC power adapter. Plug the adapter into a standard electrical outlet. The charging indicator will illuminate. A full charge typically takes several hours.

## 4.2 Setting Up the LCD Display

The LCD display features time, date, temperature, and alarm functions. Refer to the small buttons located on the back or side of the display unit for setting adjustments. Typically, there are buttons for MODE, SET, UP, and DOWN. Press MODE to cycle through settings (Time, Date, Alarm) and use SET to confirm, then UP/DOWN to adjust values.

## **4.3 Placement Options**

The OttLite 48500C can be used in two primary configurations:

- **Tabletop Use:** Unfold the light to your desired angle and place it on a stable, flat surface.
- Wall Mount: Use the included wall mount bracket to secure the light to a wall. Ensure the wall mount is securely fastened before attaching the light.



Figure 1: OttLite 48500C in open, tabletop configuration.



Figure 2: OttLite 48500C mounted on a wall.

## 5. OPERATING INSTRUCTIONS

## 5.1 Powering On/Off and Brightness Adjustment

Locate the power button, typically on the base or side of the light. Press the power button once to turn the light on to the first brightness setting. Press it again to switch to the second, brighter setting. Press a third time to turn the light off.

## **5.2 Using the LCD Display Functions**

- **Time/Date:** Use the MODE button to select time or date display. Use SET to enter adjustment mode, then UP/DOWN to change values.
- **Temperature:** The display shows ambient temperature. Some models allow switching between Celsius and Fahrenheit using a dedicated button or a combination of SET and UP/DOWN.

• Alarm/Snooze: To set an alarm, select the alarm mode using MODE, then use SET and UP/DOWN to set the desired alarm time. The snooze function is typically activated by pressing a specific button when the alarm sounds.

## 6. MAINTENANCE

#### 6.1 Cleaning

Ensure the light is turned off and unplugged before cleaning. Use a soft, dry cloth to wipe down the exterior surfaces. For stubborn marks, a slightly damp cloth can be used, followed by a dry cloth. Avoid abrasive cleaners or solvents, as these can damage the finish or electronic components.

## **6.2 Battery Care**

The OttLite 48500C uses a rechargeable Lithium Ion battery. To prolong battery life, avoid fully discharging the battery frequently. Recharge the light when the brightness noticeably diminishes. If storing the light for an extended period, ensure it is partially charged (around 50%) and recharge it every few months to prevent deep discharge.

## 7. TROUBLESHOOTING

- **Light does not turn on:** Ensure the unit is charged. Connect it to the AC adapter and allow it to charge for at least 30 minutes before attempting to turn it on again.
- Light dims unexpectedly: This indicates a low battery. Recharge the unit.
- LCD display is blank or incorrect: Check if the unit has power. If the time/date is incorrect, reset it using the instructions in Section 4.2.
- Charging issue (light not charging): Verify that the USB cable and AC adapter are securely connected to both the light and the power outlet. Try a different USB port or outlet if available.

If problems persist, please refer to the warranty and support information in Section 9.

## 8. SPECIFICATIONS



Figure 3: OttLite 48500C dimensions.

Feature	Detail
Brand	OttLite
Model Number	48500C

Feature	Detail
Product Dimensions (Folded)	1.3"D x 7.25"W x 14.25"H
Item Weight	0.73 Pounds (approx. 11.7 ounces)
Lamp Type	Travel Light
Shade Color	White
Light Source Type	LED
Power Source	Battery Powered (Rechargeable)
Battery Type	Lithium Ion
Number of Light Sources	1 (LED Panel)
Mounting Type	Tabletop, Wall Mount
Wattage	6 watts
Voltage	120 Volts (via AC adapter)
UPC	761712009896
Manufacturer	OttLite Technologies

## 9. WARRANTY AND SUPPORT

## 9.1 Warranty Information

OttLite bulbs are covered for 1 year from the date of purchase. OttLite lamps and accessories (excluding batteries) are covered for 2 years from the date of purchase. This warranty does not cover damages resulting from the use of the product for any purpose other than its intended use. Warranty coverage also excludes OttLite items purchased "as is" or from unauthorized retailers.

## 9.2 Customer Support

For technical assistance, warranty claims, or further inquiries, please contact OttLite Technologies customer support. Refer to the official OttLite website or product packaging for the most current contact information.

#### **Related Documents - 48500C**



## OttLite Rechargeable LED Travel Light User Manual and Specifications

Comprehensive guide for the OttLite Rechargeable LED Travel Light, including setup, operation, safety instructions, FCC compliance, and specifications. Features include dimmable LED, calendar, alarm, and temperature display.

