

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Voltas](#) /
- › [Voltas 125 CYE Classic YE Series Split AC User Manual](#)

Voltas 125 CYe

Voltas 125 CYE Classic YE Series Split AC User Manual

Model: 125 CYe

[Introduction](#) [Safety Information](#) [Included Components](#) [Setup](#) [Operating Instructions](#) [Maintenance](#)
[Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Voltas 125 CYE Classic YE Series Split Air Conditioner. Please read this manual thoroughly before using the appliance and retain it for future reference.

The Voltas 125 CYE is a 1-ton, 3-star rated non-inverter split AC designed for effective cooling. Key features include a copper condenser for efficient heat transfer, an anti-bacterial filter for improved air quality, and a dehumidifier function. It also incorporates a Turbo Cool mode for rapid cooling, an Auto Restart function for convenience after power outages, and a Sleep mode for energy-efficient comfort during the night.



An image showing the indoor unit of the Voltas 125 CYE Classic YE Series Split Air Conditioner, typically mounted on a wall.

2. SAFETY INFORMATION

Always adhere to the following safety precautions to prevent injury or damage to the appliance.

- **Professional Installation:** Installation and servicing must be performed by qualified personnel. Improper installation can lead to electric shock, fire, or water leakage.
- **Electrical Safety:** Ensure the power supply matches the unit's requirements. Do not use damaged power cords or plugs. Never operate the AC with wet hands.
- **Ventilation:** Do not block the air inlet or outlet of either the indoor or outdoor unit.
- **Cleaning:** Disconnect power before cleaning. Use a soft, dry cloth for cleaning. Do not use water directly on the unit.
- **Children and Pets:** Keep children and pets away from the unit, especially during operation and maintenance.
- **Flammable Materials:** Do not place flammable materials or spray aerosols near the air conditioner.
- **Leakage:** If you notice any unusual smells, sounds, or smoke, immediately turn off the unit and disconnect the power supply. Contact customer support.

3. INCLUDED COMPONENTS

Your Voltas 125 CYE Classic YE Series Split AC package typically includes the following items:

- Indoor Unit
- Outdoor Unit
- Remote Control
- User Manual (this document)
- Installation Kit (pipes, wires, etc. - typically provided by installer)

4. SETUP AND INSTALLATION

Installation of the Voltas 125 CYE Split AC requires specialized tools and knowledge. It is strongly recommended to arrange for professional installation by authorized Voltas service personnel.

4.1 Site Selection

- **Indoor Unit:** Choose a location that allows for even air distribution throughout the room, away from direct sunlight or heat sources. Ensure there is sufficient space around the unit for maintenance and air circulation.
- **Outdoor Unit:** Select a well-ventilated area, free from obstructions, and where the noise will not disturb neighbors. Ensure it is placed on a stable surface and protected from direct rain and sunlight if possible.

4.2 Electrical Connection

Ensure the electrical wiring meets local regulations and the specifications of the air conditioner. A dedicated power circuit is often required. The power supply should be stable and correctly grounded.

4.3 Drainage

The indoor unit produces condensate water during operation. Ensure the drainage pipe is properly installed with a downward slope to allow for efficient water removal and prevent leakage.

5. OPERATING INSTRUCTIONS

Your Voltas AC is controlled via a remote control. Familiarize yourself with its functions for optimal comfort.

5.1 Remote Control Functions

- **Power Button:** Turns the unit ON or OFF.
- **Mode Button:** Cycles through operating modes: Cool, Fan, Dry.
- **Temperature Buttons (▲/▼):** Adjusts the desired temperature.
- **Fan Speed Button:** Selects fan speed (Low, Medium, High, Auto).
- **Swing Button:** Controls the vertical louver movement for air direction.
- **Timer Button:** Sets the ON/OFF timer for automatic operation.
- **Sleep Button:** Activates Sleep mode for comfortable night-time operation.
- **Turbo Button:** Initiates rapid cooling for quick temperature reduction.

5.2 Operating Modes

- **Cool Mode:** Provides cooling by lowering the room temperature to the set level.
- **Fan Mode:** Circulates air without cooling, useful for ventilation.
- **Dry Mode (Dehumidifier):** Reduces humidity in the room without significant temperature drop.

5.3 Special Features

- **Turbo Cool:** When activated, the unit operates at maximum fan speed and cooling capacity to quickly reach the desired temperature.
- **Sleep Mode:** Automatically adjusts the room temperature gradually over several hours to maintain comfort and save energy during sleep.
- **Auto Restart:** In case of a power outage, the unit will automatically restart with the previous settings once power is restored.

6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your air conditioner. Always disconnect power before performing any maintenance.

6.1 Air Filter Cleaning

The anti-bacterial air filters should be cleaned regularly, typically every two weeks or more frequently depending on usage and air quality.

1. Open the front panel of the indoor unit.
2. Carefully remove the air filters.
3. Clean the filters using a vacuum cleaner or wash them with lukewarm water and a mild detergent.
4. Rinse thoroughly and allow them to dry completely in a shaded area before re-installing.
5. Close the front panel securely.

6.2 Indoor Unit Cleaning

Wipe the surface of the indoor unit with a soft, dry cloth. For stubborn dirt, use a cloth dampened with a mild detergent solution, then wipe dry. Do not use harsh chemicals or abrasive cleaners.

6.3 Outdoor Unit Maintenance

Ensure the outdoor unit's coils and fins are free from dust, leaves, and other debris. Do not attempt to clean the internal components yourself; contact a qualified technician for professional cleaning and servicing.

7. TROUBLESHOOTING

Before contacting customer support, refer to the following common issues and their potential solutions:

Problem	Possible Cause	Solution
AC does not turn on	No power supply; Remote control batteries depleted; Circuit breaker tripped.	Check power connection; Replace remote batteries; Reset circuit breaker.
Insufficient cooling	Dirty air filters; Blocked outdoor unit; Room too large; Doors/windows open.	Clean air filters; Clear obstructions from outdoor unit; Ensure room is sealed.
Unusual noise	Loose parts; Obstruction in fan; Unit not level.	Check for loose parts; Remove obstructions; Ensure unit is level. If noise persists, contact service.
Water leakage from indoor unit	Blocked drainage pipe; Improper installation.	Check and clear drainage pipe; Contact professional for inspection.

If the problem persists after attempting these solutions, please contact Voltas customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	Voltas
Model Number	125 CYe
Capacity	1 Ton
Energy Rating	3 Star
Cooling Power	3650 Watts
Wattage	1013 Watts
Special Features	Anti Bacterial Filter, Dehumidifier
Noise Level	49 Decibels
Core Material	Copper
Inverter Type	No Inverter
Installation Type	Split System
Voltage	230 Volts

Feature	Detail
Control Method	Remote Control
Item Weight	33570 Grams
Floor Area	110 Square Feet (approx.)

9. WARRANTY & SUPPORT

9.1 Warranty Information

Your Voltas 125 CYE Classic YE Series Split AC comes with the following warranty:

- **1 year comprehensive warranty** on the product.
- **5 years warranty** on the compressor.

Please refer to your warranty card for detailed terms and conditions, including coverage, exclusions, and claim procedures. Keep your purchase receipt as proof of purchase.

9.2 Customer Support

For installation requests, service, or any technical assistance, please contact the Voltas support team:

- **Voltas Customer Care:** 1800-4254-555

When contacting support, please have your product model number (125 CYe) and purchase details ready to facilitate quicker service.