

## GSP YK-FJS\_2011

# Instruction Manual

GSP AC Remote Control Replacement

Model: YK-FJS\_2011

## 1. INTRODUCTION

This manual provides detailed instructions for the proper use and maintenance of your GSP AC Remote Control Replacement, model YK-FJS\_2011. This remote is designed as a direct replacement for various Fujitsu air conditioner models, including AR-RY17, ASU18CL, and AR-RY14. Please read this manual thoroughly before operating the remote control to ensure optimal performance and longevity.

## 2. SAFETY INFORMATION

- Do not expose the remote control to direct sunlight, high temperatures, or high humidity.
- Avoid dropping the remote control or subjecting it to strong impacts.
- Do not mix old and new batteries, or batteries of different types.
- Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- Keep batteries out of reach of children. If swallowed, seek immediate medical attention.

## 3. SETUP: BATTERY INSTALLATION

The remote control requires two (2) AAA batteries for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment. Incorrect polarity can prevent the remote from functioning.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image: Back of the remote control, displaying the battery compartment and instructions for battery type (AAA/R03/LR03x2) and polarity. It also warns against mixing old and new batteries.

## 4. OPERATING INSTRUCTIONS

Familiarize yourself with the buttons and their functions on your GSP AC remote control.



Image: Front view of the GSP AC remote control. The display shows '24°C' and '10:04 AM'. Buttons include 'START/STOP', 'SET TEMP.', 'FAN CONTROL', 'MASTER CONTROL', 'AIR CLEAN', 'COIL DRY', 'SLEEP', 'TIMER', 'SWING', 'CLOCK ADJUST', 'TEST RUN', and 'RESET'.

## 4.1. Basic Operation

- **START/STOP:** Press this button to turn the air conditioner ON or OFF.
- **SET TEMP. (▲/▼):** Use these buttons to adjust the desired temperature. Press ▲ to increase and ▼ to decrease the temperature.
- **MASTER CONTROL:** Cycles through various operating modes such as Auto, Cool, Dry, Fan, and Heat (if supported by your AC unit).
- **FAN CONTROL:** Adjusts the fan speed (e.g., Auto, Low, Medium, High).

## 4.2. Advanced Functions

- **AIR CLEAN:** Activates the air purification function (if available on your AC unit).
- **COIL DRY:** Initiates a coil drying cycle to prevent mold and mildew growth.
- **SLEEP:** Activates the sleep mode, which adjusts temperature and fan speed for comfortable sleep and energy saving.
- **SWING (SET):** Controls the louver swing direction. Press to cycle through swing patterns or set a fixed position.
- **TIMER MODE:** Used to set ON/OFF timers for the air conditioner. Refer to your AC unit's manual for specific timer programming instructions.
- **CLOCK ADJUST:** Allows you to set the current time on the remote control's display.
- **TEST RUN:** For service and diagnostic purposes only. Do not use during normal operation.
- **RESET:** Resets the remote control to its factory default settings. Use a pointed object (like a pen tip) to press this recessed button.

## 5. MAINTENANCE

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the display becomes dim or the remote control's range decreases. Always replace both batteries at the same time.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote not responding	Dead or incorrectly installed batteries. Obstruction between remote and AC unit.	Replace batteries, ensuring correct polarity. Remove any obstructions. Ensure remote is pointed directly at the AC unit's receiver.
Display is dim or blank	Low battery power.	Replace batteries.
AC unit not responding to specific functions	Function not supported by your specific AC model.	Refer to your air conditioner's original manual to confirm supported features.

## 7. SPECIFICATIONS

---

- **Model:** YK-FJS\_2011
- **Brand:** GSP
- **Compatible Devices:** Fujitsu Air Conditioners (AR-RY17, ASU18CL, AR-RY14, etc.)
- **Connectivity Technology:** Infrared
- **Power Source:** 2 x AAA Batteries (not included)
- **Item Weight:** 4.2 ounces
- **Special Feature:** Ergonomic design

## 8. WARRANTY AND SUPPORT

---

This GSP remote control is designed for reliable performance. For any issues or inquiries, please contact your retailer or the manufacturer directly. Please retain your purchase receipt as proof of purchase for warranty claims.

For further assistance, please visit the GSP official website or contact their customer support. (Specific contact details are typically provided by the seller or manufacturer at the time of purchase.)