

BELLISSIMA 11144X

Bellissima Imetec Creativity B9 300 Hair Straightener User Manual

Model: 11144X | Brand: BELLISSIMA

INTRODUCTION

The Bellissima Creativity B9 300 is a hair straightener designed for easy and fast smooth or wavy styling. Its heated plates feature a "silk effect" ceramic coating, ensuring uniform heat distribution for optimal hair protection. The temperature is adjustable from 150°C to 230°C, offering 5 levels to suit various hair types. The Bellissima B9 300 provides impeccable results in a single pass, thanks to its oscillating plates that automatically adapt to the hair section for defined styling. The rapid heating system makes the straightener ready for use in seconds. The key lock and plate locking system make the Bellissima Creativity B9 300 a practical, safe, and easy-to-use tool.

SAFETY INFORMATION

Important Safety Warnings:

- Do not use near water or in damp environments.
- Always switch off and unplug the appliance when not in use.
- Keep out of reach of children.
- Ensure the power cord is not damaged and avoid wrapping it tightly around the appliance.
- Allow the appliance to cool completely before storing.

PRODUCT OVERVIEW

The Bellissima Imetec Creativity B9 300 offers advanced features for versatile hair styling:

- **Versatile Styling:** Achieve smooth or wavy styles in a single pass, suitable for all hair types, especially beneficial for dull and lifeless hair.
- **Temperature Control:** Electronic temperature regulation from 150°C to 230°C, with 5 distinct temperature levels to match your hair's needs.
- **Ceramic Plates:** Features "Silk Effect" ceramic plate coating for homogeneous heat distribution and optimal

hair protection, ensuring smooth gliding.

- **Oscillating Plates:** Plates automatically adapt to the hair section, providing defined results in a single pass.
- **Rounded Design:** Special rounded design facilitates and defines wavy styling with ease.
- **Key Lock Function:** Prevents accidental temperature changes during use for uninterrupted styling.
- **Plate Dimensions:** The heating plates measure 25x100 mm.

CAPELLI LISCI O MOSSI, LUMINOSI E MORBIDI



Image: The Bellissima Imetec Creativity B9 300 hair straightener, showcasing its sleek design and ceramic plates.

RIVESTIMENTO IN CERAMICA

PROTEZIONE DAL CALORE
E PERFETTA SCORREVOLEZZA



Image: A close-up view of the ceramic "Silk Effect" plates, designed for even heat distribution and smooth gliding.

CONTROLLO DELLA TEMPERATURA

5 LIVELLI DA 150°C A 230°C



Image: Detail of the temperature control buttons (+/-) and power button on the straightener handle.

SETUP

1. **Unboxing:** Carefully remove the hair straightener and any accessories from its packaging. Retain the packaging for future storage or transport.
2. **Initial Inspection:** Before first use, inspect the device for any signs of damage. Ensure the power cord is intact and free from cuts or fraying.
3. **Placement:** Place the straightener on a stable, heat-resistant surface, ensuring it is away from water, flammable materials, and any objects that could be damaged by heat.
4. **Power Connection:** Plug the power cord into a standard electrical outlet. Verify that the voltage of your outlet matches the requirements specified on the appliance.

OPERATING INSTRUCTIONS

1. **Hair Preparation:** Ensure your hair is clean, completely dry, and thoroughly detangled before using the straightener. For best results and protection, apply a heat protectant spray.
2. **Power On:** Press and hold the power button (usually marked with a power symbol) until the device turns on and the indicator light illuminates.
3. **Temperature Selection:** Use the '+' and '-' buttons to select your desired temperature. The digital display or indicator lights will show the chosen setting.

Recommended Temperature Settings:

- **150°C - 170°C:** For fine, delicate, or chemically treated hair.
- **180°C - 200°C:** For normal, healthy hair.
- **210°C - 230°C:** For thick, coarse, or very curly hair.

4. **Heating:** The straightener will heat up rapidly. The indicator light will stop flashing or change color (depending on the model) once the selected temperature is reached, indicating it is ready for use.

5. **Styling - Straightening:**

- Divide your hair into small, manageable sections (approximately 2-3 cm wide).
- Take one section and place it between the heated plates, close to the roots.
- Gently close the plates and glide the straightener slowly and evenly down the hair section, from root to tip. Avoid stopping in one place to prevent heat damage.
- Repeat for all sections until desired straightness is achieved.

6. **Styling - Wavy/Curled:**

- Divide your hair into small sections.
- Place a section between the plates, close to the roots.
- Rotate the straightener 180 degrees away from your face (or towards, for different curl directions).
- Slowly pull the straightener down the hair section, maintaining the rotation. The rounded design helps create smooth waves.
- Release the hair and allow the curl to cool before touching or styling further to set the wave.

7. **Key Lock Function:** To prevent accidental temperature changes during styling, press and hold the lock button (if available, often indicated by a lock icon) until it activates. Repeat the action to unlock.

8. **Power Off:** After completing your styling, press and hold the power button until the device turns off. Unplug the straightener from the electrical outlet.

9. **Cool Down:** Allow the straightener to cool completely on a heat-resistant surface before handling or storing.



Image: Demonstrates the versatility of the straightener, showing both smooth and wavy hair styling results.



Image: The Bellissima hair straightener being used on a section of hair, illustrating the styling process.

MAINTENANCE

1. **Cleaning:** Always ensure the straightener is unplugged and completely cool before cleaning. Wipe the ceramic plates and the exterior of the appliance with a soft, damp cloth. Do not use abrasive cleaners, harsh chemicals, or solvents, as these can damage the surfaces.
2. **Storage:** Once the straightener has cooled down, store it in a safe, dry place, away from moisture and direct sunlight. Utilize the plate locking system to keep the plates closed, which protects them and allows for more compact storage. Avoid wrapping the power cord tightly around the appliance, as this can cause damage over time.

TROUBLESHOOTING

If you encounter any issues with your Bellissima Imetec Creativity B9 300, please refer to the following common troubleshooting steps:

- **Device Not Turning On:**
 - Check if the power cord is securely plugged into a functional electrical outlet.
 - Ensure the power button is pressed and held for a few seconds to activate the device.
- **Device Not Heating Up:**
 - Confirm that the device is powered on and a temperature setting has been selected.
 - Allow sufficient time for the straightener to reach the set temperature (it heats rapidly, but a few seconds are needed).
 - If the issue persists after checking these points, contact customer support.

• **Hair Snagging or Pulling:**

- Ensure your hair is completely detangled before use.
- Work with smaller, thinner sections of hair.
- Check the ceramic plates for any residue from hair products that might be causing friction. Clean the plates if necessary (when cool and unplugged).

SPECIFICATIONS

Feature	Detail
Model Number	11144X
Brand	BELLISSIMA
Manufacturer	Tenacta Group S.p.A.
Product Dimensions	31 x 3 x 3 cm
Product Weight	367 grams
Plate Material	Ceramic ("Silk Effect" coating)
Color	Grey
Temperature Settings	5 levels, from 150°C to 230°C
Maximum Temperature	230°C
Plate Dimensions	25x100 mm
Power Source	Corded Electric

WARRANTY AND SUPPORT

Warranty Information: This Bellissima product is covered by a manufacturer's warranty. For detailed information regarding the warranty period, terms, and conditions, please refer to the warranty card included in the original product packaging. Please retain your proof of purchase for warranty claims.

Customer Support: Should you require technical assistance, have questions about product operation, or need to arrange for repairs, please contact Bellissima customer service. Contact details, including phone numbers and email addresses, can typically be found on the official Bellissima website or within the product documentation provided with your straightener.