**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



### FLEETWOOD 2004 Destiny Timberlake Cortez Pecos

# FLEETWOOD 2004 Popup Trailer Owners Manual

Models: Destiny, Timberlake, Cortez, Pecos

## Introduction

This manual provides essential instructions for the safe and efficient operation, maintenance, and care of your FLEETWOOD 2004 Popup Trailer. It covers the Destiny, Timberlake, Cortez, and Pecos models. Please read this manual thoroughly before operating your trailer to ensure proper usage and to prevent damage or injury. Keep this manual in a safe place for future reference.

## Setup Procedures

Proper setup is crucial for the stability and functionality of your popup trailer. Follow these steps carefully:

1. **Leveling the Trailer:**

   Position the trailer on a firm, level surface. Use a spirit level to ensure the trailer is level from side to side and front to back. Adjust with leveling blocks under the wheels or stabilizer jacks as needed.

2. **Stabilizer Jacks Deployment:**

   Extend the four corner stabilizer jacks until they firmly contact the ground. Do not use stabilizer jacks to level the trailer; they are for stability only. Ensure all jacks are snug to prevent movement.

3. **Connecting Utilities:**
   - **Electrical:** Connect the shore power cord to a suitable electrical outlet (e.g., 30-amp RV pedestal). Ensure the circuit breaker is off before connecting, then turn it on.
   - **Water:** Connect a potable water hose to the city water inlet. Use a pressure regulator to protect the plumbing system. Open all faucets to purge air from the lines.
   - **Propane:** Open the valve on the propane tank slowly. Check for leaks using a soapy water solution on connections.

4. **Raising the Roof:**

   Unlock the roof latches. Operate the lift system crank handle according to the specific model's instructions until the roof is fully extended and locked into position. Ensure all canvas sections are properly seated.

## Operating Instructions

Familiarize yourself with the operation of your trailer's features:

- **Appliance Operation:**

  Refer to individual appliance manuals for detailed instructions on operating the refrigerator, stove, furnace, and water heater. Ensure proper ventilation when using propane appliances.

- **Water System Usage:**

  When using the fresh water tank, ensure the water pump is turned on. Monitor tank levels and conserve water. For wastewater, ensure the gray water tank valve is closed during use and opened for dumping at designated facilities.

- **Electrical System:**

  Understand the 12V DC and 120V AC systems. The 12V system powers lights, water pump, and furnace fan, typically from the battery. The 120V AC system powers outlets and air conditioning when connected to shore power.

- **Lowering the Roof:**

  Before lowering, ensure all interior items are secured and clear of the roof path. Release the roof locks and slowly lower the roof using the crank handle. Tuck in all canvas and secure the latches.

## Maintenance Schedule

Regular maintenance extends the life of your trailer and ensures safe operation:

- **Before Each Trip:**
  - Check tire pressure and lug nut torque.
  - Test all exterior lights (brake, turn, running).
  - Inspect hitch connection and safety chains.
  - Verify battery charge level.
- **Monthly/Seasonal:**
  - Lubricate lift system components and door hinges.
  - Inspect roof seals and seams for leaks.
  - Clean and condition canvas/vinyl material.
  - Check propane system for leaks.
- **Annual Maintenance:**
  - Wheel bearing inspection and re-packing.
  - Brake system inspection.
  - Appliance servicing by a qualified technician.
  - Winterization/De-winterization procedures.

## Troubleshooting Common Issues

This section addresses common problems you might encounter:

| Problem | Possible Cause | Solution |
|---|---|---|
| No 12V power | Dead battery, tripped fuse, disconnected battery terminal. | Check battery charge, inspect fuses in the power converter, ensure terminals are clean and tight. |

| Problem | Possible Cause | Solution |
|---|---|---|
| No 120V power | Shore power not connected, tripped circuit breaker (trailer or pedestal), faulty cord. | Verify shore power connection, reset circuit breakers, inspect power cord for damage. |
| Water pump runs but no water | Empty fresh water tank, air in lines, clogged filter. | Fill fresh water tank, open faucets to bleed air, check pump filter. |
| Propane appliance not lighting | Propane tank valve closed, empty tank, air in lines, faulty igniter. | Open tank valve, check tank level, purge air by lighting stove burners, consult appliance manual for igniter troubleshooting. |

## Specifications

Key specifications for the FLEETWOOD 2004 Popup Trailer models (Destiny, Timberlake, Cortez, Pecos) may vary slightly by specific floor plan. Consult your original purchase documents for exact figures.

- **Overall Length (Closed):** Approximately 15-18 feet
- **Overall Length (Open):** Approximately 20-25 feet
- **Exterior Width:** Approximately 7 feet
- **Exterior Height (Closed):** Approximately 5 feet
- **Dry Weight:** Approximately 1,500 - 2,500 lbs
- **Gross Vehicle Weight Rating (GVWR):** Approximately 2,500 - 3,500 lbs
- **Fresh Water Capacity:** Typically 10-20 gallons
- **Tire Size:** Consult sidewall of tires for specific size and pressure.

*Note: These are general estimates. Always refer to the weight and tire information labels located on your specific trailer for precise data.*

## Warranty and Support

For specific warranty information regarding your FLEETWOOD 2004 Popup Trailer, please refer to the warranty documentation provided at the time of purchase. Warranty terms and conditions typically cover manufacturing defects for a specified period.
For technical support, parts, or service inquiries, it is recommended to contact an authorized FLEETWOOD dealer or a qualified RV service center. While this manual provides general guidance, professional assistance may be required for complex repairs or diagnostics.
*Please note that this manual is a reprint and may not contain the most current contact information for FLEETWOOD.*

© 2004 FLEETWOOD. All rights reserved. This manual is for informational purposes only.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B00W2492P6**

More documents and user manuals: **https://manuals.plus/**