

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [BaBylissPRO](#) /

› [BaByliss Pro BAB2770E Rotating Hot Air Brush User Manual](#)

BaBylissPRO BAB2770E

BaByliss Pro BAB2770E Rotating Hot Air Brush User Manual

Model: BAB2770E

PRODUCT OVERVIEW

The BaByliss Pro 800W Rotating Hot Air Brush is a professional styling tool designed to provide soft and dynamic or smooth results after blow-drying. Its 800W power delivers volume to hair. The brush features reinforced boar bristles with epoxy tips for easy detangling. Integrated ionic technology helps prevent frizz and static electricity, contributing to a smooth and shiny finish.

This hot air brush includes two interchangeable round brush heads: 40mm and 50mm in diameter. The 50mm brush is suitable for shaping longer hair, while the 40mm brush is ideal for shorter hair sections and fringes. A professional 2.70m rotating cord offers flexibility and ease of use.



Image: The BaByliss Pro BAB2770E Rotating Hot Air Brush, shown with its main body and two interchangeable brush heads. The larger brush head is attached to the device, and the smaller brush head is displayed separately. The device is black with red accents.

SAFETY WARNINGS

Important: Always read all safety instructions before using this appliance. Failure to follow these instructions may result in electric shock, fire, or injury.

- Do not use this appliance near water, in a bathroom, or near a sink.
- Keep the appliance away from children.
- Do not use if the cord is damaged. Contact a qualified service agent for repair.
- Always unplug the appliance after use and before cleaning.
- Do not block the air inlets or outlets during operation.
- Allow the appliance to cool down before storing.
- Do not immerse the appliance in water or any other liquid.

SETUP

1. **Unpack:** Carefully remove the hot air brush and all accessories from the packaging.
2. **Inspect:** Check the appliance and its components for any signs of damage. Do not use if damaged.
3. **Attach Brush Head:** Select the desired brush head (40mm or 50mm). Align the brush head with the main unit and push it firmly until it clicks into place. Ensure it is securely attached before use.
4. **Power Connection:** Plug the appliance into a suitable electrical outlet. Ensure the voltage matches the specifications of the device.

OPERATING INSTRUCTIONS

The BaByliss Pro Rotating Hot Air Brush features 2 rotation directions and 2 speed/temperature settings.

1. **Preparation:** Ensure hair is towel-dried and detangled before use.
2. **Power On:** Turn on the appliance using the power switch. Select your desired speed and temperature setting.
3. **Styling Outwards:**
 - Place the brush at the ends of a hair section.
 - Activate the automatic rotation function to rotate the hair outwards.
 - Slowly glide the brush through the hair, allowing it to dry and style.
4. **Styling Inwards:**
 - Place the brush at the ends of a hair section.
 - Activate the automatic rotation function to wrap the hair inwards.
 - Slowly glide the brush through the hair, allowing it to dry and style.
5. **Volume and Waves:** The rotating action helps create voluminous blowouts and waves.
6. **Power Off:** After styling, turn off the appliance and unplug it from the electrical outlet.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your appliance.

1. **Cleaning:**
 - Ensure the appliance is unplugged and completely cool before cleaning.
 - Remove any hair tangled in the brush bristles using a comb or your fingers.
 - The removable filter can be cleaned for easy and quick maintenance. Gently remove the filter and clean any accumulated dust or hair. Reattach securely.
 - Wipe the body of the appliance with a soft, damp cloth. Do not use abrasive cleaners or solvents.
2. **Storage:**
 - Allow the appliance to cool completely before storing.
 - Place the protective caps over the brush heads to prevent bristles from deforming.
 - Store the appliance in a dry, safe place, out of reach of children.
 - Do not wrap the power cord tightly around the appliance, as this can damage the cord.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in correctly; power outlet issue; damaged cord.	Ensure plug is fully inserted. Test with another outlet. If cord is damaged, discontinue use and contact support.
Brush rotation is inconsistent or stops.	Hair tangled in bristles; excessive hair section; motor overload protection.	Clean brush head of tangled hair. Use smaller hair sections. The motor may temporarily stop to prevent damage; reduce resistance.
Reduced airflow or heating.	Blocked air inlet/outlet; dirty filter.	Check and clear any obstructions from air vents. Clean the removable filter as per maintenance instructions.
Hair is frizzy after use.	Ionic technology not fully effective; hair not fully dry before styling.	Ensure hair is mostly dry before using the hot air brush. Ensure the ionic function is active (if indicated).

SPECIFICATIONS

Model Number: BAB2770E

Brand: BaBylissPRO

Power: 800 Watts

Material: Nylon, Ceramic, Aluminum, Plastic

Color: Black

Dimensions (L x W x H): 37.6 x 15.4 x 9 cm

Weight: 916 grams

Cord Length: 2.70 meters (Professional Rotating Cord)

Brush Heads: 2 interchangeable (40mm and 50mm diameter)

Speed Settings: 2

Temperature Settings: 2

Special Features: Ionic Technology, 2 Rotation Directions, Removable Filter

WARRANTY AND SUPPORT

This BaByliss Pro appliance comes with a **1-year warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.

For technical support, troubleshooting assistance beyond this manual, or warranty service, please contact your local BaBylissPRO authorized service center or retailer.

Online Resources: For additional information and product registration, visit the official BaBylissPRO website.