

HTC One M8s

HTC One M8s User Manual

Model: HTC One M8s

1. INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your HTC One M8s smartphone. Please read this guide thoroughly to ensure proper use and to maximize the performance of your device.

2. PRODUCT OVERVIEW

The HTC One M8s is a powerful 4G/LTE smartphone designed for communication and multimedia. Familiarize yourself with its physical features.



Figure 2.1: Front view of the HTC One M8s, showing the display, front camera, and BoomSound speakers.



Figure 2.2: Side view of the HTC One M8s, highlighting the volume rocker and power button.




Figure 2.3: Rear view of the HTC One M8s, featuring the main camera, dual-LED flash, and HTC logo.



Figure 2.4: Angled front view of the HTC One M8s, displaying the active screen interface.

3. SETUP

3.1. Inserting the Nano SIM Card

1. Locate the SIM card tray on the side of your device.
2. Use the provided SIM ejector tool to open the tray.
3. Place your Nano SIM card into the tray with the gold contacts facing down and the cut corner aligned.

4. Carefully push the tray back into the slot until it is flush with the device.

Important: This device uses a Nano SIM card. Using an incorrect SIM card size or a modified SIM card may damage the device and the card tray.

3.2. Initial Power On and Setup

1. Press and hold the **Power button** (located on the side) until the HTC logo appears.
2. Follow the on-screen instructions to complete the initial setup, including language selection, Wi-Fi connection, and Google account setup.

3.3. Network Compatibility

The HTC One M8s is compatible with network SIM cards that operate on the following frequencies:

- **2G GSM:** 850/900/1800/1900 MHz
- **3G:** 850(B5)/900(B8)/1900(B2)/2100(B1) MHz
- **4G LTE:** 800(B20)/1800(B3)/2600(B7) MHz

Important: Please verify compatibility with your network provider before use to ensure full functionality.

4. OPERATING INSTRUCTIONS

4.1. Basic Navigation

- **Touchscreen:** Tap to select, swipe to scroll, pinch to zoom.
- **Home Button:** Returns to the home screen.
- **Back Button:** Returns to the previous screen.
- **Recent Apps Button:** Displays recently used applications.

4.2. Making Calls and Sending Messages

- To make a call, tap the **Phone** icon, enter the number, and tap the call button.
- To send a message, tap the **Messages** icon, start a new conversation, enter the recipient and your message.

4.3. Connecting to Wi-Fi

1. Go to **Settings > Wi-Fi**.
2. Toggle **Wi-Fi On**.
3. Select your desired network from the list and enter the password if prompted.

4.4. Using the Camera

- Tap the **Camera** icon to open the camera application.
- Tap the screen to focus.
- Tap the shutter button to take a photo or start/stop video recording.

5. MAINTENANCE

5.1. Battery Care

- Use only the charger provided with your device.
- Avoid extreme temperatures, which can affect battery life.
- For optimal battery longevity, avoid frequently discharging the battery completely.

5.2. Cleaning Your Device

- Use a soft, lint-free cloth to clean the screen and body.
- Avoid using harsh chemicals or abrasive materials.

5.3. Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements. Go to **Settings > About phone > Software updates**.

6. TROUBLESHOOTING

If you encounter issues with your HTC One M8s, try the following common troubleshooting steps:

- **Device not turning on:** Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again.
- **No network connection:** Check if your SIM card is properly inserted. Verify that Airplane mode is off. Restart your device.
- **Apps crashing or freezing:** Close and reopen the app. Clear the app's cache (Settings > Apps > [App Name] > Storage > Clear cache). Restart your device.
- **Slow performance:** Close unused apps. Clear cache and temporary files. Consider performing a factory reset as a last resort (back up your data first).

7. SPECIFICATIONS

Feature	Detail
Brand	HTC
Model Name	One M8s
Operating System	Android 4.4
Memory Storage Capacity	16 GB
Screen Size	5 Inches
Resolution	1080 x 1920
Wireless Carrier	Unlocked
Cellular Technology	4G
Connectivity Technology	Wi-Fi
Color	GUNMETAL GRAY
SIM Card Slot Count	Single SIM

Feature	Detail
Connector Type	3.5mm Jack
Form Factor	Bar
Biometric Security Feature	Fingerprint Recognition
Water Resistance Level	Water Resistant
Headphones Jack	3.5 mm
Camera Description	Front, Rear
Item Weight	160 Grams
Item Dimensions	5.75 x 2.76 x 0.39 inches
Video Capture Resolution	720p
Display Type	LCD
Model Year	2015

8. WHAT'S IN THE BOX

The HTC One M8s package typically includes:

- HTC One M8s Smartphone
- Charger

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the warranty card included with your purchase or visit the official HTC support website. Keep your proof of purchase for warranty claims.