

[manuals.plus](#) /› [Timco](#) /› [Timco DW-9600 Rechargeable Shaver and Epilator User Manual](#)

Timco DW-9600

Timco DW-9600 Rechargeable Shaver and Epilator User Manual

1. INTRODUCTION

Welcome to the user manual for your Timco DW-9600 Rechargeable Shaver and Epilator. This device is designed for efficient and convenient hair removal, offering both shaving and epilation functions. It features an interchangeable head, a spot light for enhanced visibility, and comes with a cleaning brush and a protective case.

Please read this manual thoroughly before first use to ensure safe operation, optimal performance, and proper maintenance of your device. Keep this manual for future reference.

2. PRODUCT OVERVIEW

Key Features

- Rechargeable design for cordless operation.
- Interchangeable heads for versatile shaving and epilation.
- Integrated Spot Light for improved visibility of fine hairs.
- Compact and ergonomic design.

Package Contents

- Timco DW-9600 Main Unit
- Epilator Head
- Shaver Head (interchangeable)
- Cleaning Brush
- Storage Case
- Charging Cable (not explicitly listed but implied by 'rechargeable')



Image 1: The Timco DW-9600 device shown with its interchangeable shaver head, cleaning brush, and pink storage pouch.

3. SETUP

Charging the Device

1. Before first use, fully charge the device for approximately 8 hours.
2. Connect the charging cable to the charging port on the device and plug the other end into a suitable power source.
3. The charging indicator light will illuminate during charging.
4. Once fully charged, disconnect the device from the power source.

Attaching and Changing Heads

1. Ensure the device is turned off before changing heads.
2. To remove a head, gently pull it upwards from the main unit.
3. To attach a head, align it with the main unit and press down until it clicks securely into place.



Image 2: A detailed view of the epilator head, showing the rotating tweezers.



Image 3: Side profile of the Timco DW-9600, displaying the model number DW-9600 and charging specifications.

4. OPERATING INSTRUCTIONS

General Use

1. Ensure your skin is clean and dry before use.
2. Turn on the device using the power switch.
3. The integrated spot light will activate, illuminating the area for better visibility.
4. Hold the device at a 90-degree angle to the skin and move it slowly against the direction of hair growth.

5. Do not press too hard on the skin.
6. After use, turn off the device and clean the head.

Using the Epilator Head

The epilator head is designed to remove hair from the root. For best results, ensure hair length is between 2-5mm. Epilation may cause some discomfort initially, which typically decreases with regular use.

Using the Shaver Head

The shaver head provides a close shave for sensitive areas or for quick touch-ups. Move the shaver gently over the skin in short, circular motions or against the direction of hair growth.



Image 4: An alternative view of the Timco DW-9600 epilator, highlighting its ergonomic design.

5. MAINTENANCE

Cleaning the Device

1. Always turn off and unplug the device before cleaning.
2. Remove the head from the main unit.
3. Use the provided cleaning brush to remove any trapped hairs from the epilator or shaver head.
4. The heads can be rinsed under running water. Ensure they are completely dry before reattaching or storing.
5. Wipe the main unit with a dry or slightly damp cloth. Do not immerse the main unit in water.

Storage

Store the device and its accessories in the provided case in a cool, dry place, away from direct sunlight and out of reach of children.

6. TROUBLESHOOTING

- **Device not turning on:** Ensure the device is fully charged. Check if the power switch is in the 'on' position.
- **Reduced performance/pulling hair:** The head might be clogged with hair. Clean the head thoroughly using the cleaning brush. Ensure the head is correctly attached.
- **Charging indicator not lighting up:** Check the charging cable connection and the power source. Ensure the cable is not damaged.
- **Battery life is short:** Battery performance can decrease over time. Ensure the device is fully charged before each use.

7. SPECIFICATIONS

Specification	Detail
Model Number	DW-9600
Brand	Timco
Power Source	Battery Powered
Dimensions	17 x 3 x 12 cm
Weight	200 g
Components Included	Cleaning Brush and Case
Country of Origin	United States

8. WARRANTY AND SUPPORT

For information regarding warranty coverage, please refer to the warranty card included with your product or contact Timco customer support directly. Keep your purchase receipt as proof of purchase.

If you encounter any issues not covered in this manual or require further assistance, please contact Timco customer service through their official website or the contact information provided in your product packaging.