

Manuals.plus /

› Orbegozo /

› Orbegozo PW 1020 Industrial Mini Desktop Fan Instruction Manual

Orbegozo PW 1019

Orbegozo PW 1020 Industrial Mini Desktop Fan

Model: PW 1019 | Brand: Orbegozo

IMPORTANT SAFETY INSTRUCTIONS

Please read and understand all safety instructions before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious personal injury.

- Always unplug the fan from the power source before cleaning, performing maintenance, or when not in use.
- Do not operate the fan with a damaged cord or plug. If the cord or plug is damaged, contact qualified service personnel for repair or replacement.
- Do not immerse the fan, cord, or plug in water or other liquids.
- Keep the fan out of reach of children and pets.
- Do not insert fingers or any objects into the fan grille while it is operating.
- Place the fan on a stable, flat, and dry surface to prevent tipping.
- Ensure proper ventilation around the fan; do not block air inlets or outlets.
- This fan is designed for indoor use only. Do not use outdoors or in wet conditions.

PRODUCT OVERVIEW

The Orbegozo PW 1020 is a compact and efficient industrial-style mini desktop fan, designed to provide personal cooling in various indoor environments such as offices, bedrooms, or small workspaces. Its robust metal construction ensures durability, while its 10 cm diameter blades deliver effective airflow.



Image: The Orbegozo PW 1020 Industrial Mini Desktop Fan, featuring a grey metal frame, a protective grille, and visible fan blades. The Orbegozo logo is centered on the front grille.

SETUP

1. **Unpack:** Carefully remove the fan and all packaging materials from the box. Inspect the fan for any signs of damage.
2. **Placement:** Place the fan on a firm, level, and stable surface. Ensure there is adequate space around the fan for proper air circulation and that no objects obstruct the air intake or exhaust.
3. **Connect Power:** Insert the USB plug of the fan's power cord into a compatible USB power source, such as a computer's USB port, a USB wall adapter (not included), or a power bank.

OPERATING INSTRUCTIONS

1. **Power On:** Once connected to a power source, locate the power switch/button on the fan. Press the switch to turn the fan ON.
2. **Adjust Angle:** Manually tilt the fan head up or down to direct the airflow to your desired position. The fan's stand allows for vertical angle adjustment.

3. **Power Off:** To turn the fan OFF, press the power switch/button again.
4. **Disconnect:** For extended periods of non-use, unplug the fan from the power source.

MAINTENANCE

Regular cleaning and maintenance will help ensure the longevity and optimal performance of your fan.

- **Cleaning:** Before cleaning, always unplug the fan. Use a soft, damp cloth to wipe the exterior surfaces of the fan. Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish.
- **Dust Removal:** Periodically, use a soft brush or a vacuum cleaner with a brush attachment to gently remove dust from the fan blades and the protective grille. Ensure the fan is unplugged during this process.
- **Storage:** When storing the fan, especially during off-season, ensure it is clean and dry. Store it in its original packaging or a suitable container in a cool, dry place to protect it from dust and damage.

TROUBLESHOOTING

If you encounter issues with your Orbegozo PW 1020 fan, refer to the table below for common problems and their solutions.

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply or loose connection.	Ensure the USB cable is securely plugged into both the fan and a working USB power source. Try a different USB port or adapter.
Weak or no airflow.	Blocked air intake/exhaust or dirty blades.	Check for any obstructions around the fan. Unplug the fan and clean dust from the blades and grille.
Unusual noise or rattling.	Fan not on a stable surface or internal obstruction.	Place the fan on a flat, stable surface. Unplug the fan and carefully check for any foreign objects inside the grille.

SPECIFICATIONS

Feature	Detail
Brand	Orbegozo
Model Number	PW 1019
Power Source	Corded Electric (USB)
Style	Industrial
Wattage	4 watts
Voltage	230 Volts (via USB adapter, not included)
Control Method	Touch (On/Off Switch)
Product Dimensions	6.1 x 3.94 x 6.14 inches
Item Weight	12 ounces

WARRANTY AND SUPPORT

This Orbegozo product is covered by a standard manufacturer's warranty, typically for a period of one year from the date of purchase, against defects in materials and workmanship under normal use.

For warranty claims, technical support, or service inquiries, please contact Orbegozo customer service through their official website or the retailer from whom the product was purchased. Please have your proof of purchase and product model number (PW 1019) ready when contacting support.

Do not attempt to repair the fan yourself, as this may void the warranty and could lead to injury.