

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Fasta Pasta](#) /
- › [Fasta Pasta Microwave Pasta Cooker Instruction Manual \(Model FP_102\)](#)

Fasta Pasta FP_102

Fasta Pasta Microwave Pasta Cooker Instruction Manual

Model: FP_102

INTRODUCTION

The Fasta Pasta Microwave Pasta Cooker is designed to simplify the process of cooking pasta in a microwave oven. This manual provides instructions for safe and effective use, ensuring consistent results.



Image: The Fasta Pasta Microwave Cooker, red in color, shown alongside its retail packaging. The cooker is a rectangular container with a lid, designed for microwave use.

KEY FEATURES

- **Microwave Safe:** Designed specifically for microwave use.
- **1.2 Liter Capacity:** Cooks up to 4 servings of pasta.
- **BPA Free:** Made from food-safe materials.
- **Dishwasher Safe:** Easy to clean.
- **Patented Reservoir Design:** Ensures even cooking and prevents boil-overs.

Perfect for:



Students & Busy parents



**Microwave
Safe**



**1.2 L
Capacity**



**BPA
Free**



**Dishwasher
Safe**

Image: A graphic illustrating key features of the Fasta Pasta cooker, including its microwave-safe nature, 1.2-liter capacity, BPA-free material, and dishwasher-safe design. It also suggests suitability for students and busy parents.

SAFETY INFORMATION

- Always use the Fasta Pasta cooker in a microwave oven. Do not use on a stovetop or in a conventional oven.
- Ensure the cooker is placed on a microwave-safe turntable or surface.
- Exercise caution when removing the cooker from the microwave, as contents and the cooker itself will be hot. Use oven mitts or heat-resistant gloves.
- Do not place the lid on the cooker during microwave cooking. The lid is for measuring and draining only.
- Keep out of reach of children.
- Inspect the cooker for any damage before each use. Discontinue use if cracks or damage are observed.

SETUP

1. **Unpacking:** Remove the Fasta Pasta Microwave Cooker from its packaging.
2. **Initial Cleaning:** Before first use, wash the cooker and lid with warm, soapy water. Rinse thoroughly and dry. The cooker is also dishwasher safe.

OPERATING INSTRUCTIONS

Follow these steps for cooking pasta using your Fasta Pasta Microwave Cooker:

4 Easy steps!



Perfect Pasta Every Time!

Image: A visual guide demonstrating the four easy steps: 1. Measure pasta using the cooker's lid. 2. Microwave the pasta in the cooker. 3. Strain the cooked pasta using the lid. 4. Serve the pasta.

1. **Measure Pasta:** Use the built-in measuring holes on the lid to determine the desired serving size for spaghetti or other long pasta. For other pasta shapes, refer to the pasta packaging for serving size recommendations. Place the measured pasta into the cooker.



Image: The Fasta Pasta cooker open, filled with uncooked shell-shaped pasta, positioned on a wooden surface with tomatoes, basil, and sauce nearby.

2. **Add Water:** Fill the cooker with water up to the appropriate water line indicated on the side of the cooker. Ensure the pasta is fully submerged. Do not add salt or oil to the water before cooking, as this can affect the cooking process and potentially cause boil-overs.
3. **Microwave Cooking:** Place the cooker (without the lid) into the microwave. Cook for the time recommended on your pasta packaging, plus an additional 3 minutes. Cooking times may vary based on microwave wattage and pasta type. For example, one serving of spaghetti typically takes 12-13 minutes.
 - **Note on Al Dente:** The Fasta Pasta's patented reservoir design allows water to circulate, promoting even cooking for al dente results.
 - **High Altitude:** For users at high altitudes, this cooker can help achieve al dente pasta more effectively than traditional stovetop methods, as it cooks before water reaches a rolling boil.
4. **Drain Water:** Carefully remove the hot cooker from the microwave using oven mitts. Place the lid securely onto the cooker, aligning the draining holes. Tilt the cooker over a sink to drain the hot water.
5. **Serve:** Once drained, your pasta is ready to serve. Add your favorite sauce and enjoy.

Compatible Pasta Types

The Fasta Pasta Microwave Cooker is suitable for cooking various pasta types, including but not limited to:

- Spaghetti
- Linguini
- Fettuccini
- Penne
- Fusilli
- Lasagna
- Sea Shell
- Tortellini
- Ravioli
- Egg Noodles
- Whole Wheat Pasta
- Gluten-Free Pasta

Cook all types of pasta!

Spaghetti	Lasagna	Ravioli	Egg Noodles
Linguini	Sea Shell	Tortellini	Whole Wheat
Fettuccini	Penne	Fusilli	Gluten-Free

Tons of recipes all under



15 Minutes!

Image: A graphic displaying a list of pasta types such as Spaghetti, Lasagna, Ravioli, Egg Noodles, Linguini, Sea Shell, Tortellini, Whole Wheat, Fettuccini, Penne, Fusilli, and Gluten-Free, indicating the cooker's versatility.

EFFORTLESS COOKING

The Fasta Pasta Microwave Cooker eliminates common inconveniences associated with traditional pasta preparation:

Effortless Cooking



No Boiling



No Straining



No Mess

Image: A graphic showing three panels: "No Boiling" with a boiling pot, "No Straining" with a colander, and "No Mess" with a sink full of dirty dishes, emphasizing the ease of use of the Fasta Pasta cooker.

- **No Boiling:** Avoids the need for large pots and waiting for water to boil on a stovetop.
- **No Straining:** The integrated lid acts as a strainer, eliminating the need for a separate colander.
- **No Mess:** Reduces cleanup by containing the cooking process and minimizing dirty dishes.

MAINTENANCE

- **Cleaning:** The Fasta Pasta Microwave Cooker is dishwasher safe. For hand washing, use warm water and mild dish

soap. Avoid abrasive cleaners or scouring pads that could scratch the surface.

- **Storage:** Store the cooker in a clean, dry place when not in use.

TROUBLESHOOTING

Pasta is not cooked to desired consistency (too hard or too soft):

Adjust microwave cooking time. Microwave wattages vary, so initial cooking times may need slight modification for your specific appliance. Add or subtract 1-2 minutes as needed for future batches.

Water boils over in the microwave:

Ensure you are not adding salt or oil to the water before cooking. These can contribute to boil-overs. Also, verify that the water level does not exceed the maximum fill line.

Cooker does not rotate on the microwave turntable:

If your microwave's turntable is too small for the cooker to rotate freely, manually rotate the cooker halfway through the cooking process to ensure even cooking.

SPECIFICATIONS

Model Number: FP_102

Product Dimensions: 11 x 5.25 x 4 inches (Length x Width x Height)

Item Weight: 11.6 ounces

Capacity: Approximately 1.2 Liters (suitable for up to 4 servings of pasta)

Material: Food-safe, BPA-free microwavable material

Care: Dishwasher safe

Manufacturer: SCS Direct

Dimensions:




Image: A diagram illustrating the dimensions of the Fasta Pasta cooker: 11¼ inches in length, 5¼ inches in width, and 4 inches in height.

SUPPORT

For further assistance or inquiries, please contact the manufacturer, SCS Direct, or visit their official website. Refer to your product packaging for specific contact details.