

[Manuals.plus](#) /

› [Infinity Instruments](#) /

› Infinity Instruments 13.5 inch Shatter Resistant Round Silent Wall Clock (Model 15018BK-4017) User Manual

Infinity Instruments 15018BK-4017

Infinity Instruments 13.5 inch Shatter Resistant Round Silent Wall Clock User Manual

Model: 15018BK-4017

1. INTRODUCTION

This manual provides instructions for the setup, operation, maintenance, and troubleshooting of your new Infinity Instruments 13.5 inch Shatter Resistant Round Silent Wall Clock. This clock features a silent sweep movement, ensuring no ticking sound, and an easy-to-read dial with bold numbers. It is designed for indoor use in various settings such as offices, classrooms, and homes.



Figure 1: Front view of the Infinity Instruments 13.5 inch round wall clock.

2. SETUP

2.1 Battery Installation

1. Locate the battery compartment on the back of the clock.
2. Insert one (1) AA battery (not included) into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the indicators.
3. Close the battery compartment cover securely.

2.2 Setting the Time

1. Turn the time setting knob, located on the back of the clock, in either direction until the hands display the correct time.

2. Avoid forcing the hands directly. Always use the setting knob.

2.3 Mounting the Clock

1. Choose a suitable location on a wall for mounting. Ensure the wall material can support the clock's weight (approximately 1.1 pounds).
2. Use an appropriate wall anchor and screw (not included) for your wall type.
3. Hang the clock using the integrated keyhole hanger on the back.




Figure 2: Side view of the clock, illustrating its dimensions and the typical location for battery and mounting features.

3. OPERATING INSTRUCTIONS

Once the battery is installed and the time is set, your Infinity Instruments wall clock will begin operating automatically. The silent sweep movement ensures that the second hand moves continuously without producing any ticking sounds, making it ideal for quiet environments.

4. MAINTENANCE

4.1 Cleaning

- To clean the clock, gently wipe the surface with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or chemical sprays, as these may damage the finish or the shatter-resistant lens.

4.2 Battery Replacement

Replace the AA battery annually or when the clock begins to lose time or stop functioning. Follow the battery installation steps outlined in Section 2.1.

5. TROUBLESHOOTING

- **Clock Not Running:** Ensure the battery is inserted correctly with the proper polarity. Replace with a fresh AA battery if necessary.
- **Clock Losing Time:** This typically indicates a low battery. Replace the AA battery with a new one.
- **Hands Getting Stuck:** Check if the hands are bent or obstructed. Gently adjust them if possible, ensuring they do not touch each other or the clock face. If the issue persists after battery replacement, the internal mechanism may require professional inspection.

6. SPECIFICATIONS

Feature	Detail
Brand	Infinity Instruments
Model Number	15018BK-4017
Product Dimensions	13.5"W x 13.5"H
Item Weight	1.1 Pounds
Color	Black
Display Type	Analog
Special Feature	Silent Clock
Power Source	Battery Powered
Number of Batteries	1 AA batteries required (not included)
Room Type	Office
Indoor/Outdoor Usage	Indoor
Material	Resin
Mounting Type	Wall Mount
Operation Mode	Mechanical

Feature	Detail
Dial Color	White

7. WARRANTY

This product comes with a **2-year limited warranty**. For specific details regarding warranty coverage and claims, please refer to the warranty documentation included with your purchase or contact customer support.

8. SUPPORT

If you encounter any issues or have questions not covered in this manual, please contact Infinity Instruments customer support. Contact information can typically be found on the product packaging or the official Infinity Instruments website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question