



Manuals.plus /

› Zinus /

› ZINUS Arnav Metal Platform Bed Frame Full Black - Instruction Manual

## Zinus Arnav Metal Platform Bed Frame

# ZINUS Arnav Metal Platform Bed Frame - Full Black Instruction Manual

## 1. INTRODUCTION

---

This manual provides detailed instructions for the assembly, usage, and maintenance of your ZINUS Arnav Metal Platform Bed Frame. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

The ZINUS Arnav Metal Platform Bed Frame is designed to provide sturdy support for your mattress without the need for a box spring. Its minimalist design and durable steel construction ensure long-lasting performance.

## 2. SAFETY INFORMATION


---

- Always check weight limits and properly assemble the bed frame according to these instructions.
- Do not exceed the maximum weight capacity of 700 lbs for Full, Queen, and King sizes, or 350 lbs for Twin size.
- Ensure all bolts are securely tightened before use. Periodically check and re-tighten bolts as needed.
- Keep small parts away from children during assembly to prevent choking hazards.
- Use caution when moving the assembled bed frame to avoid injury or damage.

## 3. PACKAGE CONTENTS

---

Before assembly, verify that all components listed below are present in your package. If any parts are missing or damaged, please contact Zinus customer support.



*An overhead view of all components included in the ZINUS Arnav bed frame package, laid out before assembly.*

- Bed Frame Foundation Components
- Hardware (bolts, washers, nuts)
- Installation Manual (this document)
- Legs
- Wooden Slats
- Assembly Tool (Mini Ratchet)

## 4. ASSEMBLY INSTRUCTIONS

---

Assembly of the ZINUS Arnav bed frame is designed to be straightforward. All necessary tools are included.

### Step-by-Step Guide:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Frame Sides:** Connect the side rails to the head and foot sections using the provided bolts and the mini ratchet tool. Ensure all connections are snug but do not overtighten until the frame is fully assembled.



*A hand using the provided mini ratchet to tighten a bolt, demonstrating the ease of assembly.*

3. **Install Center Support:** Attach the center support beam(s) to the frame.
4. **Place Wooden Slats:** Unroll the wooden slats onto the assembled frame. The slats are connected by a strap and often feature Velcro for secure placement. Peel off any protective film from the anti-slip tape on the slats.



*Detailed view of the wooden slats, highlighting the anti-slip tape for mattress stability and the Velcro strips that secure the slats to the frame.*

- 5. Final Tightening:** Once all parts are in place, go back and securely tighten all bolts. Do not overtighten.



*Image showing the included mini ratchet tool, bolts, and thank you cards provided for assembly.*

## 5. USAGE

---

### **Mattress Support:**

The ZINUS Arnav Metal Platform Bed Frame is designed to be used without a box spring. The wooden slats provide direct support for various mattress types, including latex, memory foam, or spring mattresses. The integrated anti-slip tape on the slats helps prevent mattress movement.

### **Headboard Compatibility:**

The frame features pre-drilled holes in two of the legs, allowing for easy attachment of a standard-sized headboard (headboard not included).

### **Under-Bed Clearance:**

The frame provides approximately 6.8 inches of clearance from the ground, offering space for under-bed storage.



*A close-up of the bed frame leg, showing the clearance for under-bed storage.*



*An assembled ZINUS Arnav Full Metal Platform Bed Frame, showcasing its low-profile design with a mattress and bedding.*

## 6. MAINTENANCE AND CARE

---

- **Cleaning:** Wipe the metal frame with a damp cloth to clean. Avoid harsh chemicals that may damage the finish.
- **Inspection:** Periodically inspect all bolts and connections to ensure they remain tight. Re-tighten as necessary to maintain stability and prevent squeaking.
- **Moving:** When moving the bed frame, lift it rather than dragging it to prevent damage to the frame or your flooring.

## 7. TROUBLESHOOTING

---


- **Squeaking Noises:** If the bed frame develops squeaking noises, check all bolts and ensure they are securely tightened. Loose connections are a common cause of squeaking.
- **Parts Not Fitting:** If a part does not seem to fit, double-check the assembly instructions and part numbers. Ensure no parts are bent or warped. If a part is genuinely defective, contact customer support.
- **Mattress Slippage:** The bed frame includes anti-slip tape on the wooden slats. Ensure the protective

film has been removed from this tape. If slippage persists, additional anti-slip measures can be applied to the slats.

## 8. SPECIFICATIONS

<b>Model Number</b>	AZ-ASMP-10F
<b>Size</b>	Full
<b>Product Dimensions</b>	74.5"L x 53.5"W x 10"H
<b>Color</b>	Black
<b>Material</b>	Durable Steel and Plywood
<b>Weight Capacity</b>	700 lbs (Full, Queen, King); 350 lbs (Twin)
<b>Ground to Item Distance</b>	6.8 Inches
<b>Assembly Required</b>	Yes
<b>Item Weight</b>	54.3 pounds

## Dimension & Capacity



*A diagram illustrating the dimensions of the ZINUS Arnav Full Bed Frame (74.5 inches length, 53.5 inches width, 10 inches height) and its maximum weight capacity of 700 lbs.*

## **9. WARRANTY AND SUPPORT**

---

### **Warranty Information:**

This ZINUS Arnav Metal Platform Bed Frame includes a **5-year worry-free limited warranty**. Please refer to the warranty documentation included with your purchase for specific terms and conditions.

### **Customer Support:**

For assistance with assembly, missing parts, or warranty claims, please contact Zinus customer support. Contact information can typically be found on the Zinus website or on the packaging materials.