

[Manuals.plus](#) /

› [Quechua](#) /

› QUECHUA BL 40 Camping Lantern User Manual

Quechua BL 40

QUECHUA BL 40 Camping Lantern User Manual

Your guide to safe and effective use

1. PRODUCT OVERVIEW

The Quechua BL 40 Camping Lantern is designed for outdoor enthusiasts, providing reliable illumination with its 40 lumens of power. This lantern features a simple, single-button operation and is built for durability with excellent shock resistance. Its IPX4 rating ensures it can withstand rain in all conditions, making it a dependable light source for your camping and outdoor adventures.



The Quechua BL 40 Camping Lantern features a compact design with a yellow base and a translucent white diffuser, providing 40 lumens of light.

2. SETUP

2.1 Battery Installation

1. Locate the battery compartment cover, typically at the base of the lantern.
2. Twist or slide the cover to open it.
3. Insert three (3) AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Securely close the battery compartment cover.



The Quechua BL 40 Camping Lantern can be easily hung using its integrated handle, making it versatile for various camping setups.

3. OPERATING INSTRUCTIONS

3.1 Turning On/Off

The Quechua BL 40 Camping Lantern features a simple, single-button control for ease of use. Press the power button located on the front of the lantern to turn it on. Press the button again to turn it off. This model has one light setting, providing consistent 40-lumen illumination.



When activated, the Quechua BL 40 Camping Lantern emits a bright, even light, ideal for illuminating small areas.

4. MAINTENANCE

4.1 Cleaning

To clean your lantern, wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these can damage the plastic components. Ensure the lantern is dry before storing.

4.2 Battery Replacement

When the light becomes dim or the lantern stops working, it's time to replace the batteries. Follow the battery installation steps outlined in Section 2.1. Always use fresh AA batteries and dispose of old batteries responsibly.

4.3 Storage

For long-term storage, remove the batteries from the lantern to prevent leakage and corrosion. Store the lantern in a cool, dry place away from direct sunlight and extreme temperatures.

5. TROUBLESHOOTING

5.1 Lantern Does Not Turn On

- **Check Batteries:** Ensure batteries are inserted correctly with the proper polarity.
- **Replace Batteries:** If batteries are old or depleted, replace them with new AA batteries.
- **Clean Contacts:** Inspect battery contacts for corrosion. Gently clean with a pencil eraser or cotton swab if necessary.

5.2 Light is Dim

- **Replace Batteries:** Dim light is often an indication of low battery power. Replace all three AA batteries.

6. SPECIFICATIONS

Feature	Detail
Model	BL 40
Brightness	40 lumens
Battery Type	3 x AA batteries (included)
Weight	454 g (approx. 1 pound)
Material	Plastic (Chassis: ABS, Top: PP, Gasket: TPE)
Water Resistance	IPX4 (withstands rain in all conditions)
Manufacturer	Decathlon

7. WARRANTY AND SUPPORT

The Quechua BL 40 Camping Lantern comes with a **2-year guarantee**, ensuring quality and reliability. For any issues not covered in the troubleshooting section or for warranty claims, please contact the retailer or manufacturer's customer support with your proof of purchase.



The Quechua BL 40 Camping Lantern is designed for practical use in outdoor settings, providing essential illumination for camping and other activities.

© 2024 Quechua. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00WRHTIZC>

More documents and user manuals: <https://manuals.plus/>