

O-Cedar 153185

O-Cedar EasyWring Microfiber Spin Mop and Bucket Floor Cleaning System User Manual

Model: 153185

INTRODUCTION

The O-Cedar EasyWring Microfiber Spin Mop and Bucket Floor Cleaning System is designed to provide an efficient and effective floor cleaning experience. This system features hands-free wringing, allowing for controlled moisture levels and quicker drying times for your floors. The microfiber mop head effectively captures dirt and grime using only water, reducing the need for harsh chemicals. It is suitable for all hard floor surfaces, including hardwood, tile, vinyl, and more.

The telescopic handle adjusts up to 51 inches, accommodating various user heights for comfortable operation. The microfiber mop head is reusable and machine-washable, offering a sustainable cleaning solution. Independent lab tests confirm that the O-Cedar EasyWring Spin Mop removes over 99% of E. coli and Staph. aureus from pre-finished hardwood flooring and ceramic tiling with tap water.

INCLUDED COMPONENTS

The O-Cedar EasyWring Microfiber Spin Mop and Bucket Floor Cleaning System includes the following:

- O-Cedar EasyWring Bucket with built-in wringer and splash guard
- Telescopic Mop Handle (adjustable up to 48 inches / 122 cm)
- Microfiber Mop Head Refill (1 count)



EASYWRING™ COMPLETE SET

TRIANGULAR
MOP BASE



EXTENDABLE HANDLE



REUSABLE MOPHEAD



EASYWRING BUCKET

Image: The O-Cedar EasyWring Mop System components, including the triangular mop base, extendable handle, reusable mop head, and the EasyWring bucket.

SETUP INSTRUCTIONS

- 1. Assemble the Mop Handle:** Connect the sections of the telescopic mop handle by twisting them together until secure. Extend the handle to your desired length, up to 48 inches, by twisting the handle to unlock, pulling to extend, and twisting to lock.
- 2. Attach the Mop Head:** Align the microfiber mop head with the triangular mop base. Press the mop head firmly onto the base until it clicks into place.
- 3. Prepare the Bucket:** Fill the O-Cedar EasyWring bucket with water up to the indicated 'MAX' fill line. You may add a small amount of your preferred floor cleaner if desired, though the microfiber is effective with just water.



Image: The O-Cedar EasyWring Microfiber Spin Mop and Bucket Floor Cleaning System, showing the assembled mop and bucket alongside its retail packaging.

OPERATING INSTRUCTIONS

1. **Wet the Mop Head:** Dip the microfiber mop head into the water in the bucket. Ensure the mop head is fully saturated.
2. **Wring the Mop Head:** Place the mop head into the wringer basket. Press the foot pedal repeatedly to activate the spin wringing mechanism. The more you press the pedal, the drier the mop head becomes, allowing you to control the moisture level for different floor types.



Image: A foot pressing the pedal of the O-Cedar EasyWring bucket, demonstrating the 'Pedal Power' feature for moisture control during wringing.

3. **Mop the Floor:** Use the mop to clean your hard floor surfaces. The triangular mop head and 360-degree rotation allow for effective cleaning in corners, under furniture, and along baseboards.

HANDS-FREE WRINGING



Image: A person demonstrating hands-free wringing with the O-Cedar EasyWring mop system, showing the ergonomic design.

The O-Cedar EasyWring Spin Mop is safe for use on all hard floor surfaces, including:

- Stone
- Bamboo
- Wood
- Ceramic
- Laminate
- Concrete
- Marble
- Porcelain
- Vinyl

SAFE FOR ALL HARD FLOORS




Image: A visual guide illustrating the compatibility of the O-Cedar EasyWring mop with various hard floor types, including stone, bamboo, wood, ceramic, laminate, concrete, marble, porcelain, and vinyl.

MAINTENANCE

Mop Head Care

- **Washing:** The microfiber mop head is machine-washable. For best results, wash in cold water with similar colors. Do not use fabric softeners or bleach, as these can damage the microfiber and reduce its effectiveness.
- **Drying:** Air dry or tumble dry on low heat.
- **Replacement:** For optimal cleaning performance, it is recommended to replace the mop head refill every 3 months.



Image: A hand placing the O-Cedar EasyWring microfiber mop head into a washing machine, illustrating the 'Wash & Reuse' feature.

Removing and Replacing Mop Head

1. To remove the mop head, gently pull the mop head away from the triangular base.
2. To attach a new mop head, align it with the triangular base and press firmly until it clicks securely into place.



Image: A visual guide showing the process of easily removing and replacing the O-Cedar EasyWring mop head refill.

Bucket Care

- After each use, empty the dirty water from the bucket.
- Rinse the bucket with clean water and allow it to air dry before storing.



Image: A person emptying the O-Cedar EasyWring bucket into a kitchen sink after use, demonstrating proper disposal of dirty water.

TROUBLESHOOTING

- **Mop head not wringing dry enough:** Ensure the mop head is properly attached to the base. Press the foot pedal firmly and repeatedly until the desired dryness is achieved. Check that the wringer basket is free from obstructions.
- **Streaks on the floor:** The mop head may be too wet, or it might need cleaning or replacement. Ensure the mop head is adequately wrung out before mopping. If using a cleaning solution, ensure it is diluted correctly.
- **Mop head detaches during use:** Verify that the mop head is securely clicked onto the triangular base. If the mop head is old or worn, it may need to be replaced.

SPECIFICATIONS

Brand	O-Cedar
Model Number	153185
Product Dimensions	11.88 x 19.38 x 11.5 inches (30.18 x 49.23 x 29.21 cm)
Item Weight	0.16 ounces (0.01 lbs) - Mop Head; 0.01 Pounds - System
Material	Plastic (Bucket), Microfiber (Mop Head)
Handle Material	Wood (Telescopic)
Special Feature	Spin Mop, Hands-Free Wringing

Included Components

Mop Head, Bucket, Handle

WARRANTY INFORMATION


The O-Cedar EasyWring Microfiber Spin Mop and Bucket Floor Cleaning System is covered by the manufacturer's warranty. For specific details regarding warranty coverage, terms, and conditions, please refer to the documentation included with your product packaging or visit the official O-Cedar website.

CUSTOMER SUPPORT

For further assistance, product inquiries, or to purchase replacement parts and accessories, please contact O-Cedar customer service. You can find contact information on the official O-Cedar website or through the link below:

Visit the [O-Cedar Store on Amazon](#).

Related Documents - 153185

	<p>PowerSmart PS3002 Spin Mop & Bucket Floor Cleaning System User Manual</p> <p>Comprehensive user manual for the PowerSmart PS3002 Spin Mop & Bucket Floor Cleaning System, detailing assembly, usage, cleaning, and maintenance. Features include a microfiber mop head, dehydrator basket, and ergonomic design for efficient floor cleaning.</p>
	<p>O-Cedar EasyWring Microfiber Spin Mop & Bucket System: Use & Care Guide</p> <p>Comprehensive guide for the O-Cedar EasyWring Microfiber Spin Mop & Bucket System, including assembly, usage, and washing instructions. Learn how to effectively clean floors and maintain your mop.</p>
	<p>O-Cedar RinseClean Spin Mop System: Use and Care Guide</p> <p>Comprehensive guide for using and caring for the O-Cedar RinseClean Spin Mop System. Learn assembly, operation, and maintenance for optimal cleaning performance.</p>
	<p>O-Cedar H2PRO™ Flat Mop System: Use & Care Guide</p> <p>Comprehensive guide for assembling, using, and caring for the O-Cedar H2PRO™ Flat Mop System, including cleaning instructions and floor surface compatibility.</p>

© O&O software
O&O BuildPE



[O&O BuildPE User's Guide: Create and Manage Bootable Environments](#)

Comprehensive user guide for O&O BuildPE, detailing how to create, manage, and customize bootable environments for O&O Software products. Covers system requirements, installation, usage, and licensing.

Greenes



[Original Cedar Composter Assembly Instructions | Greenes Fence Co.](#)

Step-by-step assembly guide for the Greenes Fence Co. Original Cedar Composter (Model RCCOMP36). Includes package contents and installation support.