

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Tefal](#) /

› [Tefal Ingenio K20607 Food Tongs Instruction Manual](#)

Tefal K20607

Tefal Ingenio K20607 Food Tongs Instruction Manual

Model: K20607

1. PRODUCT OVERVIEW

The Tefal Ingenio K20607 Food Tongs are designed for versatile use in the kitchen, featuring food-grade silicone tips and a robust construction. These tongs are heat-resistant and safe for use with various cookware surfaces.





Front view of the Tefal Ingenio K20607 Food Tongs, showing the black handles and red silicone tips.

2. SETUP

The Tefal Ingenio K20607 Food Tongs require no assembly. Before first use, wash the tongs thoroughly with warm soapy water and rinse completely. Ensure they are dry before storage or use.

3. OPERATING INSTRUCTIONS

The Tefal Ingenio Food Tongs are designed for safe and efficient handling of food during cooking and serving.

- **General Use:** Use the tongs to grip, lift, and turn food items in pans, on grills, or during serving. The silicone tips provide a gentle yet firm grip.
- **Heat Resistance:** The tongs are heat-resistant up to 230°C (446°F), making them suitable for high-temperature cooking tasks like grilling and frying.

- **Cookware Protection:** The food-grade silicone tips are designed to prevent scratching or damaging non-stick coatings and other delicate cookware surfaces.
- **Locking Mechanism:** For compact storage, the tongs feature a stainless steel locking mechanism. Push the ring at the top of the handle to lock the tongs in a closed position. Pull the ring to release and open the tongs.



A hand using the Tefal Ingenio K20607 Food Tongs to turn skewers in a frying pan, demonstrating practical use.

SUPORTA ATÉ 250°C

Resistente a altas
temperaturas



Close-up of the tongs' red silicone tips in a pan with food, highlighting their heat resistance up to 250°C.

TRAVA EM INOX



The tongs in a closed position, secured by the stainless steel locking mechanism, illustrating compact storage.

4. MAINTENANCE AND CLEANING

Proper care ensures the longevity and performance of your Tefal Ingenio Food Tongs.

- **Hand Washing:** Clean your tongs with hot water, liquid detergent, and a soft sponge. Avoid using abrasive scouring creams, steel wool, or harsh scouring pads, as these can damage the silicone and plastic components.
- **Dishwasher Safe:** The Tefal Ingenio K20607 Food Tongs are dishwasher compatible for convenience.
- **Dishwasher Detergent Note:** Be aware that some dishwasher detergents contain ingredients that may affect the appearance of kitchen utensils over time.
- **Storage:** After cleaning and drying, store the tongs in a dry place. Utilize the locking mechanism to keep them closed for compact storage.

PONTAS DE SILICONE

Fácil de limpar



The Tefal Ingenio K20607 Food Tongs resting on a wooden surface next to prepared food, emphasizing their easy-to-clean design.

COMPATÍVEL COM LAVA-LOUÇAS



The Tefal Ingenio K20607 Food Tongs placed in a dishwasher rack with other dishes, confirming their dishwasher-safe feature.

5. TROUBLESHOOTING

Most issues with the Tefal Ingenio Food Tongs can be resolved with proper care.


- **Stains or Residue:** For stubborn food stains, soak the tongs in warm soapy water before cleaning. Ensure all food particles are removed to prevent buildup.
- **Silicone Discoloration:** Prolonged exposure to highly pigmented foods (e.g., tomato sauce, turmeric) may cause slight discoloration of the silicone tips over time. This is normal and does not affect performance or safety.
- **Difficulty Locking/Unlocking:** Ensure the locking ring is clean and free from food debris. If it feels stiff, a small amount of food-grade mineral oil can be applied to the mechanism, then wiped clean.

6. SPECIFICATIONS

Model	K20607
-------	--------

Material	Food-grade Silicone, Plastic, Stainless Steel
Color	Black/Red/Silver
Dimensions (L x W)	42L x 10W centimetres (approximately 35.6 cm total length)
Item Weight	0.13 Kilograms
Heat Resistance	Up to 230°C (446°F)
Dishwasher Safe	Yes





The Tefal Ingenio K20607 Food Tongs shown with a measurement of 35.6 cm, indicating its overall length.

7. WARRANTY INFORMATION

This product comes with a manufacturer's warranty of **12 months** when sold and shipped by Amazon. If purchased from a third-party seller, please refer to the warranty terms provided by that specific seller.

Please retain your proof of purchase for any warranty claims.

8. SUPPORT

For further assistance, product inquiries, or warranty claims, please contact Tefal customer service or the retailer from whom you purchased the product. Contact information can typically be found on the official Tefal website or your purchase documentation.