

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [LG](#) /
- › [LG 32 L Convection Microwave Oven MC3283AG User Manual](#)

LG MC3283AG

LG 32 L Convection Microwave Oven MC3283AG User Manual

Model: MC3283AG

INTRODUCTION

This manual provides essential instructions for the safe and efficient operation, maintenance, and troubleshooting of your LG 32 L Convection Microwave Oven, model MC3283AG. Please read this manual thoroughly before using the appliance and retain it for future reference.



Figure 1: Front view of the LG 32 L Convection Microwave Oven (MC3283AG). The image displays the black checker pattern finish, the transparent door revealing the interior, and the control panel on the right with a digital display showing '9:00' and various function buttons and a jog dial.

SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, injury to persons, or exposure to excessive microwave energy.

- Do not attempt to operate this oven with the door open or if the door is damaged.

- Do not heat liquids or other foods in sealed containers as they are liable to explode.
- Ensure proper ventilation around the appliance.
- Do not use corrosive chemicals or vapors in this appliance.
- Refer to the full safety guidelines in the included owner's manual.

SETUP

Unpacking

1. Carefully remove all packaging materials from the oven cavity and accessories.
2. Inspect the oven for any damage, such as dents or a misaligned door. Do not operate if damaged.
3. Retain packaging materials for future transport if needed.

Placement

- Place the oven on a flat, stable surface strong enough to hold its weight (approximately 26.3 kg).
- Ensure adequate space for ventilation: at least 20 cm (8 inches) above, 10 cm (4 inches) at the rear, and 5 cm (2 inches) on each side.
- Avoid placing the oven near heat sources or in areas with high humidity.

Power Connection

Connect the power cord to a properly grounded electrical outlet. Ensure the voltage matches the appliance's requirements (900 Watts).

Initial Use

Before first use, clean the interior with a damp cloth. Place the rotating ring and glass tray inside the oven cavity.

OPERATING INSTRUCTIONS

The LG MC3283AG Convection Microwave Oven features a Tact Button/Jog Dial control system for intuitive operation.

Basic Microwave Cooking

1. Place food in a microwave-safe container on the glass tray.
2. Close the oven door securely.
3. Use the Jog Dial to set the cooking time and power level (5 available levels).
4. Press the Start button. The oven will emit a cooking completion alarm when finished.

Convection Cooking

This oven offers convection cooking, allowing for baking and roasting with even heat distribution. Refer to the recipe manual for specific temperature and time settings.

Auto Cook Menu

The oven includes a comprehensive auto cook menu with 201 pre-programmed options, including 132 Indian

dishes. Select the desired menu item and quantity, and the oven will automatically set the cooking parameters.

Special Features

- **Indian Roti Basket:** Prepare a variety of Indian breads like Naans, Lachcha Paranthas, Tandoori Rotis, Thepla, Missi Rotis, and Appams using this dedicated feature.
- **Diet Fry:** This feature allows for cooking crispy dishes with minimal oil, promoting healthier meal preparation.
- **Intellowave Technology:** Ensures faster and more even cooking results by circulating microwaves efficiently.
- **Defrost System:** Utilize the defrost function for thawing frozen foods based on weight or time.

MAINTENANCE

Cleaning the Interior

The oven features a premium stainless steel cavity, which is easy to clean. After each use, wipe the interior with a damp cloth and mild detergent. For stubborn stains, use a microwave-safe cleaner. Do not use abrasive cleaners or scouring pads.

Cleaning the Exterior

Wipe the exterior surfaces with a soft, damp cloth. Avoid spraying cleaners directly onto the control panel.

Cleaning Accessories

The glass tray and rotating ring can be washed in warm, soapy water or in a dishwasher.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Oven does not start	Power cord not plugged in; Door not closed properly; Fuse blown or circuit breaker tripped.	Ensure power cord is securely plugged in; Close door firmly; Check household fuse or reset circuit breaker.
Food not heating	Incorrect cooking time or power level set; Food not suitable for microwave heating.	Adjust cooking time and power level; Ensure food is microwave-safe.
Turntable not rotating	Turntable not properly placed; Debris under turntable.	Re-position turntable and rotating ring; Clean any debris from under the turntable.
Unusual noise during operation	Metal objects in oven; Food container touching oven walls.	Remove any metal objects; Ensure containers are not touching oven walls.

If the problem persists after attempting these solutions, please contact customer support.

SPECIFICATIONS

Brand	LG
Model	MC3283AG
Capacity	32 Litres
Installation Type	Countertop
Oven Cooking Mode	Convection
Special Features	Tact Button/Jog Dial, Indian Roti Basket, Diet Fry, Intellowave Technology
Colour	Black
Wattage	900 Watts
Defrost System	Defrost
Door Orientation	Left
Material	Stainless Steel (Inner Cavity)
Included Components	Owners manual, Recipe manual, cook book, shelf, glass tray & tawa, rotating ring
Item Weight	26 kg 300 g
Item Dimensions (LxWxH)	53 x 31.5 x 52 Centimeters

WARRANTY INFORMATION

This LG 32 L Convection Microwave Oven (MC3283AG) comes with a **1 Year Warranty** from the date of purchase. Please retain your purchase receipt as proof of warranty. The warranty covers manufacturing defects under normal use conditions. For detailed terms and conditions, refer to the warranty card included with your product or contact LG customer service.

SUPPORT

For further assistance, technical support, or service requests, please refer to the contact information provided in your owner's manual or visit the official LG website for your region. Ensure you have your model number (MC3283AG) and serial number ready when contacting support.

Additional resources:

- The included Owner's Manual provides detailed operational and safety guidelines.
- The Recipe Manual and Cook Book offer various recipes optimized for this appliance.

