

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Keurig](#) /
- › [Keurig 2.0 K200 Brewer Instruction Manual](#)

Keurig K200

Keurig 2.0 K200 Brewer Instruction Manual

Model: K200 (117645)

INTRODUCTION

Welcome to the world of Keurig brewing! The Keurig K2.0 K200 Brewer is designed to provide a convenient and high-quality brewing experience for both single cups and carafes. This compact brewer features advanced technology to ensure a perfect beverage every time.

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Keurig K2.0 K200 Brewer. Please read it thoroughly before first use.

KEY FEATURES

- **Versatile Brewing:** Brews 9 different sizes, including K-Cup and K-Carafe sizes.
- **Large Water Reservoir:** Equipped with a 40 oz. water reservoir for multiple brews.
- **Strength Control:** Customize your beverage strength to your preference.
- **Intuitive Interface:** Features a black and white touch display for easy operation.
- **Compact Design:** Sleek and compact size fits well in various kitchen spaces.
- **Water Filtration:** Includes 1 water filter handle and 1 charcoal filter for improved water quality.

SETUP GUIDE

1. Unpacking and Placement

Carefully remove all packaging materials from the brewer. Place the brewer on a clean, flat, and stable surface. Ensure there is adequate clearance around the brewer for proper ventilation and access to the water reservoir.



KEURIG

Enjoy!

KEURIG
2.0

MAX

MIN



Image: The Keurig K200 Brewer in Strawberry, showcasing its compact design and a mug placed on the drip tray.

2. Initial Rinse

1. Remove the water reservoir from the brewer.
2. Wash the reservoir and lid with mild soap and warm water. Rinse thoroughly.
3. Fill the reservoir with fresh, filtered water up to the MAX fill line.
4. Place the reservoir back onto the brewer, ensuring it is seated properly.

3. Power On and First Brew

1. Plug the brewer into a grounded outlet. The brewer will automatically power on.
2. Place a large mug (at least 10 oz.) on the drip tray.
3. Do not insert a K-Cup pod. Close the handle.
4. Select the largest brew size from the touch display.
5. Press the brew button. The brewer will dispense hot water. Discard the hot water.
6. Repeat this process once more to ensure the system is clean.





Image: A detailed front view of the Keurig K200 Brewer, highlighting the water reservoir and the touch display panel.

OPERATING INSTRUCTIONS

Brewing a Single K-Cup Pod

1. Ensure the water reservoir is filled with fresh water.
2. Lift the brewer handle.
3. Place a K-Cup pod into the K-Cup holder.
4. Lower the handle completely to close.
5. Place a mug on the drip tray.

6. Select your desired brew size and strength from the touch display.
7. Press the brew button. The brewer will begin brewing.

Brewing a K-Carafe Pod

The K200 Brewer is compatible with K-Carafe pods for brewing larger quantities (up to 4 cups) into a Keurig Carafe (sold separately).

1. Ensure the water reservoir is filled with fresh water.
2. Lift the brewer handle.
3. Place a K-Carafe pod into the K-Carafe holder.
4. Lower the handle completely to close.
5. Place a Keurig Carafe on the drip tray.
6. Select your desired brew size (carafe size) and strength from the touch display.
7. Press the brew button. The brewer will begin brewing into the carafe.

Your browser does not support the video tag.

Video: An official Keurig video demonstrating the features and ease of use of the K200 series brewer, including K-Cup and K-Carafe brewing options, water reservoir, and touch display.

MAINTENANCE AND CLEANING

Regular Cleaning

- **Drip Tray:** The drip tray can accumulate liquid. It should be removed, emptied, and cleaned regularly with warm, soapy water.
- **K-Cup Pod Holder:** The K-Cup pod holder can be removed for cleaning. Wash with warm, soapy water and rinse thoroughly.
- **Exterior:** Wipe the exterior of the brewer with a damp, non-abrasive cloth.

Descaling

Over time, calcium deposits (scale) can build up in your brewer, affecting performance. Descaling should be performed every 3-6 months, or when the 'Descale' indicator appears on the display.

1. Turn off the brewer.
2. Empty the water reservoir.
3. Pour a full bottle of Keurig Descaling Solution into the water reservoir.
4. Fill the empty descaling solution bottle with water and pour it into the reservoir.
5. Place a large mug on the drip tray.
6. Turn on the brewer.
7. Perform a series of cleansing brews until the 'Add Water' message appears.
8. Let the brewer stand for at least 30 minutes.
9. Empty the mug and rinse the water reservoir.

10. Fill the reservoir with fresh water and perform at least 12 rinse brews to remove any residual solution.

Water Filter Replacement

The Keurig K200 Brewer includes a water filter handle and a charcoal filter. The charcoal filter should be replaced every 2 months or 60 tank refills for optimal water quality.

1. Soak a new charcoal filter in fresh water for 5 minutes.
2. Rinse the filter under running water for 60 seconds.
3. Insert the new filter into the water filter handle.
4. Place the assembled filter into the water reservoir.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Brewer not turning on	Not plugged in; power outage; circuit breaker tripped.	Ensure brewer is securely plugged into a grounded outlet. Check power supply and circuit breaker.
No water dispensing	Water reservoir empty; air in lines; brewer needs descaling.	Fill reservoir. Perform a cleansing brew without a pod. Descale the brewer.
Coffee tastes weak or watery	Incorrect brew size selected; strength control not activated; K-Cup pod punctured incorrectly.	Select a smaller brew size. Activate strength control. Ensure K-Cup pod is properly seated and punctured.
"Add Water" message persists	Reservoir not seated correctly; water level sensor issue.	Remove and re-seat the water reservoir firmly. Ensure water level is above the minimum fill line.

For further assistance, please refer to the [Keurig Support Page](#) or contact customer service.

PRODUCT SPECIFICATIONS

Brand: Keurig

Model: K200 (117645)

Color: Strawberry

Coffee Maker Type: Drip Coffee Machine

Operation Mode: Semi-Automatic

Human Interface Input: Touchscreen

Water Reservoir Capacity: 40 oz.

Brew Sizes: 9 (including K-Cup and K-Carafe sizes)

Special Feature: Water Filter (includes 1 water filter handle and 1 charcoal filter)

Product Dimensions: 15 x 9 x 13.7 inches

Item Weight: 7.5 pounds

UPC: 649645202914

Manufacture Year: 2014

Date First Available: May 11, 2015

WARRANTY AND SUPPORT

The Keurig K2.0 K200 Brewer comes with a manufacturer's warranty. Please refer to the warranty card included with your product for specific terms and conditions. For spare part availability in the EU, a duration of 2 years is specified.

For customer support, troubleshooting, or to purchase accessories and replacement parts, please visit the official [Keurig Store on Amazon](#) or contact Keurig customer service directly.