Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- TecTake /
- > TecTake® Set of 3 Hard-Shell Suitcases Instruction Manual

TecTake 800024

TecTake® Set of 3 Hard-Shell Suitcases

Model: 800024

1. Introduction

Thank you for choosing the TecTake Set of 3 Hard-Shell Suitcases. This manual provides essential information for the safe and efficient use of your new luggage set. Please read these instructions carefully before using the product and retain them for future reference. This set includes three suitcases in XL, L, and M sizes, designed for durability, convenience, and secure travel.



Image 1.1: The TecTake Set of 3 Hard-Shell Suitcases (XL, L, M) in Burgundy Red.

2. SAFETY GUIDELINES

- Do not overload the suitcases beyond their recommended capacity to prevent damage to the zippers, handles, or shell.
- Always ensure the combination lock is set and secured before checking in or leaving your luggage unattended.
- When lifting, use both the top and side handles for balanced weight distribution, especially for heavier suitcases.
- Be cautious when navigating uneven surfaces with the wheels to prevent damage.
- Keep the suitcases away from extreme heat sources or open flames.
- Do not allow children to play with or inside the suitcases.

3. PRODUCT FEATURES AND COMPONENTS

Your TecTake suitcase set is designed with several features to enhance your travel experience:

- **Durable Shell:** Constructed from a lightweight blend of polycarbonate and ABS plastic, offering robust protection against impacts and scratches.
- 360° Spinner Wheels: Each suitcase is equipped with four super quiet, mobile, and removable rubber wheels for effortless multi-directional movement.
- **Telescopic Handle:** A premium aluminum telescopic handle that extends and retracts smoothly, adjustable to multiple heights for comfortable maneuvering.
- Combination Lock: An integrated three-digit combination lock provides security for your belongings.
- Compartmented Interior: The interior features a divider, elastic fastening straps, and a mesh pocket to help organize your packed items.
- Side Handles: Ergonomic side handles on two sides (for L and XL sizes) for easy lifting and carrying.
- Stackable Design: The suitcases are designed to nest within each other for optimal storage when not in use.



Image 3.1: The TecTake suitcases demonstrating their mobility in an airport environment.




Image 3.2: Detailed view of key components including the ergonomic telescopic handle, protective rubber feet, reinforced corners, and smooth 360-degree rotating wheels.

4. INITIAL SETUP

4.1 Unpacking

Carefully remove all suitcases from their packaging. The smaller suitcases are nested inside the larger ones for efficient shipping. Inspect each suitcase for any signs of damage during transit. Remove any protective films or tags.

4.2 Setting the Combination Lock


Your suitcase comes with a pre-set combination of 0-0-0. To set your personal combination:

- 1. Locate the combination lock on the side of the suitcase.
- 2. The initial combination is usually 0-0-0. Ensure the dials are set to this combination.
- 3. Find the small reset button or lever. This is typically a small, recessed button that needs to be pressed with a pen or a pointed object, or a small lever that needs to be moved.

- 4. While holding the reset button/lever, set your desired 3-digit combination by rotating the dials. Choose a memorable number.
- 5. Release the reset button/lever. Your new combination is now set.
- 6. Test your new combination by scrambling the dials and then entering your new code to open the lock.

Note: There is no master key for this lock. If you forget your combination, you will need to try all 1000 possible combinations (000-999) or seek professional assistance to open the lock.

MÁXIMA seguridad









Con estas 3 maletas de viaje resistentes a arañazos, golpes y agua, siempre estarás tranquilo cuando viajes. Gracias a la resistente carcasa en plástico ABS y a los fiables cierres de 3 posiciones, tus pertenencias estarán perfectamente protegidas contra golpes e influencias externas.

Image 4.1: Detail of the integrated combination lock and double zipper closure for enhanced security.

4.3 Attaching/Detaching Wheels (If Applicable)

Some models feature removable wheels for compact storage or replacement. If your wheels are removable, they typically click into place. To attach, align the wheel stem with the socket and push firmly until it clicks. To detach, locate the release button or lever near the wheel base and press it while pulling the wheel away.


5. OPERATION

5.1 Using the Telescopic Handle

Press the button on top of the handle and pull upwards to extend it. Release the button to lock it at your desired height. To retract, press the button again and push the handle down until it is fully nested.

5.2 Maneuvering the Suitcase

Thanks to the 360° spinner wheels, you can push, pull, or roll the suitcase alongside you with minimal effort. For optimal stability, especially on uneven surfaces, tilt the suitcase and pull it on two wheels.



nuevos viajes









Las 3 maletas se deslizan sin esfuerzo sobre cualquier superficie. Las resistentes ruedas, no sólo giran 360° y funcionan con suavidad, sino que también pueden desmontarse en caso necesario, como para ahorrar espacio en el maletero. Esto hará que su próximo viaje sea aún más cómodo.

Image 5.1: The 360-degree wheels are designed for smooth movement across various surfaces, including wood, cobblestone, and asphalt.

5.3 Packing the Suitcase

Utilize the interior compartments, elastic straps, and mesh pocket to organize your belongings efficiently. Place heavier items at the bottom near the wheels for better balance. Secure items with the elastic straps to prevent shifting during transit.



Image 5.2: The functional interior features a divisible compartment and an ample mesh pocket, along with practical fastening straps to keep contents organized.

6. CARE AND MAINTENANCE

6.1 Cleaning the Exterior

Wipe the hard-shell exterior with a soft, damp cloth and mild soap. Avoid abrasive cleaners or solvents that could damage the finish. Dry thoroughly with a clean cloth.

6.2 Wheel Maintenance

Periodically check the wheels for debris (hair, lint, etc.) that might hinder their rotation. Clean them gently with a small brush or cloth. If wheels become stiff, a small amount of silicone-based lubricant can be applied to the axle.

6.3 Storage

Store the suitcases in a cool, dry place away from direct sunlight. For optimal space-saving, nest the smaller suitcases inside the larger ones.

7. TROUBLESHOOTING

7.1 Combination Lock Issues

- Lock not opening: Ensure you have entered the correct combination. If you forgot it, refer to section 4.2 for instructions on resetting (if applicable) or note that you may need to try all combinations.
- Dials are stiff: Apply a small amount of silicone spray to the dials and work them to loosen.

7.2 Wheel Issues

- Wheels not spinning smoothly: Check for tangled hair or debris around the wheel axle and remove it. Lubricate if necessary (see section 6.2).
- Wheels detaching unexpectedly: If your model has removable wheels, ensure they are securely clicked into place. If they continue to detach, inspect the locking mechanism for damage.

7.3 Zipper Issues

• **Zipper stuck:** Do not force it. Gently pull the fabric away from the zipper teeth and try to move the slider. A small amount of lubricant (like graphite from a pencil) can help.

8. TECHNICAL SPECIFICATIONS



Detalles del producto

MEDIDAS

Maleta M Medidas 41 x 22 x 58 cm Interiores 35 x 21 x 50 cm

Maleta L Medidas 47 x 26,5 x 68 cm Interiores 41 x 25,5 x 60 cm

Maleta XL Medidas 53 x 30 x 77,5 cm Interiores 47 x 29 x 70 cm

Las medidas son aproximadas

DATOS TÉCNICOS

Peso maleta M aprox. 2,6 kg Peso maleta L aprox. 3,1 kg Peso maleta XL aprox. 4 kg Material plástico ABS, aluminio, polipropileno, 100% poliéster

CONTENIDO

Maleta M Maleta L Maleta XL Manual de instrucciones



Image 8.1: Detailed measurements and technical data for the M, L, and XL suitcases.

Specification	Suitcase M	Suitcase L	Suitcase XL
External Dimensions (approx.)	56 x 40 x 23 cm	66 x 44.5 x 26 cm	75 x 50 x 30 cm
Internal Dimensions (approx.)	47.5 x 35 x 22 cm	58.5 x 41 x 24.5 cm	68 x 47.5 x 29 cm
Volume (approx.)	37 liters	58 liters	93 liters
Weight (approx.)	2.5 kg	3.1 kg	4.1 kg
Telescopic Handle Extended Height	102 cm	102 cm	102 cm
Material	ABS Plastic (Shell), Aluminum (Telescopic Handle), Rubber (Wheels), Polyester (Interior Lining)		

9. WARRANTY AND SUPPORT

TecTake products are manufactured to high-quality standards. For any questions regarding your product, warranty claims, or technical support, please refer to the contact information provided at the point of purchase or visit the official TecTake website. Please retain your proof of purchase for any warranty-related inquiries.

Related Documents - 800024



TecTake Luggage Combination Lock Setup and Parts Guide

Comprehensive guide for TecTake luggage, covering combination lock setup, parts identification (suitcase, wheels), and assembly instructions. Features model numbers 402669-402675.



Tectake Non-Stick Cookware Set Instruction Manual

This manual provides comprehensive instructions for the Tectake non-stick cookware set (Model N250609004-V1), including parts identification, safety guidelines, usage instructions, and cleaning procedures.



Tectake Cookware Set Instruction Manual - FRR251128025-V2

Comprehensive instruction manual for the Tectake FRR251128025-V2 cookware set, covering parts list, safety, usage, cleaning, and handle attachment/removal. Includes multilingual support.




TecTake 402756 Home Gym Assembly and Exercise Guide

Instruction manual for the TecTake 402756 home gym, covering assembly, safety precautions, and exercise guidance. Includes preparation tips and warm-up/cool-down routines.



TecTake 400777 Semi-Automatic Washing Machine User Manual and Instructions

This user manual provides comprehensive instructions for the TecTake 400777 semi-automatic washing machine, covering installation, operation, safety guidelines, and maintenance. Learn how to effectively wash and spin your clothes with this efficient appliance.



tectake Non-Stick Cookware Set Instruction Manual & Parts List

Comprehensive instruction manual and parts list for the tectake non-stick cookware set (Model R251128022-V4, 405299), including safety guidelines, usage instructions, and cleaning advice.