Tefal K2060614

Tefal Ingenio Kitchen Tools K20606 User Manual

Model: K2060614

Product Overview

The Tefal Ingenio Kitchen Tools K20606 are a set of two versatile utensils designed for serving salads and other dishes. These tools can be used independently as a spoon and a fork, or they can be interlocked to form a convenient pair of tongs. Made from durable plastic, they are designed for ease of use and simple maintenance.



Image: The Tefal Ingenio Kitchen Tools K20606, featuring a red spoon and a black fork, designed to interlock for use as salad tongs.

Setup

The Tefal Ingenio Kitchen Tools K20606 require no assembly. They are ready for immediate use upon unboxing.

1. **Unpacking:** Carefully remove the salad servers from their packaging.
2. **Initial Cleaning:** Before first use, wash the tools with warm soapy water and rinse thoroughly. They are also dishwasher safe.



Image: The Tefal Ingenio Kitchen Tools K20606, displayed as two separate pieces: a red spoon and a black fork.

Operating Instructions

The Ingenio Kitchen Tools offer flexible usage options:

- **Individual Use:** Use the spoon and fork separately for serving different components of a meal or for general kitchen tasks.
- **Tongs Function:** To form tongs, align the handle of the red spoon with the handle of the black fork. The design allows them to interlock securely, providing a convenient tong mechanism for gripping and serving salads or other items.





Image: A top-down view of the Tefal Ingenio Kitchen Tools K20606, illustrating how the handles interlock to form a single serving utensil.

Maintenance and Care

Proper care will ensure the longevity of your Tefal Ingenio Kitchen Tools:

- **Cleaning:** These tools are dishwasher safe. For hand washing, use warm water and a mild dish soap. Rinse thoroughly and dry completely before storage.
- **Storage:** Store in a dry place. The interlocking design allows for compact storage when used as tongs.
- **Heat Resistance:** While durable, avoid exposing the plastic tools to direct high heat sources like open flames or leaving them in hot pans for extended periods, as this may cause melting or deformation.



Image: The Tefal Ingenio Kitchen Tools K20606, with the red spoon and black fork crossed, demonstrating their individual forms.

Troubleshooting

Problem	Possible Cause	Solution
Tools do not interlock securely.	Incorrect alignment of handles.	Ensure the designated interlocking points on both handles are properly aligned and clicked into place.
Tools show signs of melting or deformation.	Exposure to excessive heat.	Avoid leaving tools in hot pans or near open flames. These tools are not designed for cooking directly in high-heat environments.
Stains or residue remain after washing.	Stubborn food particles or hard water.	Pre-soak tools in warm soapy water. Use a non-abrasive brush or sponge for cleaning. For hard water stains, a vinegar solution may help.

Specifications

- **Model Number:** K2060614
- **Material:** Plastic
- **Color:** Black / Red
- **Dimensions:** Approximately 22.1 x 9.2 x 3.5 cm (L x W x H)
- **Weight:** Approximately 78 g
- **Dishwasher Safe:** Yes
- **Components:** 1 x Tefal Ingenio Salad Spoon, 1 x Tefal Ingenio Salad Fork
- **GTIN:** 03168430220546
- **UPC:** 764558098123

Warranty Information

Tefal products are manufactured to high-quality standards. This product typically comes with a manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation provided with your purchase or visit the official Tefal website. The warranty period is generally 12 months when sold and shipped by Amazon. For purchases from third-party sellers, their specific warranty information applies.

Customer Support

For further assistance, product inquiries, or troubleshooting not covered in this manual, please contact Tefal customer support or visit the official Tefal website:

- **Tefal Official Website:** www.tefal.com
- **Amazon Store Page:** Tefal Store on Amazon

© 2024 Tefal. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question