

[Manuals.plus](#) /

› [Diesel](#) /

› Diesel Mega Chief Chronograph Watch DZ4360 User Manual

Diesel DZ4360

Diesel Mega Chief Chronograph Watch DZ4360 User Manual

Model: DZ4360

INTRODUCTION

This manual provides essential information for the proper use, care, and maintenance of your Diesel Mega Chief Chronograph Watch, Model DZ4360. This timepiece features a bold design with a 51mm gold stainless steel case, a gold dial, and a matching gold stainless steel bracelet. It is equipped with a quartz movement, chronograph functionality, and a date window. The watch is water-resistant up to 100 meters (330 feet), making it suitable for bathing, swimming, snorkeling, and shallow diving.



Figure 1: Front view of the Diesel Mega Chief 51MM Gold Chronograph Watch.

SETUP

Setting the Time and Date

1. **Pull out the crown:** Gently pull the crown (the knob on the side of the watch) to the second click position.
2. **Set the time:** Turn the crown to adjust the hour and minute hands to the correct time. Ensure you differentiate between AM and PM for the date change.
3. **Set the date:** Push the crown back to the first click position. Turn the crown to adjust the date. Avoid setting the date between 9 PM and 3 AM, as this can interfere with the date change mechanism.
4. **Push in the crown:** Once the time and date are set, push the crown back into its normal position to start the watch.

Adjusting the Watch Band

The gold stainless steel bracelet features removable links for a customized fit. It is recommended to have a professional jeweler adjust the band to ensure proper fit and to avoid damage to the watch or band.



Figure 2: The Diesel Mega Chief watch worn on a wrist, showcasing its size and design.

OPERATING THE CHRONOGRAPH

Your Diesel Mega Chief watch includes a chronograph function for measuring elapsed time. The chronograph features three subdials to track minutes, seconds, and 24-hour time.

1. **Start:** Press the top pusher button (A) to start the chronograph. The chronograph second hand will begin to move.
2. **Stop:** Press the top pusher button (A) again to stop the chronograph. The elapsed time will be indicated by the chronograph hands.
3. **Reset:** After stopping the chronograph, press the bottom pusher button (B) to reset all chronograph hands to their zero positions.

Your browser does not support the video tag. Please
update your browser to view this content.

Video 1: A detailed look at the Diesel Mega Chief Stainless Steel Chronograph Watch, highlighting its features and design.

MAINTENANCE

Cleaning

To maintain the appearance of your watch, regularly wipe the case and bracelet with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials.

Water Resistance

The watch is water-resistant up to 100 meters (330 feet) or 10 ATM. This means it is suitable for recreational swimming, snorkeling, and shallow diving. However, it is crucial to ensure the crown is fully pushed in before any water exposure. Do not operate the crown or pushers while the watch is wet or submerged.

Battery Replacement

The watch is powered by a quartz movement and requires a battery. When the battery needs replacement, it is recommended to take your watch to an authorized Diesel service center or a reputable jeweler. This ensures the correct battery type is used and the water resistance seal is properly maintained.



Figure 3: Rear view of the watch, showing the case back and bracelet clasp.

TROUBLESHOOTING

- **Watch not running:** Check if the crown is fully pushed in. If the watch still does not run, the battery may need replacement.
- **Time or date not setting:** Ensure the crown is pulled out to the correct position (first click for date, second click for time). Avoid setting the date during the automatic date change period (9 PM - 3 AM).
- **Chronograph hands not resetting to zero:** This may require a chronograph reset procedure. Consult an authorized service center if the issue persists after following the operating instructions.
- **Water inside the watch:** If you notice condensation or water inside the watch, immediately take it to an authorized service

center. This indicates a compromised water resistance seal.

Your browser does not support the video tag. Please update your browser to view this content.

Video 2: A brief merchant video showcasing the Diesel Mega Chief watch, including its design and features.

SPECIFICATIONS

Feature	Detail
Model Number	DZ4360
Case Diameter	51 Millimeters
Case Thickness	12 Millimeters
Band Width	26 Millimeters
Band Length	200 Millimeters
Case Material	Stainless Steel
Band Material	Stainless Steel
Dial Color	Gold
Band Color	Gold
Movement Type	Quartz
Display Type	Analog
Water Resistance Depth	100 Meters (330 Feet) / 10 ATM
Item Weight	120 Grams
Battery	1 Lithium Ion battery (included)

WARRANTY AND SUPPORT

Your Diesel Mega Chief Chronograph Watch (Model DZ4360) is covered by a manufacturer's warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included with your purchase or visit the official Diesel website. For technical support, repairs, or any other inquiries, please contact an authorized Diesel service center or the retailer from whom you purchased the watch. You can find more information and support by visiting the official [Diesel Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question