

[Manuals.plus](#) /

› [RASTAR](#) /

› RASTAR Ferrari LaFerrari Die-Cast Model Instruction Manual

RASTAR 48900

RASTAR Ferrari LaFerrari Die-Cast Model Instruction Manual

Model: 48900

INTRODUCTION

This manual provides comprehensive instructions for the operation and maintenance of your RASTAR Ferrari LaFerrari Die-Cast Model. This highly detailed replica offers a full-function radio control experience, designed for enthusiasts and collectors. Please read this manual thoroughly before use to ensure proper function and longevity of your model.



Image: The RASTAR Ferrari LaFerrari Die-Cast Model in red, accompanied by its red radio control unit.

SAFETY INFORMATION

Please observe the following safety guidelines to prevent injury or damage to the product:

- This product is recommended for ages 6 years and up. Adult supervision is advised for younger users.
- Do not operate the model near people, pets, or obstacles.
- Avoid operating in wet conditions or on public roads.
- Ensure batteries are inserted with correct polarity. Do not mix old and new batteries, or different types of batteries.
- Remove batteries from the model and remote control when not in use for extended periods.
- Do not attempt to modify or disassemble the model or remote control.
- Keep small parts away from young children to prevent choking hazards.

WHAT'S IN THE BOX

Upon opening the packaging, verify that all components are present:

- 1 x RASTAR Ferrari LaFerrari Die-Cast Model (RC Car)
- 1 x Remote Control Unit
- 1 x Instruction Manual (this document)



Image: The RASTAR Ferrari LaFerrari Die-Cast Model and its remote control, displayed in front of the product packaging.

SETUP

Battery Installation

The RASTAR Ferrari LaFerrari Die-Cast Model requires 5 AA batteries for operation (not included).

1. **For the RC Car:** Locate the battery compartment on the underside of the car. Open the cover, insert 3 AA batteries, ensuring correct polarity (+/-). Close the cover securely.
2. **For the Remote Control:** Locate the battery compartment on the back of the remote control. You may need a Philips screwdriver to open the cover. Insert 2 AA batteries, ensuring correct polarity (+/-). Close the cover securely.

and replace the screw if applicable.

Once batteries are installed, ensure the power switch on the car (usually on the underside) is in the "ON" position.

OPERATING INSTRUCTIONS

Pairing the Remote Control

The remote control and car are typically pre-paired. If pairing is required, turn on both the car and the remote control. The remote control's indicator light should illuminate, and the car should respond to commands. If not, turn both off and on again.

Driving the Model

The remote control features intuitive controls:

- **Forward/Backward:** Use the joystick or button to move the car forward or backward.
- **Left/Right:** Use the joystick or button to steer the car left or right.
- **Combined Movement:** For example, pushing forward and left simultaneously will make the car move forward and turn left.

For optimal performance, operate the model on smooth, flat surfaces. Avoid carpets or rough terrain which may impede movement.



Image: A young child seated on the floor, happily operating the RASTAR Ferrari LaFerrari Die-Cast Model with the remote control.

MAINTENANCE

Cleaning

To maintain the appearance and function of your model:

- Wipe the car and remote control with a soft, dry cloth.
- Do not use chemical cleaners or water directly on the electronic components.
- Remove any debris from the wheels and axles regularly to ensure smooth operation.

Storage

When not in use, store the model in a cool, dry place, away from direct sunlight and extreme temperatures. Remove batteries if storing for an extended period.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Car does not move.	Batteries are dead or incorrectly installed. Car power switch is OFF. Remote control batteries are dead. Car and remote are not paired.	Replace batteries in car and/or remote. Ensure correct polarity. Turn car power switch to ON. Replace remote control batteries. Turn both car and remote OFF, then ON again to re-establish connection.
Car moves slowly or erratically.	Low battery power. Interference from other electronic devices. Obstruction in wheels.	Replace batteries. Move to an area with less interference. Check and clear any debris from the wheels.
Car does not steer straight.	Wheel alignment issue.	Adjust the steering trim knob/lever on the underside of the car or on the remote control (if available) until the car tracks straight.

SPECIFICATIONS

Feature	Detail
Model Name	Ferrari LaFerrari Die-Cast Model
Model Number	48900 (ASIN: B00XGDQIK4)
Brand	RASTAR
Product Dimensions	Approximately 15.16 x 4.72 x 3.94 inches
Item Weight	14.1 ounces
Recommended Age	6 years and up
Batteries Required	5 AA batteries (3 for car, 2 for remote)

Feature	Detail
Control Type	Full Function Radio Control



Image: A diagram illustrating the approximate dimensions of the RASTAR Ferrari LaFerrari Die-Cast Model, showing length, width, and height measurements.

WARRANTY AND SUPPORT

For warranty information or technical support, please contact RASTAR customer service. Details regarding specific warranty periods and support channels are typically provided with the product packaging or on the official RASTAR website.

You can visit the official RASTAR store for more information:[RASTAR Official Store](#)



