

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Energizer](#) /

› [Energizer 123 Photo Battery User Manual](#)

Energizer COMINU041474

Energizer 123 Photo Battery User Manual

Model: COMINU041474

INTRODUCTION

Thank you for choosing Energizer 123 Photo Batteries. These high-performance 3-volt lithium batteries are designed to provide reliable power for a variety of devices, including film cameras, high-end flashlights, and medical equipment. This manual provides essential information for the safe and effective use of your Energizer 123 batteries.

IMPORTANT SAFETY INFORMATION

WARNING: Improper use of batteries may result in leakage, fire, or explosion, causing personal injury or product damage. Please read and follow all instructions carefully.

- Keep batteries out of reach of children and pets. Swallowing can lead to serious injury or death.
- Do not recharge, disassemble, crush, heat, or incinerate batteries.
- Do not expose batteries to water or extreme temperatures.
- Insert batteries correctly, observing the positive (+) and negative (-) polarity markings.
- Do not mix old and new batteries, or different types of batteries.
- Remove depleted batteries promptly from devices.
- If a battery leaks, avoid contact with skin and eyes. If contact occurs, flush with plenty of water and seek medical attention.

SETUP AND INSTALLATION

Energizer 123 Photo Batteries are designed for easy installation in compatible devices.

1. Identify the battery compartment on your device (e.g., camera, flashlight).
2. Open the battery compartment cover.
3. Observe the polarity markings (+ and -) inside the compartment.
4. Insert the Energizer 123 battery, ensuring the positive (+) end aligns with the positive terminal and the negative (-) end aligns with the negative terminal.

5. Close the battery compartment cover securely.



Image: Energizer 123 Photo Battery packaging, showing a 24-count pack. The batteries are typically used in film cameras, high-end flashlights, and medical devices.

OPERATING INSTRUCTIONS

Once properly installed, Energizer 123 Photo Batteries will power your device. These are single-use batteries and are not rechargeable.

- Ensure your device is turned off before installing or removing batteries.
- Refer to your device's manual for specific operating instructions related to battery usage.
- Replace all batteries in a set at the same time to ensure optimal performance and prevent leakage.

MAINTENANCE AND STORAGE

Proper maintenance and storage can extend the shelf life of your Energizer 123 batteries.

- Store unused batteries in their original packaging in a cool, dry place at room temperature.
- Avoid storing batteries with metal objects (like coins or keys) to prevent short-circuiting.
- Do not store batteries in direct sunlight or in places with high humidity.

TROUBLESHOOTING

If your device is not functioning after installing new batteries, consider the following:

- **Check Polarity:** Ensure batteries are inserted with the correct positive (+) and negative (-) orientation.
- **Battery Contact:** Verify that the battery terminals are clean and making proper contact with the device's contacts.
- **Device Functionality:** Test the device with another set of known good batteries to rule out a device malfunction.
- **Battery Condition:** Although new, inspect batteries for any visible damage or signs of leakage.

SPECIFICATIONS

Feature	Detail
Model Number	COMINU041474
Battery Type	CR123A Lithium Manganese Dioxide
Voltage	3 Volts
Reusability	Single Use (Non-rechargeable)
Typical Applications	Film cameras, high-end flashlights, medical devices
Manufacturer	Energizer Batteries
Package Dimensions	4.7 x 3.8 x 1.5 inches
Item Weight (per pack)	0.1 Kilograms (approx. 3.53 ounces)

DISPOSAL INFORMATION

Do not dispose of batteries in household waste. Lithium batteries should be disposed of responsibly to prevent environmental harm and potential safety hazards.

- Check local regulations for proper battery recycling and disposal options.
- Many retail stores and community centers offer battery recycling drop-off points.
- For more information, visit the Energizer website or contact your local waste management facility.

WARRANTY AND SUPPORT

Energizer stands behind the quality of its products. For specific warranty information or technical support regarding your Energizer 123 Photo Batteries, please refer to the official Energizer website or contact their customer service directly.

Manufacturer: Energizer Batteries

For further assistance, please visit: www.energizer.com