



Manuals.plus /

› VI VINTRONS /

› VI VINTRONS Replacement Li-ion Battery User Manual for Panasonic NV-MX1000 Camcorders

VI VINTRONS NV-MX1000

VI VINTRONS Replacement Li-ion Battery User Manual

For Panasonic NV-MX1000 and Compatible Camcorder Models

1. INTRODUCTION

Thank you for choosing the VI VINTRONS Replacement Li-ion Battery. This manual provides essential information for the safe and effective use, installation, and maintenance of your new battery. Please read this manual thoroughly before using the product.

This battery is designed as a high-capacity replacement for various Panasonic camcorder models, including the NV-MX1000, offering reliable power for your device.

2. IMPORTANT SAFETY INFORMATION

To prevent personal injury or damage to your battery and device, always observe the following safety precautions:

- Do not disassemble, open, or shred the battery pack.
- Do not expose the battery to heat or fire. Avoid storage in direct sunlight.
- Do not short-circuit the battery. Do not store battery packs haphazardly in a box or drawer where they may short-circuit each other or be short-circuited by other metal objects.
- Do not remove the battery from its original packaging until required for use.
- Do not subject battery packs to mechanical shock.
- In the event of a battery leaking, do not allow the liquid to come into contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice.
- Do not use any charger other than that specifically provided for use with the equipment.
- Observe the plus (+) and minus (-) marks on the battery and equipment and ensure correct use.
- Do not use any battery pack which is not designed for use with the equipment.
- Keep battery packs out of the reach of children.
- Seek medical advice immediately if a battery pack has been swallowed.

- Always purchase the correct battery pack for the equipment.
- Keep battery packs clean and dry.
- Wipe the battery pack terminals with a clean dry cloth if they become dirty.
- Rechargeable battery packs must be charged before use. Always use the correct charger and refer to the manufacturer's instructions or equipment manual for proper charging instructions.
- Do not leave a rechargeable battery pack on charge when not in use.
- Do not dispose of batteries in household waste. Dispose of used batteries promptly according to local regulations.

3. SETUP AND INITIAL USE

3.1 Unpacking

Carefully remove the battery from its packaging. Inspect the battery for any visible damage. If any damage is observed, do not use the battery and contact customer support.



Image 1: Front view of the VI VINTRONS replacement battery.

3.2 Initial Charging

For optimal performance, it is recommended to fully charge the battery before its first use. Use a compatible Panasonic charger or a universal charger designed for this battery type. Refer to your camcorder's manual or charger's instructions for specific charging procedures.



Image 2: Rear view of the battery showing the information label.

3.3 Installation

Ensure your camcorder is powered off before installing or removing the battery. Locate the battery compartment on your Panasonic camcorder. Align the battery with the compartment's terminals and slide it in until it clicks securely into place. Refer to your camcorder's user manual for precise installation steps.



Image 3: Side view of the battery, illustrating its form factor.

4. OPERATING INSTRUCTIONS

4.1 Charging the Battery

Connect your camcorder or external battery charger to a power source. Insert the battery into the charger or camcorder. The charging indicator light on your device or charger will typically show the charging status. A full charge may take several hours depending on the charger and battery's depleted state.

4.2 Battery Life and Performance

The battery's operating time will vary based on camcorder usage, settings (e.g., LCD brightness, recording quality), and environmental conditions. For optimal battery life, avoid frequently draining the battery completely or overcharging it for extended periods.

5. MAINTENANCE AND STORAGE

5.1 General Care

Keep the battery terminals clean and free from dust or debris. Use a dry, soft cloth to wipe the battery if it becomes dirty. Do not use harsh chemicals or abrasive cleaners.

5.2 Storage

If storing the battery for an extended period, charge it to approximately 50-60% capacity. Store it in a cool, dry place away from direct sunlight and extreme temperatures. Avoid storing fully charged or fully depleted

batteries for long durations, as this can reduce their lifespan.

6. TROUBLESHOOTING

- **Battery Not Charging:** Ensure the battery is correctly inserted into the charger or camcorder. Verify that the charger is properly connected to a power source. Check for any visible damage to the battery or charger.
- **Short Operating Time:** Battery capacity naturally degrades over time. Ensure the battery is fully charged before use. Extreme temperatures can also affect battery performance.
- **Battery Not Recognized by Camcorder:** Ensure the battery is securely installed. Power cycle the camcorder (turn off, remove battery, reinsert, turn on).

If problems persist, refer to your camcorder's manual or contact VI VINTRONS customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	VI VINTRONS
Battery Type	Lithium-Ion (Li-ion)
Voltage	7.4V
Capacity	5400mAh (5.4 Ah)
Dimensions (L x W x H)	59.48 x 36.25 x 69.81 mm
Weight	Approximately 242 Grams
Reusability	Rechargeable
ASIN	B00XKO6XLS

7.1 Compatible Panasonic Camcorder Models

- AG-DVC180A, AG-DVC30, AG-DVC30E, AG-DVC32, AG-DVC33, AG-DVC60, AG-DVC60E, AG-DVC62, AG-DVC63, AG-DVC80
- AG-DVX100, AG-DVX100A, AG-DVX100AE, AG-DVX100AP, AG-DVX100B, AG-DVX100BE, AG-DVX100BP, AG-DVX100E, AG-DVX102A, AG-DVX102B
- AG-HVX200, AG-HVX200P
- AJ-PCS060G (Portable Hard Disk Unit)
- NV-DS29, NV-DS29EG, NV-DS30, NV-DS30A, NV-DS30EG, NV-DS50A
- NV-GX7, NV-GX7K
- NV-MX1000, NV-MX2500, NV-MX350, NV-MX350A, NV-MX350B, NV-MX350EN, NV-MX5, NV-MX500, NV-MX5000, NV-MX500EG, NV-MX500EN

7.2 Compatible Panasonic Battery Part Numbers

- CGA-D54, CGA-D54S, CGA-D54SE, CGA-D54SE/1B, CGA-D54SE/1H
- CGP-D54S, CGR-D54S
- VW-VBD55

8. WARRANTY INFORMATION

VI VINTRONS products are manufactured to high-quality standards. For specific warranty terms and conditions, please refer to the product packaging or the official VI VINTRONS website. Keep your proof of purchase for warranty claims.

9. CUSTOMER SUPPORT

If you have any questions, concerns, or require technical assistance, please contact VI VINTRONS customer support. Contact information can typically be found on the product packaging or the official VI VINTRONS website.