Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Michael Kors /
- Michael Kors Women's Watch MK6225 User Manual

Michael Kors MK6225

Michael Kors Women's Watch MK6225

USER INSTRUCTION MANUAL

Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your Michael Kors Women's Watch, model MK6225. Please read this guide thoroughly to ensure proper use and care of your timepiece.

Setup

1. Unboxing and Initial Inspection

Carefully remove the watch from its packaging. Inspect the watch for any visible damage or irregularities. Ensure all protective films are removed from the crystal and case back.

2. Setting the Time

- 1. **Pull out the crown:** Gently pull the crown (the small knob on the side of the watch case) to its outermost position. You may feel a slight click.
- 2. **Adjust the time:** Rotate the crown clockwise or counter-clockwise to move the hour and minute hands to the correct time.
- 3. **Push in the crown:** Once the time is set, push the crown back into its original position against the watch case. This will start the watch movement.



Image: Side view of the Michael Kors MK6225 watch, highlighting the crown used for time adjustment.

3. Bracelet Adjustment

The metal bracelet of your watch may require adjustment to fit your wrist comfortably. It is recommended to have this procedure performed by a qualified jeweler or watch technician to avoid damage to the bracelet or watch case.

Operating

Basic Timekeeping

Once the time is set and the crown is pushed in, your Michael Kors MK6225 watch will continuously display the current time. The watch operates on a quartz movement, powered by a lithium metal battery.



Image: Front view of the Michael Kors MK6225 watch, showcasing its purple dial, crystal accents, and rose gold-tone stainless steel bracelet.

Maintenance

1. Cleaning Your Watch

- Wipe the watch case and bracelet with a soft, dry, lint-free cloth regularly to remove dust and fingerprints.
- For more thorough cleaning, a slightly damp cloth can be used, followed immediately by a dry cloth. Avoid using harsh chemicals, solvents, or abrasive cleaners.

2. Water Resistance

While many watches offer some level of water resistance, it is generally recommended to avoid prolonged exposure to water, such as swimming or showering, unless specifically stated otherwise for your model. Always ensure the crown is fully pushed in to maintain any water resistance rating.

3. Battery Replacement

The watch is powered by a Lithium Metal battery. When the watch stops running, it indicates the battery needs replacement. It is highly recommended to have the battery replaced by an authorized Michael Kors service center or a professional watchmaker to ensure proper sealing and functionality.

4. Storage

When not wearing your watch, store it in a cool, dry place, away from direct sunlight and extreme temperatures. The original watch box is ideal for storage.

Troubleshooting

- Watch not running: Ensure the crown is fully pushed in. If it is, the battery may need replacement.
- **Inaccurate time:** Reset the time as described in the 'Setup' section. If the issue persists, the battery may be low, or the watch may require servicing.
- Condensation under crystal: This indicates a potential breach in water resistance. Seek professional service immediately.

Specifications

Feature	Detail
Brand	Michael Kors
Model Number	MK6225
Material	Stainless Steel
Product Dimensions	10.01 x 10.01 x 5 cm
Item Weight	118.2 g
Batteries	1 Lithium Metal battery (included)
Movement Type	Quartz

Warranty and Support

For information regarding warranty coverage, service, or repairs, please refer to the warranty card included with your purchase or visit the official Michael Kors website. Contacting Michael Kors customer support directly is recommended for any specific product inquiries or assistance.

