

[Manuals.plus](#) /

› [UPBRIGHT](#) /

› UpBright 26V AC Adapter Instruction Manual for ORFELD Cordless Vacuum Cleaners

UPBRIGHT RK-2650500, ZD12D270050US

UpBright 26V AC Adapter Instruction Manual

For ORFELD Cordless Vacuum Cleaners (Models H20A, EV-660, EV-679, RB666, RB680)

INTRODUCTION

This manual provides essential instructions for the safe and effective use of your UpBright 26V AC/DC Adapter. This adapter is designed to provide power and charge compatible ORFELD cordless stick vacuum cleaners. Please read this manual thoroughly before use and retain it for future reference.



Figure 1: UpBright 26V AC Adapter. This image displays the UpBright 26V AC adapter, featuring a standard US two-prong plug on one end and a barrel connector on the other, connected by a black cable.

PRODUCT COMPATIBILITY

This UpBright AC adapter is compatible with various ORFELD cordless stick vacuum cleaner models. It is crucial to verify your vacuum cleaner's model number to ensure compatibility.

- ORFELD Model H20A
- ORFELD EV-660 (EV660)
- ORFELD EV-679 (EV679)
- ORFELD RB666
- ORFELD RB680
- And other models requiring a 26V-27V DC 0.5A power supply with a barrel connector.

Important Note:

This adapter is designed for direct charging of the vacuum cleaner. It is **NOT** compatible with charging dock stations. Please ensure your vacuum cleaner has a direct charging port suitable for a barrel connector.

UpBright AC Adapter Power Supply Compatible with:




Figure 2: Compatible ORFELD Vacuum Cleaners. This image illustrates several models of ORFELD cordless stick vacuum cleaners, including the H20A and EV-679, demonstrating the range of devices compatible with this UpBright AC adapter.

SETUP AND CONNECTION

1. **Inspect the Adapter:** Before connecting, visually inspect the adapter and its cable for any signs of damage. Do not use if damaged.
2. **Identify Charging Port:** Locate the charging port on your ORFELD cordless vacuum cleaner. This port is typically a circular input designed for a barrel connector.
3. **Connect Adapter to Vacuum:** Gently insert the barrel connector end of the UpBright adapter into the charging port of your vacuum cleaner. Ensure a snug fit.
4. **Connect to Power Outlet:** Plug the AC adapter's two-prong plug into a standard wall power outlet (100-240VAC, 50/60Hz).
5. **Verify Connection:** Some vacuum cleaners may have an indicator light to show that charging has begun. Refer to your vacuum cleaner's manual for specific charging indicators.



Figure 3: Barrel Connector. A detailed view of the barrel connector, which is the output plug of the UpBright AC adapter, designed to connect to compatible vacuum cleaners.

OPERATING INSTRUCTIONS

Once properly connected, the adapter will begin supplying power to your vacuum cleaner, either for direct operation (if supported by the vacuum) or for charging its internal battery.

- **Charging:** Allow sufficient time for your vacuum cleaner's battery to fully charge. Charging times vary depending on the vacuum model and battery capacity. Refer to your vacuum cleaner's manual for estimated charging durations.
- **Safety During Use:** Ensure the adapter is placed in a well-ventilated area during operation and charging. Avoid covering the adapter, as this can lead to overheating.
- **Disconnection:** Once charging is complete or if you need to disconnect the vacuum, first unplug the adapter from the wall outlet, then disconnect the barrel connector from the vacuum cleaner.

MAINTENANCE AND CARE


- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the adapter. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and moisture. Avoid tightly winding the cable to prevent damage.
- **Cable Care:** Do not bend, twist, or pull the cable excessively. Avoid placing heavy objects on the cable. Regularly check the cable for any cuts, fraying, or exposed wires.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Adapter not charging the vacuum.	◦ Loose connection. ◦ Power outlet not active. ◦ Incompatible vacuum model. ◦ Damaged adapter or cable. ◦ Vacuum battery issue.	◦ Ensure all connections are secure. ◦ Test the power outlet with another device. ◦ Verify your vacuum model is listed as compatible. ◦ Inspect adapter and cable for damage; replace if necessary. ◦ Note: Rechargeable batteries have a limited lifespan (typically 1-3 years). An old or faulty battery may not accept a charge, which is not an adapter issue.
Adapter feels warm during use.	◦ Normal operation. ◦ Poor ventilation.	◦ A slight warmth is normal. ◦ Ensure the adapter is in a well-ventilated area and not covered. If it becomes excessively hot, disconnect immediately and contact support.

Security Protection

Multiple professional protection, so that fast
Charge more safe



Good heat
Resistance



VO-Grade
Fire-Retardant



Overcharge
Protection



Overvoltage
Protection



Overheat
Protection



Overcurrent
Protection

Figure 4: Security Protection Features. A cutaway diagram of the UpBright AC adapter highlighting its internal components and various safety features such as good heat resistance, fire-retardant materials, overcharge, overvoltage, overheat, and overcurrent protection.

SPECIFICATIONS

- **Input Voltage:** 100-240VAC, 50/60Hz (Worldwide Compatible)
- **Output Voltage:** 26V - 27V DC
- **Output Current:** 0.5A (500mA)
- **Connector Type:** Barrel Connector
- **Protection Features:**
 - OVP (Over Voltage Output Protection)
 - OCP (Over Current Output Protection)
 - SCP (Short Circuit Output Protection)
- **Product Dimensions:** Approximately 4 x 3 x 2 inches
- **Item Weight:** Approximately 2.89 ounces
- **Model Identifiers:** RK-2650500, ZD12D270050US

WARRANTY AND SUPPORT

Your UpBright AC Adapter comes with a limited warranty:

- **Refund Policy:** 30 Days Refund
- **Exchange Policy:** 24 Months Exchange

For warranty claims, technical assistance, or any questions regarding your UpBright AC Adapter, please contact the seller or manufacturer directly through your purchase platform. Ensure you have your order details and product model identifiers (RK-2650500, ZD12D270050US) available when seeking support.

Come With A Suitable Outlet Adapter (Only One) to Fit Your Country/Area For International Order




Figure 5: International Adapters and Warranty. This image displays three different international outlet adapters (AU, EU, UK) that may be included with the product for international orders, alongside a sample UpBright Limited Warranty Certificate.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00XMA4M3Q>

More documents and user manuals: <https://manuals.plus/>