

[Manuals.plus](#) /

› [Sachtler](#) /

› Sachtler Dr. Bag - 4 Camera Bag User Manual

Sachtler SC004

Sachtler Dr. Bag - 4 Camera Bag User Manual

Model: SC004 | Brand: Sachtler

1. INTRODUCTION

The Sachtler Dr. Bag - 4 is a professional camera bag engineered for the secure transport and protection of DSLR, Reflex, and Mirrorless camera setups. Its design accommodates cameras with attached accessories such as matte boxes and microphones, ensuring equipment is both safe and readily accessible. This manual provides essential information for the proper setup, operation, and maintenance of your Dr. Bag - 4.

2. PRODUCT OVERVIEW

2.1. Exterior Features



Figure 1: Exterior view of the Sachtlar Dr. Bag - 4. This image displays the bag's robust black fabric construction, ergonomic top handle, side pockets, and the Sachtlar logo. The overall design emphasizes durability and ease of transport.

The Dr. Bag - 4 features a durable exterior shell designed to withstand the rigors of travel. It includes an ergonomic carrying handle for comfortable lifting and side pockets for additional storage of smaller accessories. The bag's construction incorporates cold-molded laminate panels, providing enhanced protection against impacts.

2.2. Interior Features



Figure 2: Interior view of the Sachtler Dr. Bag - 4, showcasing a camera with attached lens and microphone, along with other accessories, organized by the removable internal dividers. The bright red interior lining enhances visibility of contents.

The interior of the Dr. Bag - 4 is characterized by its extra-wide opening, facilitating easy access to equipment. It is equipped with removable internal rigid dividers, allowing for custom configuration to secure various camera setups. An internal LED lighting system is integrated to illuminate the contents, aiding visibility in dimly lit environments.

- **Extra-Wide Opening:** Provides convenient access to your camera and attached accessories.
- **Safe Shell Protection:** Cold-molded laminate panels offer robust protection for delicate equipment.
- **Customizable Interior:** Removable rigid dividers allow for flexible organization of gear.
- **Internal LED Lighting:** Enhances visibility of contents in low-light conditions.
- **Travel-Friendly Design:** Features an ergonomic handle and compatibility with the Snaplock Trolley System.

3. SETUP

3.1. Adjusting Internal Dividers

1. Open the main zipper to fully expose the bag's interior.
2. Identify the hook-and-loop fasteners on the internal rigid dividers.
3. Carefully detach the dividers from their current positions.
4. Arrange the dividers to create compartments that securely fit your camera, lenses, and accessories. Ensure snug but not overly tight placement to prevent movement during transport.
5. Press firmly on the hook-and-loop fasteners to secure the dividers in their new configuration.

3.2. Attaching the Shoulder Strap

1. Locate the D-rings on either end of the bag.
2. Attach the swivel clips of the padded shoulder strap to these D-rings.
3. Adjust the length of the shoulder strap using the buckle to achieve a comfortable carrying position.

4. OPERATING INSTRUCTIONS

4.1. Packing Your Equipment

- Utilize the extra-wide opening to place your camera, even with a matte box and microphone attached, directly into its designated compartment.
- Ensure all equipment is nestled securely within the padded dividers to prevent shifting.
- Close the main zipper completely to secure the contents.

4.2. Using the Internal LED Lighting

- Locate the power switch for the internal LED lighting, typically found near the top interior of the bag.
- Toggle the switch to activate the LED lights, providing illumination for easy viewing of contents in dark or dimly lit environments.
- Remember to turn off the LED lights when not in use to conserve battery life.

4.3. Carrying Options

- **Ergonomic Handle:** For short distances or quick transfers, use the padded top handle.
- **Padded Shoulder Strap:** For hands-free carrying, utilize the adjustable shoulder strap.
- **Snaplock Trolley System Compatibility:** The bag is designed for easy connection with Sachtler's Snaplock Trolley System (sold separately) for convenient transport over longer distances.

5. MAINTENANCE

- **Cleaning the Exterior:** Wipe the exterior fabric with a damp cloth and mild soap solution. Avoid harsh chemicals.
- **Cleaning the Interior:** Use a soft brush or vacuum cleaner to remove dust and debris from the interior lining and dividers. Spot clean with a damp cloth as needed.
- **Storage:** Store the bag in a cool, dry place away from direct sunlight when not in use.

6. TROUBLESHOOTING

6.1. Internal LED Light Not Functioning

- **Check Battery:** Ensure the batteries powering the LED light are correctly installed and have sufficient charge. Replace if necessary.
- **Check Switch:** Verify that the LED light switch is in the 'ON' position.
- If the issue persists after checking these points, contact Sachtler customer support.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	12.99 x 24.41 x 15.16 inches (33 x 62 x 38.5 cm)
Item Weight	8.36 pounds (3.8 kg)
Model Number	SC004

Feature	Detail
ASIN	B00XQQ8FXO
Manufacturer	Vitec Group
Date First Available	May 16, 2015

8. WARRANTY AND SUPPORT

For detailed information regarding the product warranty, please refer to the official Sachtler website or the warranty card included with your purchase. For technical support, spare parts, or service inquiries, please contact Sachtler customer service directly through their official channels.

© 2023 Sachtler. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question