

## Husqvarna 532175067

# Husqvarna 532175067 Clutch Cable Kit: Riding Lawn Mower Instruction Manual

Model: 532175067

## 1. INTRODUCTION

This manual provides essential information for the safe and effective installation, operation, and maintenance of your Husqvarna 532175067 Clutch Cable Kit. This manufacturer-approved clutch cable is designed to engage and disengage the blades on your riding lawn mower, ensuring proper functionality and safety during operation.

## 2. SAFETY INFORMATION

Always prioritize safety when working with power equipment. Failure to follow these safety guidelines may result in serious injury or damage to the equipment.

- Disconnect Power:** Before performing any maintenance or installation, ensure the lawn mower engine is off and the spark plug wire is disconnected to prevent accidental starting.
- Wear Protective Gear:** Always wear appropriate personal protective equipment, including safety glasses, gloves, and sturdy footwear.
- Read Mower Manual:** Consult your riding lawn mower's owner's manual for specific safety instructions and procedures related to your model.
- Secure the Mower:** When working underneath the mower deck, ensure the mower is stable and securely supported to prevent it from tipping.
- Sharp Blades:** Mower blades are extremely sharp. Handle them with extreme caution and wear heavy-duty gloves.

## 3. PACKAGE CONTENTS

The Husqvarna 532175067 Clutch Cable Kit includes the following components:

- One (1) OEM Clutch Cable (approximately 45 inches long)
- One (1) Spring
- Additional components as part of the kit (e.g., zip ties, bolt, as shown in product images)



Figure 1: Components of the Husqvarna 532175067 Clutch Cable Kit, including the cable, spring, and other small parts.

## 4. COMPATIBILITY

This clutch cable kit is a direct replacement for Husqvarna riding lawn mowers and is also compatible with various models from other brands that use the following part numbers:

- Husqvarna: 532175067
- Replaces part numbers: 169676, 532169676, 21547184
- Commonly used on 42-inch deck riding lawn mowers.

Always verify compatibility with your specific mower model number before installation.

## 5. INSTALLATION INSTRUCTIONS

Follow these steps to replace the clutch cable on your riding lawn mower. Refer to your mower's service manual for model-specific details.

### 5.1. Preparation

1. **Park Safely:** Park the lawn mower on a flat, level surface.
2. **Turn Off Engine:** Ensure the engine is completely off and cool.
3. **Disconnect Spark Plug:** Disconnect the spark plug wire to prevent accidental starting.
4. **Remove Ignition Key:** If applicable, remove the ignition key.
5. **Engage Parking Brake:** Set the parking brake.
6. **Gather Tools:** You will typically need a wrench set, pliers, and work gloves.

## 5.2. Removing the Old Cable

7. **Access the Cable:** Depending on your mower model, you may need to open the main hood or remove covers to access the clutch cable assembly.
8. **Remove Mower Deck (if necessary):** For some models, it may be easier to remove the mower deck to gain full access to the cable connections. Consult your mower's manual.
9. **Disconnect Cable from Lever Bracket:** Locate where the cable connects to the blade engagement lever bracket. Disconnect the black knob at the end of the cable from the lever.
10. **Release Cable from Deck:** Follow the cable down to the mower deck. Release the cable from any retaining clips or brackets on the deck.
11. **Disconnect Spring:** Locate the spring at the end of the cable connected to the idler arm or similar mechanism. Carefully unhook the spring.
12. **Remove Old Cable:** Once all connections are released, carefully pull the old cable out from the mower.

## 5.3. Installing the New Cable

13. **Feed New Cable:** Route the new clutch cable through the same path as the old one, ensuring it is free from kinks and obstructions.
14. **Connect Spring:** Slide the new spring over the retaining bolt and hook it into place on the idler arm or designated attachment point.
15. **Secure Cable to Deck:** Push the cable retainer into the deck bracket, securing the cable along the mower deck.
16. **Connect Cable to Lever Bracket:** Install the black knob at the end of the cable onto the lever bracket, ensuring it snaps securely into place.
17. **Reinstall Mower Deck (if removed):** If you removed the mower deck, reinstall it according to your mower's manual.
18. **Reconnect Spark Plug:** Reconnect the spark plug wire.

[REDACTED]  
**Video 1:** A visual guide demonstrating the components and installation steps for a deck engagement clutch cable, including routing and connection points.

[REDACTED]  
**Video 2:** This video illustrates the assembly of the 175067 deck clutch cable, showing how the spring and cable components fit together.

[REDACTED]  
**Video 3:** Demonstrates the installation of a lawn mower cable on a riding mower, highlighting key connection points and routing.

## 6. OPERATING INSTRUCTIONS

The clutch cable is an integral part of your mower's blade engagement system. After successful installation, operate your mower as follows:

- **Start Engine:** Start the mower engine according to your mower's operating instructions.
- **Engage Blades:** To engage the mower blades, move the blade engagement lever to the "ON" or "ENGAGE" position. The new clutch cable will transmit this action to the mower deck, causing the blades to spin.
- **Disengage Blades:** To disengage the blades, move the lever to the "OFF" or "DISENGAGE" position. The blades should stop spinning within a few seconds.
- **Test Functionality:** Before mowing, test the blade engagement and disengagement in a clear area to ensure proper operation.

## 7. MAINTENANCE

Regular maintenance helps extend the life of your clutch cable and ensures safe mower operation:

- **Inspect Regularly:** Periodically inspect the clutch cable for signs of wear, fraying, kinks, or damage. Check the spring for proper tension and any deformation.
- **Clean:** Keep the cable and its connection points free from dirt, grass clippings, and debris.
- **Lubricate:** Apply a light lubricant to the cable ends and pivot points as recommended by your mower's manufacturer to ensure smooth operation.
- **Replace if Damaged:** If the cable shows significant wear or damage, replace it immediately to prevent operational issues or safety hazards.

## 8. TROUBLESHOOTING

If you encounter issues with your blade engagement system after installing the new clutch cable, consider the following:

- **Blades Not Engaging:**

- Check if the cable is properly connected at both the lever and the mower deck.
- Ensure the spring is correctly attached and providing tension.
- Verify that the cable is not kinked or obstructed along its path.

- **Blades Not Disengaging:**

- Inspect the cable for any binding or excessive friction.
- Ensure the lever mechanism moves freely.
- Check if the spring is stretched or damaged, preventing full disengagement.

- **Excessive Slack or Tightness:**

- Some cables may have adjustment points. Consult your mower's manual for specific adjustment procedures.
- Ensure the cable length is appropriate for your mower model.


## 9. SPECIFICATIONS

Brand	Husqvarna
Model Number	532175067
Cable Length	Approximately 45 inches
Item Weight	9.6 ounces
Product Dimensions	5 x 1.5 x 6.7 inches
Replaces OEM Part Numbers	169676, 532169676, 21547184

## 10. WARRANTY AND SUPPORT

For warranty information or technical support regarding your Husqvarna 532175067 Clutch Cable Kit, please refer to the documentation provided with your original purchase or contact Husqvarna customer service directly. Keep your proof of purchase for any warranty claims.


### Related Documents - 532175067

	<p><a href="#"><u>Husqvarna CEORA Robotic Lawn Mower Quick Guide - Installation &amp; Operation</u></a></p> <p>Comprehensive quick guide for the Husqvarna CEORA robotic lawn mower. Learn about EPOS technology, system components, connectivity via Automower® Connect and Husqvarna Fleet Services™, and step-by-step installation for work areas, stay-out zones, and transport paths.</p>
	<p><a href="#"><u>Husqvarna Automower® 435X AWD Operator's Manual</u></a></p> <p>This operator's manual provides comprehensive instructions for the Husqvarna Automower® 435X AWD robotic lawn mower, covering installation, operation, maintenance, safety, and troubleshooting.</p>
	<p><a href="#"><u>Husqvarna GTH26K54 Owner's Manual: Safe Operation, Maintenance, and Assembly Guide</u></a></p> <p>Comprehensive owner's manual for the Husqvarna GTH26K54 riding lawn mower, covering safety rules, assembly, operation, maintenance, troubleshooting, and warranty information. Essential guide for optimal performance and care.</p>
	<p><a href="#"><u>Husqvarna LE 322R Operator's Manual</u></a></p> <p>Comprehensive operator's manual for the Husqvarna LE 322R walk-behind lawn mower, covering safety, assembly, operation, and maintenance. Learn how to safely and effectively use your Husqvarna lawn mower.</p>



[Husqvarna MZ 52LE / MZ52 Zero Turn Mower Operator Manual](#)

This operator manual provides essential information for the Husqvarna MZ 52LE and MZ52 Zero Turn Mower. It covers safe operation, controls, maintenance procedures, troubleshooting, and technical data to ensure optimal performance and longevity of your Husqvarna mower. Model number: 967277404-01.



[Husqvarna Aspire LC34-P4A Operator's Manual](#)

Comprehensive operator's manual for the Husqvarna Aspire LC34-P4A lawn mower, covering safety, assembly, operation, maintenance, and troubleshooting.