

IKEA MOSHULT

IKEA MOSHULT Foam Mattress (140x200cm) User Manual

1. PRODUCT OVERVIEW

The IKEA MOSHULT foam mattress provides uniform body support with its elastic foam core. Designed for comfort and practicality, it features a removable, machine-washable cover for easy maintenance. This mattress is suitable for various users, including children, thanks to its child-safe zipper design.

- **Dimensions:** Length: 200 cm; Width: 140 cm; Thickness: 10 cm.
- **Material:** Mattress ticking: 64% cotton, 36% polyester. Comfort material: polyester wadding, lining: non-woven polypropylene. Comfort material: polyether 28 kg/m³.
- **Support:** Elastic foam provides even body support.
- **Maintenance:** Easy to clean with a removable, machine-washable cover.
- **Packaging:** Rolled for convenient transport; regains original shape within 3-4 days after unpacking.



Image 1.1: A close-up view of the corner of the IKEA MOSHULT foam mattress, showing the white quilted cover and the

2. SETUP AND UNPACKING

1. **Transport:** The mattress is rolled and packaged, making it easy to transport home.
2. **Unpacking:** Carefully remove the outer packaging.
3. **Placement:** Place the rolled mattress on a flat, clean surface, preferably on the bed frame where it will be used.
4. **Unrolling:** Unroll the mattress. It will begin to expand.
5. **Expansion Time:** Allow 3 to 4 days for the mattress to fully regain its original shape and firmness after unpacking. During this time, it is normal for the mattress to gradually expand.

3. USAGE AND OPERATION

The MOSHULT foam mattress is designed to provide a firm and even sleeping surface. Its elastic foam adapts to your body, offering consistent support across the entire mattress. For optimal performance and safety, always use the mattress with a suitable slatted bed base.

- **Support:** The foam core is engineered to distribute body weight evenly, promoting a comfortable sleep posture.
- **Compatibility:** This mattress is compatible with most standard bed frames and slatted bases of corresponding dimensions (140x200cm).
- **Child-Safe Zipper:** The mattress cover features a child-safe zipper, designed without small parts to prevent children from opening the cover.

4. MAINTENANCE AND CARE INSTRUCTIONS

Proper care extends the life of your mattress and ensures a hygienic sleeping environment. The MOSHULT mattress cover is designed for easy cleaning.

Mattress Cover Care:

- **Washing:** Machine wash, normal cycle (60°C).
- **Bleaching:** Do not bleach with chlorine.
- **Drying:** Do not tumble dry.
- **Ironing:** Do not iron.
- **Dry Cleaning:** Do not dry clean.

To remove the cover, locate the child-safe zipper along the edge of the mattress. Unzip carefully before washing.

5. SAFETY INFORMATION

Adhering to safety guidelines ensures the longevity of your mattress and your well-being.

- **Slatted Bed Base Requirement:** **Never use the mattress without a suitable slatted bed base.** The slatted base provides essential support and ventilation for the mattress.
- **Child-Safe Zipper:** The zipper on the mattress cover is designed to be child-safe, containing no small parts that could be a choking hazard. This design prevents children from easily opening the cover.
- **Ventilation:** Ensure adequate air circulation around and under the mattress to prevent moisture buildup.

6. SPECIFICATIONS

| | |
|----------------------|--|
| Brand | IKEA |
| Model Name | MOSHULT |
| Product Dimensions | 200 cm (Length) x 140 cm (Width) x 10 cm (Thickness) |
| Color | White |
| Firmness Description | Hard (Firm) |
| Cover Material | 64% Cotton, 36% Polyester blend |
| Filling Material | Polyether foam (28 kg/m3) |
| Number of Layers | 3 (foam, wadding, lining) |
| Special Features | Foldable (for transport), Removable/Washable Cover |
| ASIN | B00XTPFQ3E |

7. TROUBLESHOOTING

The IKEA MOSHULT foam mattress is designed for simplicity and durability. Most common issues are related to initial setup or improper care.

- **Mattress not fully expanded:** Allow 3-4 days after unpacking for the mattress to fully regain its shape. Ensure it is placed on a flat surface.
- **Uneven support:** Ensure the mattress is placed on a suitable, evenly supported slatted bed base. Avoid using it directly on the floor or on an unsuitable base.
- **Cover difficult to remove/attach:** Ensure the mattress is completely flat when attempting to remove or attach the cover. The child-safe zipper requires careful handling.
- **Odor:** A new mattress may have a slight odor upon unpacking. This is normal and will dissipate within a few days in a well-ventilated room.

8. WARRANTY AND SUPPORT

For information regarding warranty coverage or if you require further assistance with your IKEA MOSHULT foam mattress, please refer to your purchase receipt or visit the official IKEA website. You can also contact IKEA customer service directly for support.

- **IKEA Website:** www.ikea.com
- **Customer Service:** Refer to your local IKEA store's contact information.