

[Manuals.plus](#) /

> [Conair](#) /

> Conair for Men HCT7565RLIC Even Cut Hair Cut Kit Instruction Manual

Conair HCT7565RLIC

Conair for Men HCT7565RLIC Even Cut Hair Cut Kit Instruction Manual

Model: HCT7565RLIC

INTRODUCTION

The Conair for Men HCT7565RLIC Even Cut Hair Cut Kit is designed to provide professional short hairstyles at home with ease and precision. This kit includes an ultra-sharp hair clipper with circular blades for effortless cutting in any direction, along with a bonus trimmer for detailing necklines and sideburns. The precision-engineered Japanese steel blades ensure smooth, consistent results.



Image: The Conair Even Cut Hair Clipper, demonstrating its ergonomic design and compact size when held in hand.

IMPORTANT SAFETY INFORMATION

Attention: Using this device can cause skin or eye injury. Avoid use on babies. Do not use near water sources. Conduct regular cleaning and maintenance according to the instructions. Always read labels, warnings, and directions before using or consuming a product.

WHAT'S INCLUDED

Your Conair for Men HCT7565RLIC Even Cut Hair Cut Kit comes with the following components:

- Even Cut Hair Clipper (Lithium Ion Cord/Cordless)
- Bonus Trimmer (requires 2 AA batteries, not included)
- Multiple Comb Guides for various hair lengths
- Barber Comb
- Cleaning Brush
- Blade Oil
- Storage Pouch





Image: The main Even Cut Hair Clipper shown alongside the smaller bonus trimmer, highlighting the two primary tools in the kit.

SETUP

Initial Charging (Even Cut Hair Clipper)

1. Before first use, ensure the Even Cut Hair Clipper is fully charged. Connect the USB adapter and USB cable to the clipper and a power source.
2. A full charge provides approximately 3 hours of sustained power. The clipper can be used corded or cordless.

Oiling the Blades

1. Before each use, apply a few drops of the provided blade oil across the top and sides of the clipper blades.
2. Turn the clipper on for a few seconds to allow the oil to distribute evenly. This ensures smooth operation and prolongs blade life.

Installing Batteries (Bonus Trimmer)

- The bonus trimmer requires 2 AA batteries (not included). Insert them according to the polarity markings inside the battery compartment.

OPERATING INSTRUCTIONS

Using the Even Cut Hair Clipper

The Even Cut Hair Clipper features ultra-sharp circular blades that cut in any direction, making it ideal for achieving short, even styles. The unique Lock-In comb guide ensures your chosen length setting remains secure during use.



Image: The Conair Even Cut Hair Clipper with its circular comb guide, designed for consistent and even hair cutting.

1. **Select Comb Guide:** Choose the desired comb guide for your preferred hair length. The Lock-In feature prevents accidental changes during use.
2. **Power On:** Press the power button to turn on the clipper.
3. **Cutting Technique:** For an even cut, move the clipper in circular motions over your head, ensuring all areas are covered. The circular blades are designed to cut effectively from any angle.
4. **Taper Control:** Use the integrated taper control lever to adjust the closeness of the cut for blending and fading.



Image: A detailed top-down view of the Even Cut Hair Clipper, highlighting the circular blade mechanism and the attached comb guide.

Using the Bonus Trimmer

The bonus trimmer is perfect for refining your haircut, creating sharp necklines, and tidying up sideburns.

1. **Attach Guide Comb:** Select the 5-position guide comb for the trimmer to achieve your desired length for detailing.
2. **Power On:** Turn on the trimmer.
3. **Detailing:** Carefully trim around the ears, neckline, and sideburns. Use gentle, controlled movements for precise results.

MAINTENANCE

Cleaning

1. After each use, turn off and unplug the clipper.
2. Use the provided cleaning brush to remove any loose hairs from the blades and comb guides.
3. For thorough cleaning, detach the blade assembly if possible and brush away debris.

Oiling

1. Regular oiling is crucial for maintaining blade sharpness and preventing rust. Apply a few drops of the provided oil to the blades after every few uses or as needed.
2. Only use the oil specifically designed for hair clippers, such as the one provided in your kit.

TROUBLESHOOTING

If you encounter any issues with your Conair Even Cut Hair Cut Kit, please refer to the comprehensive user manual included with your product for detailed troubleshooting steps. For further assistance, contact Conair customer support.

SPECIFICATIONS

- **Model Number:** HCT7565RLIC
- **Brand:** Conair
- **Power Source:** Battery Powered (Lithium Ion Cord/Cordless)
- **Special Feature:** Cordless operation
- **Blade Material:** Alloy Steel (Precision engineered Japanese steel blades)
- **Color:** Red
- **Product Dimensions:** 13.34 x 20.32 x 24.13 cm; 730 g
- **Recommended Uses:** Body, Face, Head
- **Target Audience:** Men
- **UPC:** 068459140494

WARRANTY AND SUPPORT

The Conair for Men HCT7565RLIC Even Cut Hair Cut Kit comes with a **3 Years Limited Warranty** from the manufacturer. For warranty claims, product support, or any inquiries, please contact Conair customer service. The manufacturer's contact information is: EAST WINDSOR, NJ, 08520 US.