

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Hype](#) /

› [Hype Bluetooth Selfie Stick \(Model HY-SLF-BT-PNK\) Instruction Manual](#)

Hype HY-SLF-BT-PNK

Hype Bluetooth Selfie Stick Instruction Manual

Model: HY-SLF-BT-PNK

INTRODUCTION

Thank you for choosing the Hype Bluetooth Selfie Stick. This extendable wireless monopod is designed to help you capture self-portraits and group photos with ease. This manual provides essential information for the safe and efficient use of your device. Please read it thoroughly before operation and retain it for future reference.

SAFETY INFORMATION

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Keep the device away from water and other liquids.
- Do not attempt to disassemble or modify the device. This will void the warranty.
- Ensure your smartphone is securely mounted in the holder before extending the stick.
- Avoid using the selfie stick in crowded areas where it might cause injury to others.
- Keep out of reach of children.

PACKAGE CONTENTS

Please check the package contents upon opening to ensure all items are present:

- Hype Bluetooth Selfie Stick
- User Manual (this document)
- Charging Cable (if applicable, usually Micro USB) **Note:** The product description does not explicitly mention a charging cable, but Bluetooth devices typically require one.

PRODUCT OVERVIEW

Familiarize yourself with the components of your Hype Bluetooth Selfie Stick:

1. **Smartphone Holder:** Adjustable grip to secure your mobile device.

2. **Extendable Monopod:** Telescopic arm for varying lengths.
3. **Handle:** Ergonomic grip for comfortable holding.
4. **Bluetooth Shutter Button:** Integrated button on the handle to trigger your phone's camera.
5. **Charging Port:** (If rechargeable) For connecting the charging cable.
6. **Power Button/LED Indicator:** To turn the device on/off and show status.



Image: Hype Bluetooth Selfie Stick with a smartphone mounted. The image displays the adjustable phone holder, the telescopic monopod arm, and the handle with the integrated Bluetooth shutter button. The phone is securely held in landscape orientation.

SETUP INSTRUCTIONS

1. Charging the Selfie Stick (if applicable)

If your selfie stick is rechargeable, connect the provided charging cable to the charging port on the device and to a USB power source (e.g., computer USB port, wall adapter). The LED indicator will typically show red during charging and turn off or change color when fully charged. A full charge usually takes 1-2 hours.

2. Attaching Your Smartphone

1. Gently pull apart the adjustable smartphone holder to expand its grip.
2. Carefully insert your smartphone into the holder, ensuring it is centered and securely gripped. The holder is designed to fit devices with 4-5.5 inch screens.
3. Verify that the phone is stable and will not slip out when the stick is extended or moved.

3. Bluetooth Pairing

1. **Power On:** Press and hold the power button on the selfie stick handle for a few seconds until the LED indicator light starts blinking, indicating it's in pairing mode.
2. **Activate Bluetooth:** On your smartphone, go to Settings > Bluetooth and turn Bluetooth ON.
3. **Search for Devices:** Your phone will search for available Bluetooth devices. Look for "Hype Selfie Stick" or a similar name in the list.
4. **Pair:** Select the selfie stick from the list. The LED indicator on the selfie stick will typically stop blinking and remain solid, confirming a successful connection.
5. **Open Camera App:** Once paired, open your smartphone's camera application.

Note: The selfie stick should automatically reconnect to your phone when powered on if it was previously paired and your phone's Bluetooth is active.

OPERATING INSTRUCTIONS

1. Extending and Retracting the Monopod

- To extend: Gently pull the telescopic sections of the monopod outwards to your desired length. The stick can extend up to 40 inches (approximately 101 cm).
- To retract: Push the telescopic sections back into the handle until fully collapsed for compact storage.

2. Adjusting the Angle

The smartphone holder features an adjustable head that allows for 180-degree rotation. Loosen the adjustment knob (if present) or gently pivot the holder to achieve the desired shooting angle, then tighten to secure it.

3. Taking Photos

1. Ensure your smartphone is securely mounted and the selfie stick is paired via Bluetooth.
2. Open your smartphone's camera application.
3. Position the selfie stick and your phone to frame your shot.
4. Press the Bluetooth shutter button on the selfie stick handle to take a photo.

Tip: Some phones may require you to set the volume button function to "shutter" in the camera settings for the Bluetooth button to work correctly.

MAINTENANCE

- Cleaning:** Wipe the selfie stick with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Storage:** Store the selfie stick in a cool, dry place away from direct sunlight and extreme temperatures. Retract the monopod fully before storage.
- Battery Care:** If the device has a rechargeable battery, charge it periodically (e.g., every 3 months) even if not in use, to maintain battery health.

TROUBLESHOOTING

Problem	Solution
Selfie stick does not power on.	Ensure the device is charged (if rechargeable). Press and hold the power button for a longer duration.
Cannot pair with smartphone.	<ul style="list-style-type: none">Ensure the selfie stick is in pairing mode (blinking LED).Make sure Bluetooth is enabled on your phone.Forget previous pairings on your phone and try pairing again.Restart both your phone and the selfie stick.
Shutter button does not take photos.	<ul style="list-style-type: none">Verify the selfie stick is successfully paired with your phone.Check your phone's camera settings; ensure the volume button is set to trigger the shutter.Ensure the camera app is open and active.Some third-party camera apps may not be fully compatible. Try the default camera app.
Phone is not secure in the holder.	Ensure your phone's screen size is within the supported range (4-5.5 inches). Adjust the holder carefully to grip the phone firmly. Remove any bulky phone cases if they interfere with the grip.

SPECIFICATIONS

Model Number	HY-SLF-BT-PNK
Brand	Hype
Connectivity	Bluetooth
Max. Extendable Length	Up to 40 inches (approx. 101 cm)
Smartphone Compatibility	Most Android and iOS smartphones with 4-5.5 inch screens
Product Dimensions (Collapsed)	30.48 x 11.43 x 2.54 cm (approx. 12 x 4.5 x 1 inches)
Item Weight	141 g (approx. 0.31 lbs)

Color	Pink
-------	------

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the retailer where the product was purchased or visit the official Hype website. Keep your proof of purchase for warranty claims.

Disclaimer: Specifications are subject to change without notice. Hype is not responsible for any damage or data loss caused by improper use of this product.

© 2026 Hype. All rights reserved.