

[Manuals.plus](#) /

> [Indesit](#) /

> Indesit Refrigerator Freezer Right Door Closing Aid Instruction Manual for Models BAN134NFGUK, CA+138/1, B33FNFPUK

Indesit BAN134NFGUK, CA+138/1, B33FNFPUK

Indesit Refrigerator Freezer Right Door Closing Aid Instruction Manual

Models: BAN134NFGUK, CA+138/1, B33FNFPUK

1. PRODUCT OVERVIEW

This document provides essential information for the installation, operation, and maintenance of your genuine Indesit Refrigerator Freezer Right Door Closing Aid. This component is a crucial replacement part designed to ensure the proper closing mechanism of your appliance's door.

Compatible Models:

- BAN134NFGUK
- CA+138/1
- B33FNFPUK



Figure 1: The white plastic Indesit Refrigerator Freezer Right Door Closing Aid, shown from an angled perspective, highlighting its specific shape and attachment points.

2. INSTALLATION INSTRUCTIONS

Safety First: Before attempting any installation or replacement, ensure your refrigerator freezer is unplugged from the main power supply to prevent electrical hazards. Wear appropriate safety gloves if necessary.

1. **Identify the Existing Part:** Locate the current door closing aid on your refrigerator freezer. This is typically a small plastic bush or stopper located near the hinge mechanism on the right side of the door.
2. **Remove the Old Part:** Carefully remove the old or damaged closing aid. This may involve gently prying it out or unscrewing it, depending on the specific design of your appliance. Refer to your appliance's main service manual for precise removal instructions if available.
3. **Clean the Area:** Clean any debris or residue from the area where the new closing aid will be installed.
4. **Install the New Part:** Align the new Indesit Right Door Closing Aid with the designated slot or mounting point. Press firmly or secure it into place. Ensure it is seated correctly and does not wobble.
5. **Test Functionality:** Gently open and close the refrigerator freezer door several times to confirm that

the new closing aid functions correctly, allowing the door to close smoothly and securely.

6. **Restore Power:** Once satisfied with the installation, plug your refrigerator freezer back into the power supply.

3. OPERATION

The door closing aid operates passively. Its function is to provide a smooth and controlled closure for the refrigerator freezer door, preventing it from slamming shut and ensuring a tight seal. No user interaction is required for its operation once correctly installed.

4. MAINTENANCE

This part requires minimal maintenance. Periodically inspect the door closing aid for any signs of wear, cracks, or damage. If the part appears worn or damaged, replace it with a genuine Indesit replacement part to maintain optimal door function.

To clean, simply wipe the part with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the plastic material.

5. TROUBLESHOOTING

If you experience issues with your refrigerator freezer door after installing this part, consider the following:

- **Door Not Closing Properly:** Ensure the closing aid is securely seated and not obstructed. Check if the door hinges are aligned correctly.
- **Door Still Slams:** Verify that the closing aid is the correct part for your model and that it is installed in the correct orientation.
- **Part Appears Loose:** Re-check the installation to ensure the part is fully engaged in its mounting slot.

If problems persist, consult a qualified appliance technician or contact Indesit customer support.

6. SPECIFICATIONS

Brand	Indesit
Model Number	HPTC00115405
Item Weight	70 g
Manufacturer	Indesit
Part Type	Refrigerator Freezer Right Door Closing Aid / Stop Bush

7. WARRANTY AND SUPPORT

For information regarding warranty coverage for this genuine Indesit replacement part, please refer to the documentation provided with your original appliance or contact the retailer from whom you purchased this part. You may also visit the official [Indesit website](#) or contact their customer support for assistance.

Manufacturer: Indesit

This manual is for informational purposes only. Always refer to your appliance's specific service manual for detailed instructions.