

[Manuals.plus](#) /

› [MTD Genuine Parts](#) /

› MTD Genuine Parts Halogen Lamp (Model 925-1658) Instruction Manual

MTD Genuine Parts 925-1658

MTD Genuine Parts Halogen Lamp (Model 925-1658) Instruction Manual

1. INTRODUCTION

This manual provides essential information for the safe and effective installation, operation, and maintenance of your MTD Genuine Parts Halogen Lamp, Model 925-1658. This lamp is designed as an Original Equipment Manufacturer (OEM) authorized replacement part for various MTD outdoor power equipment models, ensuring compatibility and performance.

2. SAFETY INFORMATION

Please read and understand all safety instructions before installing or operating the halogen lamp. Failure to follow these instructions may result in personal injury or property damage.

- **Disconnect Power:** Always ensure the equipment is turned off and disconnected from its power source before attempting any installation, removal, or maintenance of the lamp.
- **High Temperature:** Halogen lamps operate at high temperatures. Allow the lamp to cool completely before handling to prevent burns.
- **Handle with Care:** Avoid touching the glass bulb directly with bare hands. Oils from your skin can create hot spots on the bulb, leading to premature failure. Use a clean, lint-free cloth or gloves when handling the bulb.
- **Correct Replacement:** Ensure the replacement lamp matches the original specifications (voltage, wattage) for your equipment. Using an incorrect lamp can cause damage or malfunction.
- **Disposal:** Dispose of old lamps according to local environmental regulations.

3. PRODUCT OVERVIEW

The MTD Genuine Parts Halogen Lamp (Model 925-1658) is a high-quality replacement light source for compatible MTD outdoor power equipment. It is designed to provide reliable illumination for various tasks.

Key Features:

- **Type:** Halogen
- **Wattage:** 26 watts

- **Brightness:** 400 lumens
- **Shape:** Tubular (T)
- **Compatibility:** OEM authorized part, fits various MTD models.



Image: A clear halogen lamp bulb with a two-pin base, attached to a dark grey plastic socket housing. This image shows the lamp in an upright position, highlighting its tubular glass and the integrated base.



Image: A side view of the halogen lamp, showing the elongated tubular glass bulb extending horizontally from its dark grey plastic socket base. The two metal pins connecting the bulb to the base are visible.

4. INSTALLATION INSTRUCTIONS

Follow these steps to safely install your MTD Genuine Parts Halogen Lamp. Always refer to your specific equipment's

owner's manual for detailed instructions on accessing the lamp housing.

- 1. Preparation:** Ensure your MTD equipment is completely turned off and disconnected from all power sources (e.g., remove spark plug wire, disconnect battery, unplug from AC outlet). Allow any existing lamp to cool down completely if it was recently in use.
- 2. Access Lamp Housing:** Locate the lamp housing on your equipment. This may involve removing a cover, grille, or other components. Consult your equipment's manual for precise access procedures.
- 3. Remove Old Lamp:** Carefully grasp the base of the old lamp and pull it straight out from its socket. Avoid twisting or excessive force, as this could damage the socket or break the bulb.
- 4. Install New Lamp:** Holding the new MTD Genuine Parts Halogen Lamp (Model 925-1658) by its plastic base (or using a clean cloth/gloves to handle the glass bulb), align the two metal pins with the corresponding holes in the socket. Gently push the lamp straight into the socket until it is firmly seated. Do not force it.
- 5. Secure Components:** Reassemble any covers, grilles, or other components that were removed to access the lamp housing. Ensure all parts are securely fastened.
- 6. Test Functionality:** Reconnect power to the equipment. Turn on the light switch to verify that the new lamp is functioning correctly.

5. OPERATION

The MTD Genuine Parts Halogen Lamp functions as a direct replacement for the original lamp in compatible MTD equipment. Once correctly installed, its operation is controlled by the equipment's existing lighting switch or system.

- To activate the lamp, turn on the equipment's designated light switch.
- To deactivate the lamp, turn off the equipment's designated light switch.

6. MAINTENANCE

Halogen lamps generally require minimal maintenance. Proper handling during installation and occasional cleaning will help ensure optimal performance and longevity.

- **Cleaning:** If the lamp's glass surface becomes dirty or smudged, gently wipe it with a clean, dry, lint-free cloth. Ensure the lamp is cool and disconnected from power before cleaning. Avoid using abrasive cleaners or solvents.
- **Replacement:** Replace the lamp when it burns out or its light output significantly diminishes. Refer to the installation instructions in Section 4 for proper replacement procedures.

7. TROUBLESHOOTING

If your MTD Genuine Parts Halogen Lamp is not functioning as expected, consult the table below for common issues and potential solutions.

Problem	Possible Cause	Solution
Lamp does not light up	No power to the equipment Loose connection Burned-out lamp Faulty switch/wiring in equipment	Check power supply to equipment Ensure lamp is fully seated in socket Replace lamp (refer to Section 4) Consult equipment service manual or a qualified technician

Problem	Possible Cause	Solution
Lamp is dim or flickers	Low voltage supply Loose connection Lamp nearing end of life	Check power supply to equipment Ensure lamp is fully seated in socket Replace lamp (refer to Section 4)

8. SPECIFICATIONS

Technical specifications for the MTD Genuine Parts Halogen Lamp, Model 925-1658:

- **Brand:** MTD Genuine Parts
- **Model Number:** 925-1658
- **Light Type:** Halogen
- **Wattage:** 26 watts
- **Incandescent Equivalent Wattage:** 100 Watts
- **Brightness:** 400 lumens
- **Shape:** Tubular (T)
- **Material (Base):** Plastic
- **Indoor/Outdoor Usage:** Outdoor
- **Power Source:** AC adapter (as supplied by equipment)
- **Product Dimensions:** 7.75 x 6.5 x 4.5 inches (approximate, may refer to packaging)
- **Item Weight:** 0.458 ounces
- **UPC:** 889021077655

9. WARRANTY AND SUPPORT

For warranty information or technical support regarding your MTD Genuine Parts Halogen Lamp (Model 925-1658), please refer to the documentation provided with your specific MTD equipment or contact MTD Genuine Parts customer service directly.

You can also visit the official MTD Genuine Parts store for additional product information and support resources:

[MTD Genuine Parts Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question