

Dyson DC39

Dyson Nozzle Assembly, Floor DC39 Instruction Manual

Model: DC39 | OEM Part Number: 923181-03

INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of your Dyson Nozzle Assembly, Floor DC39. This is an original equipment manufacturer (OEM) authorized replacement part designed to fit various Dyson DC39 vacuum cleaner models. Please read these instructions carefully before use to ensure optimal performance and longevity of the product.

SETUP AND INSTALLATION

The Dyson Nozzle Assembly is designed for straightforward attachment to your compatible Dyson DC39 vacuum cleaner. Ensure the vacuum is unplugged before attempting installation.

- 1. Identify Connection Point:** Locate the connection point at the end of your vacuum's wand or hose where the previous floor tool was attached.
- 2. Align Nozzle:** Align the new Dyson Nozzle Assembly with the connection point. The nozzle is designed to fit securely.
- 3. Secure Attachment:** Push the nozzle firmly onto the wand/hose until it clicks into place. A secure connection is crucial for effective suction and operation.
- 4. Verify Connection:** Gently tug on the nozzle to ensure it is properly locked and will not detach during use.



Image: Dyson Nozzle Assembly, Floor DC39. This image shows the complete nozzle assembly, highlighting its design and connection point for attachment to the vacuum cleaner wand.

OPERATING INSTRUCTIONS

Once the nozzle assembly is securely attached, you can begin using your Dyson DC39 vacuum. This floor nozzle is designed to effectively clean various floor surfaces.

- **Power On:** Turn on your Dyson DC39 vacuum cleaner.
- **Surface Cleaning:** Guide the nozzle across the floor surface. The brush bar inside the nozzle is designed to agitate carpet fibers for deep cleaning and to sweep debris on hard floors.
- **Maneuverability:** The nozzle features a swivel neck for easy maneuverability around furniture and obstacles.
- **Optimal Performance:** For best results, move the nozzle in a steady, overlapping pattern.

MAINTENANCE

Regular maintenance of your Dyson Nozzle Assembly ensures consistent performance and extends its lifespan.

- **Brush Bar Inspection:** Periodically inspect the brush bar for tangled hair, threads, or debris. Excessive build-up can reduce cleaning effectiveness and strain the motor.
- **Cleaning the Brush Bar:** To clean, detach the nozzle from the vacuum. Use scissors or a seam ripper to carefully cut away any tangled material from the brush bar. Avoid pulling forcefully, as this can damage the bristles.
- **Check for Obstructions:** Ensure the air pathways within the nozzle are clear of any blockages.
- **Exterior Cleaning:** Wipe the exterior of the nozzle with a damp cloth. Do not use harsh chemicals or abrasive cleaners.

TROUBLESHOOTING

If you encounter issues with your Dyson Nozzle Assembly, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Brush bar not spinning or spinning slowly	Tangled debris, obstruction, or worn components.	Clean the brush bar of any tangled hair or debris. Check for blockages in the nozzle's air path. If the issue persists, the internal mechanism may require professional inspection or replacement.
Reduced suction at the nozzle	Blockage in the nozzle, wand, or hose; improper attachment.	Ensure the nozzle is securely attached to the vacuum. Check the nozzle, wand, and hose for any obstructions and remove them. Verify the vacuum's dust bin is not full and filters are clean.
Unusual noises from the nozzle	Foreign object caught in the brush bar or internal components.	Immediately turn off and unplug the vacuum. Inspect the brush bar and internal areas of the nozzle for any foreign objects and remove them.

SPECIFICATIONS

- **Product Dimensions:** 1 x 1 x 1 inches
- **Item Weight:** 1 pound
- **Item Model Number:** 923181-03
- **Manufacturer:** Dyson
- **Compatibility:** Designed for Dyson DC39 models

WARRANTY AND SUPPORT

This Dyson Nozzle Assembly comes with a **1-day warranty**. For any issues or further assistance beyond the scope of this manual, please contact Dyson customer support or refer to your original Dyson vacuum cleaner manual for comprehensive support information.

For additional resources, you may visit the official Dyson website or contact their customer service department directly.