Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GREENHOUSE CM658-A

GREENHOUSE CM Lighted Natural Wreath with Plate L Illumination

Model: CM658-A | Brand: GREENHOUSE

1. Introduction

Thank you for purchasing the GREENHOUSE CM Lighted Natural Wreath. This beautiful wreath is crafted from natural materials and features integrated LED lighting to enhance its aesthetic appeal. It includes a removable plate for versatile display options and is designed for indoor decorative use.

This manual provides essential information for the proper setup, operation, and maintenance of your lighted natural wreath to ensure its longevity and optimal performance.

2. Package Contents

Please verify that all items listed below are present in your package:

- 1 x GREENHOUSE CM Lighted Natural Wreath
- 1 x Removable Decorative Plate

Note: 2 AA batteries are required for the LED light function and are sold separately.

3. Setup

3.1 Battery Installation

1. Locate the battery compartment on the reverse side of the wreath.
2. Open the battery compartment cover.
3. Insert 2 AA batteries (not included), ensuring correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.

3.2 Wreath Placement

The wreath is designed for indoor use. Choose a suitable location for display, such as a wall, door, or mantelpiece. Ensure the surface is clean and dry before hanging.



Figure 3.2.1: The GREENHOUSE CM Lighted Natural Wreath in its unlit state, showcasing its natural elements like pinecones, small stars, and a decorative tag.

3.3 Attaching the Removable Plate

The decorative plate can be attached to the center of the wreath if desired. Align the plate with the designated area and secure it gently. The plate is designed to be easily removable for alternative display options.

4. Operating Instructions

4.1 Turning the LED Lights On/Off

Once batteries are installed, locate the ON/OFF switch on the reverse side of the wreath, near the battery compartment.

- To turn the LED lights **ON**, slide the switch to the "ON" position.
- To turn the LED lights **OFF**, slide the switch to the "OFF" position.



Figure 4.1.1: The GREENHOUSE CM Lighted Natural Wreath with its integrated LED lights illuminated, providing a warm and inviting glow. The lights are powered by 2 AA batteries.

5. Maintenance

5.1 Cleaning

To clean the wreath, gently dust it with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials, as these may damage the natural components or the LED lights.

5.2 Battery Replacement

When the LED lights dim or stop working, it is time to replace the batteries. Follow the steps in Section 3.1 Battery Installation to replace the 2 AA batteries.

5.3 Storage

When not in use, store the wreath in a cool, dry place, away from direct sunlight and extreme temperatures. If storing for an extended period, remove the batteries to prevent leakage.

6. Troubleshooting

Problem	Possible Cause	Solution
LED lights do not turn on.	Batteries are dead or incorrectly installed.	Check battery polarity. Replace with new AA batteries.
LED lights are dim.	Batteries are low.	Replace with new AA batteries.
Wreath appears damaged.	Improper handling or storage.	Handle with care. Store in a protected environment.

7. Specifications

- **Model:** CM658-A
- **Product Dimensions:** 13.4 x 13.4 x 2.8 inches (340 x 340 x 70 mm)
- **Item Weight:** 1.75 pounds (0.79 kg)
- **Main Materials:** Natural material, Styrofoam, Wood, ABS resin
- **Power Source:** 2 x AA Batteries (not included)

8. Warranty and Support

This product is designed for decorative purposes and is manufactured with quality materials. For any questions regarding the product's function or care, please refer to the information provided in this manual.
Please note that specific warranty details may vary by region and retailer. For further assistance or inquiries, please contact your point of purchase or refer to the manufacturer's official website for support information.

© 2023 GREENHOUSE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00YBIN6J4

More documents and user manuals: **https://manuals.plus/**