Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Denali Pure WF-UKF8001-DL474

Denali Pure Refrigerator Water Filter Instruction Manual

Model: WF-UKF8001-DL474

This manual provides essential information for the installation, operation, and maintenance of your Denali Pure Refrigerator Water Filter.

1. Introduction

Thank you for choosing the Denali Pure Refrigerator Water Filter. This filter is designed to provide clean, great-tasting water by reducing chlorine, taste, and odor. For optimal performance and safety, please read this manual thoroughly before installation and keep it for future reference.
This product is a replacement part and is not an OEM (Original Equipment Manufacturer) product. All mentions of brand names or model descriptions are made strictly to illustrate compatibility. All brand names and logos are registered trademarks of their respective owners. This product is not affiliated with any OEM brands and is not covered under any warranties offered by the original manufacturers. Any warranties for this product are offered solely by Denali Pure.

2. Safety Information

- Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system.
- Ensure the filter is installed correctly to prevent leaks.
- Replace the filter at the recommended interval to maintain water quality and prevent potential issues.
- Keep this product away from direct sunlight and heat sources.

3. Compatibility

The Denali Pure WF-UKF8001-DL474 water filter is compatible with various refrigerator models, including but not limited to:

- **Kenmore/Sears:** 59676603600, 46-9006, 46-9992, 46-9005, 469005, 9005, 9005P
- **Maytag/Amana:** UKF8001, UKF8001-750, UKF8001AXX, UKF8001AXX-200, UKF8001AXX-750, UKF8001AXXP, UKF8001AXXT, UKF8001P, UKF8001T
- **Whirlpool:** WF50, OWF50, WF51, OWF51



Image: Denali Pure filter with a list of compatible Maytag/Amana, Whirlpool, and Kenmore models.

4. Setup and Installation

Follow these steps for easy and tool-free installation:

1. **Locate the Filter:** Your refrigerator's water filter is typically located in the upper right corner of the fresh food compartment, or in the base grille. Refer to your refrigerator's manual for the exact location.
2. **Prepare for Removal:** Turn off the ice maker (if applicable) and dispense about a gallon of water to relieve pressure in the water line.
3. **Remove Old Filter:** Twist the old filter counter-clockwise a quarter turn to unlock it, then pull it straight out. Some water may drip, so have a towel ready.
4. **Install New Filter:** Remove the protective cap from the new Denali Pure filter. Insert the new filter into the filter housing, aligning the arrow on the filter with the arrow on the housing.
5. **Lock Filter:** Push the filter firmly into the housing and twist it clockwise a quarter turn until it locks into place. You should feel it click.
6. **Flush the System:** Run water through the dispenser for approximately 3-5 minutes (about 2-3 gallons) to flush out air and carbon fines. This is normal for new filters.
7. **Check for Leaks:** Inspect the filter area for any signs of water leakage.
8. **Reset Filter Indicator:** If your refrigerator has a filter indicator light, reset it according to your refrigerator's instructions. This usually involves pressing and holding a "Filter" or "Reset" button for a few seconds.



Image: Demonstrates the ease of installation for the Denali Pure water filter.

5. Operating Instructions

Once installed, the Denali Pure water filter operates automatically as part of your refrigerator's water dispensing and ice-making system. No special operation is required beyond regular use.

- **Water Dispensing:** Use your refrigerator's water dispenser as usual. The filter will purify the water as it passes through.
- **Ice Production:** The filter also supplies purified water to the ice maker, ensuring clean ice cubes.

6. Maintenance

Regular filter replacement is crucial for maintaining water quality and optimal performance.

- **Replacement Schedule:** For best performance, replace your Denali Pure water filter every **6 months** or sooner if water flow noticeably decreases.
- **Filter Indicator:** Pay attention to your refrigerator's filter change indicator light, if equipped. Reset it after each replacement.
- **Storage:** Store new, unused filters in a cool, dry place away from direct sunlight.



Image: Reminder to replace the water filter every 6 months for optimal performance.

7. Troubleshooting

Problem	Possible Cause	Solution
Slow water flow from dispenser	Clogged filter, air in system, low water pressure	Replace filter, flush system for 3-5 minutes, check household water pressure.
Water tastes or smells bad	Expired filter, new filter not flushed properly	Replace filter, flush system thoroughly (5+ gallons).
Water leaks from filter area	Filter not installed correctly, damaged O-rings	Re-install filter, ensuring it's fully seated and twisted clockwise. Check O-rings for damage.
Black particles in water	Carbon fines from new filter	Flush system for 3-5 minutes until water runs clear. This is normal for new carbon filters.

8. Specifications

- **Model:** WF-UKF8001-DL474
- **Filter Type:** Activated Carbon Block
- **Certification:** System Tested and Certified by NSF International against NSF/ANSI Standard 42 for the reduction of Chlorine, Taste and Odor.
- **Operating Temperature:** 33°F - 100°F (0.6°C - 38°C)
- **Operating Pressure:** 30 psi - 100 psi (207 kPa - 689 kPa)
- **Flow Rate:** 0.5 GPM (1.9 LPM)
- **Filter Life:** 6 months or 300 gallons (1136 liters), whichever comes first.



Image: Denali Pure filters are NSF Certified against Standard 42 for chlorine, taste, and odor reduction.



Image: Internal structure of the filter, highlighting the high-quality activated carbon and coconut shell cartridge.

9. Warranty

Any warranties for this Denali Pure product are offered solely by Denali Pure. Please refer to the product packaging or contact Denali Pure customer support for specific warranty terms and conditions.
Note: This product is a replacement part and is not covered under any warranties offered by the original equipment manufacturers (OEMs) of the compatible refrigerators.

10. Customer Support

For further assistance, questions, or to report any issues, please contact Denali Pure customer support. Contact information may be available on the product packaging or through the retailer where the product was purchased. You can also visit the Denali Pure brand store on Amazon for more information:Denali Pure Store

© 2024 Denali Pure. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00YD2YTHG

More documents and user manuals: **https://manuals.plus/**