



Manuals.plus /

› TWING /

› TWING 5x7 Acrylic Magnetic Picture Frame Instruction Manual - Model 256562

## TWING 256562

# TWING 5x7 Acrylic Magnetic Picture Frame Instruction Manual

Model: 256562

## PRODUCT OVERVIEW

---

The TWING 5x7 Acrylic Magnetic Picture Frame is designed to elegantly display your cherished photos or artwork. Made from high-quality, clear acrylic, this frameless design allows your images to take center stage. Its double-sided magnetic closure ensures easy photo insertion and secure display on any desktop or tabletop surface.



*Image: The TWING 5x7 Acrylic Magnetic Picture Frame, showcasing its clear design and magnetic corners.*

## KEY FEATURES

---

- **High-Quality Acrylic:** Constructed from super clear, high-quality plexiglass material, 12 + 12MM thickness for enhanced sturdiness.
- **Strong Magnetic Hold:** Four pairs of strong magnets securely hold the frame panels together, ensuring precise alignment.
- **Double-Sided Display:** Allows viewing of pictures from both sides, suitable for single or double-sided photo display.
- **Free-standing Design:** Designed for desktop use only; cannot be hung. Supports both horizontal and vertical orientation.
- **Frameless Aesthetic:** Provides a modern, minimalist look that highlights your photos or artwork.

## PACKAGE CONTENTS

---

- 1 x TWING 5x7 Acrylic Magnetic Picture Frame
- 1 x Microfiber Cleaning Cloth

The acrylic frame was wrapped with PE bag, thickening bubble mailer and carton box that ensure safe delivery without scratches and without any other damage



*Image: The TWING 5x7 Acrylic Frame shown with its protective packaging and included microfiber cloth.*

## SETUP AND INSTALLATION

---

### 1. Inserting a Photo

1. Gently separate the two acrylic panels of the frame. The magnets are strong, so a firm but careful pull is recommended.
2. Remove any protective film from both sides of each acrylic panel before use to ensure maximum clarity.

3. Place your 5x7 inch photo or artwork onto one of the acrylic panels, ensuring it is centered as desired.
4. Align the second acrylic panel precisely over the first, allowing the magnets to snap together and secure your photo in place.



*Image: The two acrylic panels of the frame separated, showing the magnetic points.*

## 2. Frame Orientation

The TWING 5x7 Acrylic Magnetic Picture Frame is designed to stand freely on any flat surface. It can be displayed in either horizontal or vertical orientation, depending on your photo and preference.



*Image: The TWING 5x7 Acrylic Frame displaying a photo in horizontal orientation on a shelf.*



*Image: The TWING 5x7 Acrylic Frame displaying a photo in vertical orientation on a desk.*

### **3. Double-Sided Display**

Utilize the double-sided feature by inserting two photos back-to-back. This allows for versatile display options, showcasing different images from various angles.



## Double sided available

*Image: The TWING 5x7 Acrylic Frame demonstrating its double-sided display capability with two photos.*

### Setup Demonstration Video

Your browser does not support the video tag.

*Video: A demonstration by Twing Republic showing how to insert a photo and assemble the TWING Acrylic Photo Frame, highlighting its magnetic closure and clear design.*

### CARE AND MAINTENANCE

---

- **Cleaning:** Use the provided microfiber cloth to gently wipe the acrylic surfaces. For stubborn smudges, slightly dampen the cloth with water. Avoid abrasive cleaners or paper towels, which can scratch the acrylic.
- **Handling:** While durable, acrylic can scratch. Handle the frame with care and avoid placing it on rough surfaces.
- **Placement:** Keep the frame away from direct sunlight for prolonged periods to prevent potential

fading of photos.

## TROUBLESHOOTING

---

- **Frame not standing upright:** Ensure the frame is placed on a completely flat and stable surface. The thick acrylic is designed for stability.
- **Photos slipping:** Verify that the two acrylic panels are fully aligned and the magnets are securely engaged.
- **Scratches on acrylic:** Minor scratches can sometimes be buffed out with specialized acrylic polish. Prevent scratches by using the microfiber cloth for cleaning and handling with care.

## PRODUCT SPECIFICATIONS

---

Specification	Detail
Brand	TWING
Model Number	256562
Product Dimensions	7"L x 5"W
Frame Material	Acrylic
Cover Material	Acrylic
Thickness	12 + 12MM (total 24MM)
Mounting Type	Tabletop
Orientation	Vertical or Horizontal
Special Feature	Magnetic, Double-Sided, Lightweight
Item Weight	1.3 Pounds

## WARRANTY AND SUPPORT

---

For any questions regarding your TWING 5x7 Acrylic Magnetic Picture Frame, please contact the manufacturer directly through your purchase platform. Please retain your proof of purchase for any warranty claims or support inquiries.

