Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Kaiser /
- > Kaiser EH 6355 Em Built-in Electric Oven Instruction Manual

Kaiser EH 6355 Em

Kaiser EH 6355 Em Built-in Electric Oven Instruction Manual

Model: EH 6355 Em | Brand: Kaiser

1. Introduction

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Kaiser EH 6355 Em built-in electric oven. Please read these instructions carefully before using the appliance and keep them for future reference.



Figure 1: Front view of the Kaiser EH 6355 Em built-in electric oven, showcasing its black finish and bronze Empire design elements.

2. SAFETY INSTRUCTIONS

Always adhere to the following safety guidelines to prevent accidents and ensure proper functioning of the oven:

- Ensure the oven is correctly installed by a qualified technician before first use.
- Do not allow children to operate the oven unsupervised. The oven surfaces can become very hot during operation.
- Always use oven mitts when handling hot dishes or oven accessories.
- Never use abrasive cleaners or sharp objects to clean the oven interior or exterior, as this can damage surfaces.
- Keep flammable materials away from the oven during operation.
- If the power cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.

3. PRODUCT OVERVIEW

The Kaiser EH 6355 Em is a 60 cm built-in electric oven featuring a classic Empire design with modern functionality. Key components include:

- Control Knobs: Electromechanical rotary knobs for function selection and temperature control.
- Analog Clock: Electronic analog timer with automatic shut-off and acoustic signal.
- Oven Door: Triple-glazed for improved insulation, with a removable inner glass pane for easy cleaning.
- Oven Cavity: Features catalytic self-cleaning panels and Easy Clean enamel for simplified maintenance.
- Accessories: Includes a rotisserie spit, baking tray, and oven rack.



Figure 2: The oven's distinctive Empire design with bronze accents and branding.



Figure 3: Detailed view of the electromechanical control knobs, used for selecting oven functions and setting temperature.



Figure 4: The electronic analog clock, which functions as a timer and provides automatic shut-off.

4. SETUP & INSTALLATION

The Kaiser EH 6355 Em oven is designed for built-in installation into a standard 60 cm kitchen cabinet. Professional installation is recommended.

4.1 Unpacking

- Carefully remove all packaging materials.
- Inspect the oven for any signs of damage. If damaged, do not install and contact your supplier.
- Retain packaging for potential future transport or service.

4.2 Electrical Connection

- Ensure the electrical supply matches the voltage and frequency specified on the oven's rating plate.
- The oven must be properly earthed.
- The electrical connection should be made by a qualified electrician.

4.3 Cabinet Installation

- Ensure the cabinet opening dimensions match the oven's dimensions (refer to Section 7: Specifications).
- Provide adequate ventilation around the oven to prevent overheating.
- Secure the oven into the cabinet using the provided screws.



Figure 5: Diagram illustrating the external dimensions of the Kaiser EH 6355 Em oven for installation planning.

5. OPERATING INSTRUCTIONS

Your Kaiser EH 6355 Em oven offers 8 multifunction cooking modes. Familiarize yourself with the controls before use.

5.1 Setting the Time

- Upon first connection or after a power outage, the clock will need to be set.
- Refer to the specific instructions in the full user manual for setting the electronic analog clock.

5.2 Selecting a Cooking Function

• Turn the left control knob to select the desired cooking function (e.g., Top/Bottom Heat, Convection, Grill, Rotisserie).

5.3 Setting the Temperature

- Turn the right control knob to set the desired temperature for your chosen function.
- The oven will begin to heat up once both function and temperature are set.

5.4 Using the Timer

- The analog clock can be used as a minute minder or to program the cooking duration.
- When programmed for cooking duration, the oven will automatically switch off after the set time. An
 acoustic signal will sound.

5.5 Cooking Modes

The oven features 8 cooking modes, including:

- Top/Bottom Heat: Traditional baking and roasting.
- Convection (Fan-assisted): For even cooking on multiple levels.
- Infrared Grill: For grilling and browning.
- Rotisserie: For roasting poultry or large cuts of meat evenly.
- Defrost: Gentle thawing of frozen foods.



Figure 6: The oven interior, highlighting the hot air system for uniform heat distribution and the circulation system for cooling.

Figure 7: The oven door, featuring triple glazing and a convenient recipe table printed on the inner glass for quick reference.

6. MAINTENANCE & CLEANING

Regular cleaning and maintenance will prolong the life of your oven and ensure optimal performance.

6.1 Catalytic Self-Cleaning

- The oven is equipped with catalytic panels that absorb grease and food residues.
- During normal operation at high temperatures (above 200°C), these panels oxidize and break down residues.
- For heavy soiling, run the oven at its maximum temperature for approximately one hour.
- After cooling, wipe away any remaining ash with a damp cloth.

6.2 Easy Clean Enamel

- The oven interior is coated with Easy Clean enamel, making it smooth and easy to wipe clean.
- Use a soft cloth and mild detergent for cleaning. Avoid abrasive sponges or harsh chemicals.

6.3 Exterior Cleaning

- Clean the exterior surfaces with a soft cloth and a non-abrasive cleaner.
- For bronze elements, use a specialized cleaner suitable for metal finishes to maintain their appearance.

6.4 Oven Door Cleaning

• The inner glass pane of the oven door can be removed for thorough cleaning. Refer to the full manual for instructions on how to safely remove and reattach it.

7. TROUBLESHOOTING

If you encounter issues with your oven, consult the following table before contacting service.

Problem	Possible Cause	Solution
Oven does not heat up	No power supply; Function/temperature not set; Timer not set correctly	Check power connection; Ensure function and temperature knobs are set; Set the timer or ensure it's not in automatic shut-off mode.
Uneven cooking results	Incorrect temperature/function; Overloading oven; Improper placement of dishes	Verify settings; Avoid overcrowding; Use appropriate rack positions.
Oven light not working	Bulb faulty or loose	Replace the oven bulb (ensure oven is cool and disconnected from power).
Excessive smoke during cooking	Food spillage; Excessive fat/grease	Clean oven interior thoroughly; Use a drip tray for fatty foods.

8. SPECIFICATIONS

Detailed technical specifications for the Kaiser EH 6355 Em built-in electric oven:

Feature	Specification
Brand	Kaiser
Model Number	EH 6355 Em
Туре	Built-in Electric Oven

Feature	Specification
Size	60 cm
Color	Black with Bronze Accents
Heating Method	Multifunction (Top/Bottom Heat, Convection, Grill, Rotisserie)
Number of Cooking Functions	8
Energy Efficiency Class	A
Cavity Volume	67 Liters
Energy Consumption (Conventional)	0.90 kWh/cycle
Energy Consumption (Convection)	0.81 kWh/cycle
Control Type	Electromechanical Rotary Knobs
Timer	Electronic Analog Clock with Automatic Shut-off
Cleaning System	Catalytic Self-Cleaning, Easy Clean Enamel
Oven Door	Triple Glazed, Removable Inner Glass
Dimensions (W x H x D)	594 mm x 594 mm x 543 mm




Figure 8: The EU energy label for the Kaiser EH 6355 Em oven, indicating its A-class energy efficiency.

Produktdatenblatt	
Delegierte Verordnung (EU) Nr. 65/2014	
Name oder Warenzeichen des Lieferanten	Kaiser
Modellkennung	EH 6355 Em
Anzahl der Garräume	1
Garraum 1	
Energieeffizienzindex	102,5
Energieeffizienzklasse	Α
Energieverbrauch pro Zyklus (konventioneller Modus)	0,90 kWh
Energieverbrauch pro Zyklus (Umluft-Modus)	0,81 kWh
Wärmequelle	Strom
Volumen	67 Liter

Figure 9: Product data sheet providing detailed energy consumption and volume information for the oven.

9. WARRANTY & SUPPORT

Your Kaiser EH 6355 Em oven comes with a manufacturer's warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included with your product or visit the official Kaiser website.

For technical support, spare parts, or service requests, please contact your retailer or an authorized Kaiser service center. When contacting support, please have your model number (EH 6355 Em) and serial number readv.

Information regarding returns and refunds within 30 days of receipt, or for defective/damaged products, can typically be found on the retailer's help pages where the product was purchased.

© 2025 Kaiser. All rights reserved.

Related Documents - EH 6355 Em



Kaiser EH Built-in Electric Oven User Manual

Comprehensive user manual for the Kaiser EH built-in electric oven, detailing installation, operation, safety, maintenance, and practical cooking advice. Features include multifunctionality, PYROLYSE XXL, and Air Fryer capabilities.



<u>Lisdexamfetamine (Vyvanse) Drug Coverage Criteria | Kaiser Permanente</u>

Detailed criteria for the coverage of Lisdexamfetamine (Vyvanse) for Binge Eating Disorder and ADHD/ADD, as provided by Kaiser Permanente's Prescribing Program.



Gaggenau EM 220/221 Built-in Microwave with Grill User and Installation Manual

This manual provides comprehensive instructions for the Gaggenau EM 220/221 built-in microwave with grill, covering operation, safety, cleaning, maintenance, and installation. Learn how to use microwave, grill, and combination functions, program multi-level cooking, set the clock, and activate child lock. Includes troubleshooting tips and technical specifications.



Kaiser EH 63... Built-in Electric Oven User Manual

Comprehensive user manual for the Kaiser EH 63... built-in electric oven, covering installation, safety, usage, and maintenance instructions in multiple languages.



Kaiser Permanente 2025 Benefits and Services Guide for the District of Columbia

A guide to Kaiser Permanente's 2025 benefits and services for individuals and families in the District of Columbia, including membership agreement and evidence of coverage details.



NI 62xx/63xx Pinout Labels for SCB-68A

Provides pinout labels for National Instruments (NI) 62xx and 63xx series multifunction I/O modules and devices when used with the SCB-68A shielded connector block, detailing connections for various connectors and configurations.


Documents - Kaiser - EH 6355 Em



[pdf] Datasheet

A Stieben Data sheet Kaiser Empire EH6355 Em oven Skinflint Price Comparison UK 45f7ed5f1f14d5dff8d1d6100d9fb5d5b07b gzhls at blob ldb 5 1 d 7 |||


GB ELECTRIC AND GAS OVENS: This appliance complies with the eco-design requirements of Regulation E ... tests that simulate the thermal properties of foods. Consumption depends on the mode of use Kaiser EH 6355 Em 102,5 A 0,9 0,81 1 electric 67 L Product information complies with Commission Delegated ... lang:en score:21 filesize: 48.64 K page_count: 1 document date: 2015-03-30



[pdf] Label

Energie Labels Korrektur v OLAN cdr A Kashin Energy label Kaiser Empire EH6355 Em oven Skinflint Price Comparison UK 6f857a39b91ff9201aacc2a0f78e97456d7a gzhls at blob ldb 8 1 7 3 ||| EH 6355 Em A 0.90 67 0.81 ...

lang:en score:15 filesize: 60.98 K page_count: 1 document date: 2015-03-31



[pdf] Guide Catalog

Скачать каталог 2022 Kaiser Compressed 2 32606c10 be86 40b7 b116 e9a5793740fb v 1669290478 cdn shopify s files 1 0627 0012 6414 |||

CONTENTS 1. Ovens and built-in cookers 1.1 Electric ovens 1.2 Gas ovens 2. Hobs 2.1 Glass ceramic ... ,5 66,0 19 20 ELECTRIC OVENS Electric oven with electromechanical programmer Knobs control EH 6355 Em EH 6355 ElfEm EH 6355 RotEm Anthracite colored enamel Ivory colored enamel Design P...

lang:en score:10 filesize: 18.92 M page_count: 93 document date: 2022-10-11