

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› **SRG /**

› SRG 18 Ounce Raspberry Sorbet Scented Glass Jar Container Candle Instruction Manual

SRG AX-AY-ABHI-98142

SRG 18 Ounce Raspberry Sorbet Scented Glass Jar Container Candle Instruction Manual

Model: AX-AY-ABHI-98142

INTRODUCTION

This instruction manual provides essential information for the safe and effective use of your SRG 18 Ounce Raspberry Sorbet Scented Glass Jar Container Candle. Please read all instructions carefully before use and retain this manual for future reference.



Image: A clear glass jar candle filled with red wax, featuring a label that reads 'Raspberry Sorbet scented candle'. The jar has a clear glass lid.

IMPORTANT SAFETY INFORMATION

WARNING: Failure to follow these instructions could result in fire hazard, injury, or property damage.

- Always burn candle within sight. Never leave a burning candle unattended.
- Keep burning candles away from flammable materials, such as curtains, bedding, paper, and decorations.
- Keep out of reach of children and pets.
- Place candle on a stable, heat-resistant surface. Avoid burning on or near anything that can catch fire.
- Do not burn candle for more than 4 hours at a time.
- Trim wick to 1/4 inch (6mm) before each lighting. Long wicks can cause high flames, smoking, or soot.

- Do not move a burning candle. Allow wax to cool and harden before moving.
- Extinguish candle if the flame becomes too high or flickers repeatedly. Let it cool, trim the wick, and then relight.
- Do not burn candle down to the very bottom of the container. Discontinue use when 1/2 inch (13mm) of wax remains to prevent heat damage to the container or surface.
- Avoid drafts, which can cause uneven burning, excessive smoking, or flame flare-ups.

SETUP

1. **Unpack:** Carefully remove the candle from its packaging.
2. **Inspect:** Check the candle for any damage or cracks in the glass container. Do not use if damaged.
3. **Placement:** Place the candle on a flat, stable, heat-resistant surface, away from anything flammable, drafts, children, and pets.
4. **Wick Trim:** Ensure the wick is trimmed to approximately 1/4 inch (6mm) before the first burn.

OPERATING INSTRUCTIONS

1. **Lighting:** Light the wick carefully with a long match or lighter.
2. **First Burn:** For the first burn, allow the candle to burn until the entire top layer of wax has melted to the edges of the container. This typically takes 2-4 hours and helps prevent tunneling.
3. **Subsequent Burns:** After the first burn, do not burn the candle for more than 4 hours at a time. This helps maintain the candle's integrity and scent throw.
4. **Extinguishing:** Use a snuffer to extinguish the flame. Do not use the lid to extinguish the flame as this can cause soot to accumulate on the lid and potentially damage it.

MAINTENANCE

- **Wick Trimming:** Before each use, trim the wick to 1/4 inch (6mm). This promotes a clean burn and prevents excessive soot.
- **Keep Wax Pool Clean:** Ensure no debris, such as wick trimmings or matches, accumulates in the wax pool.
- **Storage:** Store candles in a cool, dry place, away from direct sunlight or strong artificial light, to prevent discoloration and melting.

TROUBLESHOOTING

Issue	Possible Cause	Solution
Tunneling (wax left on sides)	First burn was too short.	Ensure the first burn melts wax to the container edges. For existing tunnels, you can gently push down soft wax towards the center after extinguishing, or use aluminum foil to create a "hood" during a short burn to melt the edges.

Issue	Possible Cause	Solution
Excessive Smoke/Soot	Wick is too long or candle is in a draft.	Trim the wick to 1/4 inch (6mm) before each use. Move the candle away from drafts.
Weak Scent	Room size is too large for candle, or candle is old.	Ensure the candle is appropriate for the room size. Store candles properly to preserve scent.
Flame is too small/flickering	Wick is too short or clogged.	Gently remove any debris from the wax pool. If the wick is too short, allow a small amount of wax to melt, then pour it out (carefully!) to expose more wick.

SPECIFICATIONS

Brand: SRG

Model Number: AX-AY-ABHI-98142

Scent: Raspberry Sorbet

Container Material: Glass

Wax Material: 100% Paraffin Wax

Wick Material: 100% Cotton Wick

Item Weight: 2.2 Pounds (approximately 998 grams)

Product Dimensions: 3.5 x 3.5 x 5.5 inches (approximately 8.9 x 8.9 x 14 cm)

Burn Time: Up to 40 hours

Indoor/Outdoor Usage: Indoor

UPC: 814465020608

WARRANTY AND SUPPORT

For information regarding warranty, returns, or product support, please refer to the retailer's policy where the product was purchased or contact SRG customer service directly. Contact details are typically available on the product packaging or the manufacturer's official website.